

ENGINEERING SOLUTIONS FOR DESIGN & MANUFACTURING

NASA Software of the Year

Diamondlike Carbon Coatings Resist Erosion & Cracking

Photonics Tech Briefs

Motion Control Tech Briefs

REFERENCE
COPY OCT 18 1964
KSC LIBRARY


000003764545 NB 0102
LDU OFFMER
LIBRARIAN
JDI
LIBRARY C
KENNEDY SPACE CENTER FL 32899-0001

82
0003
0048-26

www.nasatech.com

For A Good
Real-Time
Call 800-890-6229

No other real-time product delivers an integrated platform like LabVIEW™ Real-Time.



Don't spend time building every real-time system from scratch. Use National Instruments integrated solution for a flexible, high-quality test platform for designing and prototyping even the most demanding aerospace, avionics, automotive, and biomedical applications. Rapidly create custom systems that integrate a wide variety of measurement and automation devices including:

- High-speed analog I/O
- Motion control
- GPIB
- Counter/timer I/O
- Digital I/O
- Serial/RS-232
- CAN

ni.com/info

Call or visit ni.com/info and enter na6s04
for your free Real-Time Product Guide.



(800) 890-6229

Fax: (512) 683-9300 • info@ni.com




We cannot fully express our deepest sorrow to the victims and their families, our friends and associates, and to our fellow Americans for the infamous outrage to humanity.

May the genocidists who masquerade as terrorists, as well as their supporters, be brought to justice swiftly.


OMEGA • NEWPORT • OMEGADYNE • and ANALAB Families



CO₂ Laser Applications of the Month



Drilling Plastic Nozzles with CO₂ Lasers



250 & 100 micron hole sizes drilled with a Synrad 48-2 CO₂ laser with 20 watts of power.

Lasers excel at drilling small holes (<0.01" in diameter). In fact, in most cases, the smaller the diameter, the better, down to a minimum size of about 50 microns. These holes can be directly drilled in a range of materials without the need for trepanning, resulting in shorter drilling times and highlighting one of the unique characteristics of the laser - one laser and one focused spot diameter can produce a range of hole sizes.

By using a burst or train of pulses, a precise amount of energy is delivered to the material. The final hole diameter will depend on the plastic's inherent heating and wavelength absorption characteristics, as well as the gas pres-

sure used, and size of the focused beam. The number of pulses, duration of the pulse, and pulse frequency also enter into the equation. Small diameter increases can be made by altering the pulse numbers, larger ones by changing pulse duration and/or frequency. Changing the power is optional, and in many cases, the power input can be held at a constant value.


The plastic nozzles in the photo to the left were drilled with a Synrad sealed CO₂ laser. The focused spot size of the laser was around 200 microns, but hole diameters ranged from 75 to over 300 microns. The use of additional pulse power can be used to enlarge the hole by conduction effects.

Laser Welding Stainless Steel Battery Contacts

The fine control of the laser is once again highlighted in this welding application. The 0.01"-thick contact was welded to the main body with two spot welds. The spot welds provide excellent strength, while ensuring that the battery's internal components are not overheated during the process. In addition, the weld only partially penetrates the underlying thickness, so that the battery casing remains sealed.




Contacts welded with Synrad's 200W sealed CO₂ laser.



Close-up of two spot welds.

Laser Marking Quartz

This piece of 0.01"-thick quartz needed to be marked with small alphanumeric characters. Because of the thin size of the test sample, problems with heat build-up and cracking could have potentially affected the results of the application. However, by careful selection of laser parameters - not only speed and power, but resolution, font and character spacing - a highly readable mark was produced.



This quartz was marked with only 5 watts of power at 15" per second. Actual character height is 0.04".

Discover more CO₂ laser applications!
Sign up for our monthly online
Applications Newsletter at
www.synrad.com/signup1

All applications on this page were processed at Synrad's Applications Laboratory. Synrad, the world's leading manufacturer of sealed CO₂ lasers, offers free process evaluations to companies with qualified applications. Call 1-800-SYNRAD1 for more information.



© 2000 Digi-Key Corporation

FEEL THE POWER!

#1 RATED INTERNET SITE*

- #1 VALUE OF OVERALL CONTENT***
- #1 PRODUCT SEARCH ENGINE***
- #1 EASE OF NAVIGATION***
- #1 PRODUCT ORDERING MECHANISM***
- #1 ACCESS SPEED***
- #1 ORGANIZATION OF SITE***

www.
Digi-Key®
.com

*Distributor Evaluation Study, October 2000, Beacon Technology Partners, LLC

In the world of CAD/CAM,

NO LIMITS

VX Overdrive™. Premium-performance CAD/CAM



Design through manufacturing with no stops

VX® blows the doors off of
CAD/CAM with a value-priced,
design-through-manufacturing


system so superior it leaves everything
else in the dust. New VX Overdrive is so
feature-rich, so fun to drive, what used
to be roadblocks at every phase now
become thrilling curves you can
negotiate with ease.

So easy to use

VX Overdrive is loaded with flexibility to help you
fly through even the toughest jobs. Unique surface
creation tools let you blast through challenges at
high speed. And its full integration from design
through manufacturing means engineers can

bring projects to market faster using a single,
seamless system. With VX

Overdrive, if you can imagine
it, you can build it.



we're changing the rules.



that's fun to drive.

***Premium performance
without the premium price***

VX Overdrive comes fully loaded so you'll get the most bang for your buck of any system, plus the ability to import legacy data and the highest level of interoperability on the market (STEP, IGES and direct CAD translators).



Take a test spin

See for yourself how VX Overdrive is changing the rules. Contact us for a demo today.



VX® Shaping the future of CAD/CAM™

VX.COM 321-676-3222

For Free Info Circle No. 546 or Enter No. 546 at www.nasatech.com/rs

©2001, VX Corporation. VX Overdrive and the VX logo are trademarks of VX Corporation.



FEATURES

- 18 Application Briefs
- 25 FDA Approval of Medical Devices Starts with Design
- 50 NASA Chooses Top Software of the Year

SOLUTIONS



30 Special Coverage: Composites & Plastics

- 30 End Caps Increase Thermo-Oxidative Stability of Polyimides
- 32 End Caps for More Thermo-Oxidative Stability in Polyimides
- 34 Low-Density, Ablative Resin-Impregnated Ceramic Insulation
- 36 Solar Heating for Deployment of Foam Structures
- 37 Fluorinated Diamondlike Carbon Coatings



40 Electronic Components and Systems

- 40 Ultra-Efficient K_a-Band MMIC Power Amplifier
- 42 Implementing Permutation Matrices by Use of Quantum Dots



46 Software

- 46 Software for Concurrent Development of Reusable Software
- 46 Adaptive Problem Solving for Refining Control Strategy
- 46 Software for Automated Ortho-Rectification of SAR Images
- 48 Advanced Software for Two-Phase Thermohydraulic Systems
- 49 Test Automation Software for AI Planning Software
- 49 Software for Simulation of 3D, Three-Phase Combusting Flow




51 Mechanics

- 51 Flex Wedges
- 52 Heat-Shield Panels in a 2D Shingling Arrangement




54 Physical Sciences


- 54 Improved Automated System for Transferring Liquid Helium
- 55 Algorithm for Computing Dynamics of Molecules
- 56 Improving Thin Foil X-Ray Mirrors



38



50



62

DEPARTMENTS

- 12 Commercial Technology Team
- 14 UpFront
- 16 Reader Forum
- 20 Who's Who at NASA
- 22 Commercialization Opportunities
- 24 Technologies of the Month
- 38 Special Coverage Products: Composites & Plastics
- 66 Advertisers Index

NEW FOR DESIGN ENGINEERS

- 61 Web Sites
- 62 Products/Software

SPECIAL SUPPLEMENTS



1a - 14a
Photonics Tech Briefs
Follows page 38 in selected editions only.

**Motion
CONTROL**
Tech Briefs

1b - 12b

Motion Control Tech Briefs

Follows page 50 in selected editions only.

Anatomy of ALGOR's NEW Interface for Finite Element Analysis & Mechanical Simulation

1 Built-in intelligence graphically indicates the need for additional data input

2 Docking toolbars for quick access to the most common options

3 Shortcut keyboard and mouse controls for dynamic viewing options

4 Multiple view windows for any model version

5 Right-click application, modification and removal of loads, constraints and finite element properties through context-sensitive menus that adapt to the active selection and analysis type

6 Define load and constraint sets within design scenarios for an efficient analysis workflow

7 Surface-based load and constraint capabilities

8 Tree view of model parts and associated FEA data

9 HTML compiled help with robust indexing and search capabilities

10 Windows-native input screens for all loads, constraints and FEA data

11 Seamlessly works with (sits inside):

- Autodesk Inventor
- CADKEY
- Mechanical Desktop
- Pro/ENGINEER for Windows
- Solid Edge
- SolidWorks

Includes right-click application, modification and removal of loads, constraints and finite element properties for linear and nonlinear stress, thermal, fluid flow and electric field analysis as well as dynamic mechanical simulation.

ALGOR
When Engineering Has to be Right

Learn more about finite element modeling, mechanical simulation and finite element analysis tools within this new interface at

EASYINTERFACE.ALGOR.COM

For Free Info Circle No. 594 or Visit www.nasatech.com/594

US Phone: 1.412.967.2700
Europe (UK): 44.1784.442.246
Fax: 1.412.967.2781
California: 1.714.564.0844
easyinterface.algor.com
E-mail: easyinterface@algor.com
150 Beta Drive, Pittsburgh, PA 15238-2932 USA



57 Information Sciences

- 57 An Improved Genetic Algorithm for Optimal Spacecraft Scheduling
- 57 Timeout Algorithm for Communications With Long Delays




58 Books and Reports

- 58 Solar Sails Would Be Made From Carbon Nets
- 58 Solar Sails Would Be Segmented To Minimize Stresses
- 58 Modular Propulsion Clusters
- 59 Positioning System for a Human Habitat in a Large Centrifuge
- 59 Launch-on-Demand Servicing Microsatellites
- 59 First-Generation Integrated Free-Flying Micro-Spacecraft
- 60 Miniature Electrothermal Thruster
- 60 Using Photosynthetic Bacteria To Make Oxygen on Mars
- 60 DNS of a Transitional Supercritical C_7H_6/N_2 Mixing Layer

This document was prepared under the sponsorship of the National Aeronautics and Space Administration. Neither Associated Business Publications Co., Ltd. nor the United States Government nor any person acting on behalf of the United States Government assumes any liability resulting from the use of the information contained in this document, or warrants that such use will be free from privately owned rights. The U.S. Government does not endorse any commercial product, process, or activity identified in this publication.

PRODUCT OF THE MONTH

Mathcad Client from MathSoft Engineering & Education (Cambridge, MA) lets users share and collaborate on Mathcad-created content across organizations.



14

ON THE COVER




The Model 7090 optical switching card from Keithley Instruments of Cleveland, OH, enables optical, DC, and RF switching, all within one instrument. It lets manufacturers of optoelectronic devices automate their test applications by providing switching of an optical signal between several instruments, a single instrument among multiple devices, or a combination of both. Find more information on Keithley's card — and other new products and software — in New on the Market on page 62.

(Image courtesy of Keithley Instruments)

Permissions: Authorization to photocopy items for internal or personal use, or the internal or personal use of specific clients, is granted by Associated Business Publications, provided that the flat fee of \$3.00 per copy be paid directly to the Copyright Clearance Center (222 Rose Wood Dr., Danvers, MA 01923). For those organizations that have been granted a photocopy license by CCC, a separate system of payment has been arranged. The fee code for users of the Transactional Reporting Service is: ISSN 0145-319X/94 \$3.00+ .00

If it's vibration, pressure or shock, we measure it.



Signal Conditioner for Piezoelectric/ISOTRON® Sensors - Model 133

- Multi-Purpose 3-Channel Signal Conditioner
- Selectable Filter Options
- 100 kHz Bandwidth
- RS-232 Serial Interface
- Excellent Value



Actual Size

10mm-Cube Triaxial Accelerometer - Model 65

- Measures in all 3 axes
- Sensitivity 10 or 100 mV/g
- Lightweight 5 gm
- 10 kHz Frequency Response
- Single Output Cable

Endevco's products are used throughout the world - in aerospace, defense, automotive, test laboratories and jet engine test cells. We have signal conditioning to meet the needs of bench-top, single channel, multi-channel computer controlled and even the newest technology of the IEEE-1451.4 Smart Sensors. So if you've got a challenge, call the dedicated people of Endevco.



WHAT CAN WE DO FOR YOU TODAY?



San Juan Capistrano, CA
www.endevco.com/4c2t
applications@endevco.com
800/982-6732 • 949/661-7231 fax

Tracking and data analysis at sea...

*In the White House for collection,
removal and lock-up of sensitive data...*


www.storcase.com

*On the Space Shuttle for recording
mission experiments...*

Data collection in the field...

FLAWLESS IN ANY ENVIRONMENT

THE MILITARY DEPENDS ON STORCASE DATA EXPRESS®



removable drive enclosures for reliable performance. In addition to being used to collect low gravity acceleration measurements during NASA Space Shuttle missions, Data Express removable drive carriers are used in many military land, air and sea applications. From the simplest removable drive application to the most complex RAID enclosure implementation, StorCase has a solution to meet your unique storage requirements. Call a StorCase representative today at (800) 337-8421 to find out more about the Data Express — one of the toughest removables in any environment.

 **StorCase**
TECHNOLOGY
A Kingston Technology Company

INGRAM
MICRO

D&H

GATES/ARROW
DISTRIBUTING

Tech Data

SYNNEX

BELL MICROPRODUCTS

CONSAN
A GATES/ARROW Company



©2001 StorCase Technology, Inc. A Kingston Technology Company. 17600 Newhope Street, Fountain Valley, CA 92708, USA (714) 438-1850, Fax (714) 438-1847. All trademarks and registered trademarks are the property of their respective owners.

For Free Info Circle No. 523 or Enter No. 523 at www.nasatech.com/rs

COMBINE MULTIPLE COMPUTER & VIDEO SIGNALS ON A SINGLE SCREEN

**The SuperView
Display Processor Offers
Up to 10 Inputs in
Real-time & Full Color**



Now you can display multiple live video and computer inputs on a single monitor or projector. With up to 10 simultaneous inputs, the SuperView™ processor offers a better alternative to videowalls and other arrays of monitors or projectors.

The SuperView is easily installed and compatible with virtually all PCs and workstations. Functions can be controlled from the front panel or remotely via the RS-232 port. Optional software offers controls under Windows 95/98/NT.

Designed for maximum flexibility, the SuperView system is an excellent solution for applications requiring large screen projection, remote video monitoring, command-and-control, simulation, teleconferencing and multimedia display.

**Resolution up
to 1600 x 1200**

**Computer and
video inputs**

**Independent scale,
position & zoom**

RS-232 control

**Computer on
video overlay**

Visit our web site <http://www.rgb.com>

RGB SPECTRUM®
A visual communications company™

950 Marina Village Parkway
Alameda, California 94501
Tel: (510) 814-7000
Fax: (510) 814-7026
E-mail: sales@rgb.com



**For Free Info Circle No. 402 or
Enter No. 402 at www.nasatech.com/rs**

TECH BRIEFS
www.nasatech.com



Published by **Associated Business Publications**
Publisher..... **Joseph T. Pramberger**
Editor/Associate Publisher..... **Linda L. Bell**
Editor, Market Focus Editions..... **Robert Clark**
Associate Editor/Internet Editor..... **Laura Raduta**
Production Manager..... **Margery Koen**
Assistant Production Manager..... **John Iwanciw**
Art Director..... **Lois Erlacher**
Senior Designer..... **Christopher Coleman**
Circulation Manager..... **Hugh J. Dowling**

BRIEFS & SUPPORTING LITERATURE: Written and produced for NASA by
Advanced Testing Technologies, Inc., Hauppauge, NY 11788

Technical/Managing Editor..... **Ted Selinsky**
Sr. Technical Analyst..... **Dr. Larry Grunberger**
Art Manager..... **Eric Starstrom**
Staff Writers/Editors..... **Dr. Theron Cole, George Watson**
Graphics..... **Robert Simons**
Editorial & Production..... **Joan Schmiemann, Becky D. Bentley**

NASA:

NASA Tech Briefs are provided by the National Aeronautics and Space
Administration, Technology Transfer Division, Washington, DC:

Administrator..... **Daniel S. Goldin**
Director, Commercial Technology..... **Dr. Robert Norwood**
Publications Director..... **Carl Ray**

ASSOCIATED BUSINESS PUBLICATIONS INTERNATIONAL
317 Madison Avenue, New York, NY 10017-5391
(212) 490-3999 FAX (212) 986-7864

Chairman/Chief Executive Officer..... **Bill Schnirring (bill@abpi.net)**
Vice Chairman/Chief Operating Officer..... **Domenic A. Muchetti**
MIS Manager..... **Ted Morawski**
Webmaster..... **Albert Sunseri**
Director of Electronic Products..... **Luke Schnirring**
eStrategy Director..... **Andrew Runk**
Credit/Collection..... **Felecia Lahey**
Human Resources Manager..... **Lourdes Del Valle**
Accounting Manager..... **Sylvia Ruiz**
Office Manager..... **Alfredo Vasquez**

NASA TECH BRIEFS ADVERTISING ACCOUNT EXECUTIVES

Headquarters..... (212) 490-3999
CT, MA, NH, ME, VT, RI, Eastern Canada..... **Ed Marecki**
at (401) 351-0274
NJ, NY, PA, DE..... **Jim Oot**
at (973) 316-9695
VA, MD, DC, NC, SC, GA, FL, AL, TN, MS, LA, AR, OK, TX..... **Bill Manning**
at (770) 971-0677
MN, ND, SD, WI, IL..... **Bob Casey**
at (847) 223-5225
IN, KY, MI, OH, MO, KS, IA, NE, Western PA & NY, Central Canada..... **Chris Casey**
at (847) 223-5225
N. Calif., CO, WA, OR, ID, MT, WY, UT, Western Canada..... **Bill Hague**
at (800) 830-4351
S. Calif., AZ, NM, NV..... **Tom Boris**
at (949) 642-2785
Internet Advertising..... **Luke Schnirring**
at (212) 490-3999
Postcard/Literature Advertising..... **John Waddell**
at (212) 490-3999
Reprints..... **Jeannie Martin**
at (219) 879-8366

**For a complete list of staff e-mail addresses,
visit www.abpi.net**

NASA Tech Briefs Goes Digital

Dear Reader:

Now you have a choice of receiving a digital (pdf) version of *NASA Tech Briefs* in addition to or instead of your print copy. The pdf edition will be a full-color replica of the printed magazine, with many added benefits, including the ability to search and archive digital issues, hyperlink directly from articles and ads to Web pages, and view embedded video and audio clips.


Plus, as a digital subscriber, you automatically will receive technology-focused supplements such as *Photonics Tech Briefs* and *Motion Control Tech Briefs*. And the pdf edition will be available earlier than you now receive your copy through the mail.

The average pdf edition is expected to be less than 10MB, making it relatively quick and easy to download. You will be able to view pages side-by-side and print them on demand.

The pdf edition is free to qualified U.S. subscribers who switch from the print version. You can receive BOTH versions for a nominal service fee of \$2.00 per month (\$24.00 annually), which helps cover our additional costs. Of course, you can continue to receive the print edition only at no charge — provided you renew your subscription annually.

Update your subscription today at www.nasatech.com/subscribe and tell us which option you prefer, or complete and fax the subscription form on page 39 of this issue. This new service is slated to begin with the November issue, so please act now.

Thanks for your support.



Joe Pramberger
Publisher
joe@abpi.net

PS: At www.nasatech.com/subscribe, start by entering the unique ID number that appears above your name on the mailing label (printed on the front cover of the magazine). Your current address, phone, fax, and e-mail data will appear onscreen automatically, saving you time and effort.

NASA Commercial Technology Team

NASA's Technology Sources

If you need further information about new technologies presented in *NASA Tech Briefs*, request the Technical Support Package (TSP) indicated at the end of the brief. If a TSP is not available, the Commercial Technology Office at the NASA field center that sponsored the research can provide you with additional information and, if applicable, refer you to the innovator(s). These centers are the source of all NASA-developed technology.

Ames Research Center

Selected technological strengths: Information Technology; Biotechnology; Nanotechnology; Aerospace Operations Systems; Rotorcraft; Thermal Protection Systems.
Carolina Blake
(650) 604-1754
cblake@mail.arc.nasa.gov

Dryden Flight Research Center

Selected technological strengths: Aerodynamics; Aeronautics Flight Testing; Aeropropulsion; Flight Systems; Thermal Testing; Integrated Systems Test and Validation.
Jenny Baer-Riedhart
(661) 276-3689
jenny.baer-riedhart@dfrc.nasa.gov

Goddard Space Flight Center

Selected technological strengths: Earth and Planetary Science Missions; LIDAR; Cryogenic Systems; Tracking; Telemetry; Remote Sensing; Command.
George Alcorn
(301) 286-5810
galcorn@gsfc.nasa.gov

Jet Propulsion Laboratory

Selected technological strengths: Near/Deep-Space Mission Engineering; Microspacecraft; Space Communications; Information Systems; Remote Sensing; Robotics.
Merle McKenzie
(818) 354-2577
merle.mckenzie@jpl.nasa.gov

Johnson Space Center

Selected technological strengths: Artificial Intelligence and Human Computer Interface; Life Sciences; Human Space Flight Operations; Avionics; Sensors; Communications.
Charlene E. Gilbert
(281) 483-0474
charlene.e.gilbert1@jsc.nasa.gov

Kennedy Space Center

Selected technological strengths: Fluids and Fluid Systems; Materials Evaluation; Process Engineering; Command, Control and Monitor Systems; Range Systems; Environmental Engineering and Management.
Jim Aliberti
(321) 867-6224
Jim.Aliberti-1@ksc.nasa.gov

Langley Research Center

Selected technological strengths: Aerodynamics; Flight Systems; Materials; Structures; Sensors; Measurements; Information Sciences.
Sam Morello
(757) 864-6005
s.a.morello@larc.nasa.gov

John H. Glenn Research Center at Lewis Field

Selected technological strengths: Aeropropulsion; Communications; Energy Technology; High Temperature Materials Research.
Larry Viterna
(216) 433-3484
cto@grc.nasa.gov

Marshall Space Flight Center

Selected technological strengths: Materials; Manufacturing; Nondestructive Evaluation; Biotechnology; Space Propulsion; Controls and Dynamics; Structures; Microgravity Processing.
Vernotto McMillan
(256) 544-2615
vernotto.mcmillan@msfc.nasa.gov

Stennis Space Center

Selected technological strengths: Propulsion Systems; Test/Monitoring; Remote Sensing; Nonintrusive Instrumentation.
Kirk Sharp
(228) 688-1929
kirk.sharp@ssc.nasa.gov

NASA-Sponsored Commercial Technology Organizations

These organizations were established to provide rapid access to NASA and other federal R&D and foster collaboration between public and private sector organizations. They also can direct you to the appropriate point of contact within the Federal Laboratory Consortium. To reach the Regional Technology Transfer Center nearest you, call (800) 472-6785.

**Joseph Allen
National Technology
Transfer Center**
(800) 678-6882

**Ken Dozier
Far-West Technology
Transfer Center**
University of Southern
California
(213) 743-2353

**Dr. William Gasko
Center for Technology
Commercialization**
Massachusetts
Technology Park
(508) 870-0042

**B. David Bridges
Southeast Technology
Transfer Center**
Georgia Institute of
Technology
(404) 894-6786

**Gary Sera
Mid-Continent Technology
Transfer Center**
Texas A&M University
(409) 845-8762

**Charles Blankenship
Technology
Commercialization Center**
Newport News, VA
(757) 269-0025

**Pierrette Woodford
Great Lakes Industrial
Technology Transfer
Center**
Battelle Memorial
Institute
(216) 898-6400

NASA Program Offices

At NASA Headquarters there are seven major program offices that develop and oversee technology projects of potential interest to industry. The street address for these strategic business units is: NASA Headquarters, 300 E St. SW, Washington, DC 20546.

**Carl Ray
Small Business Innovation
Research Program (SBIR)
& Small Business
Technology Transfer
Program (STTR)**
(202) 358-4652
cray@mail.hq.nasa.gov

**Dr. Robert Norwood
Office of Commercial
Technology (Code RW)**
(202) 358-2320
rnorwood@mail.hq.nasa.gov

**John Mankins
Office of Space Flight
(Code MP)**
(202) 358-4659
jmankins@mail.hq.nasa.gov

NASA's Business Facilitators

NASA has established several organizations whose objectives are to establish joint sponsored research agreements and incubate small start-up companies with significant business promise.

**Wayne P. Zeman
Lewis Incubator for
Technology**
Cleveland, OH
(216) 586-3888

**B. Greg Hinkebein
Mississippi Enterprise for
Technology**
Stennis Space
Center, MS
(800) 746-4699

**Julie Holland
NASA Commercialization
Center**
Pomona, CA
(909) 869-4477

**Bridgette Smalley
UH-NASA Technology
Commercialization
Incubator**
Houston, TX
(713) 743-9155

**John Fini
Goddard Space Flight
Center Incubator**
Baltimore, MD
(410) 327-9150 x1034

**Terry Hertz
Office of Aero-Space
Technology (Code RS)**
(202) 358-4636
thertz@mail.hq.nasa.gov

**Glen Mucklow
Office of Space Sciences
(Code SM)**
(202) 358-2235
gmucklow@mail.hq.nasa.gov

**Roger Crouch
Office of Microgravity
Science Applications
(Code U)**
(202) 358-0689
rcrouch@hq.nasa.gov

**Granville Paules
Office of Mission to Planet
Earth (Code Y)**
(202) 358-0706
gpaules@mtpe.hq.nasa.gov

**Thomas G. Rainey
NASA KSC Business
Incubation Center**
Titusville, FL
(407) 383-5200

**Joanne W. Randolph
BizTech**
Huntsville, AL
(256) 704-6000

**Joe Becker
Ames Technology
Commercialization Center**
San Jose, CA
(408) 557-6700

**Marty Kaszubowski
Hampton Roads
Technology Incubator
(Langley Research Center)**
Hampton, VA
(757) 865-2140


NASA ON-LINE: Go to NASA's Commercial Technology Network (CTN) on the World Wide Web at <http://nctn.hq.nasa.gov> to search NASA technology resources, find commercialization opportunities, and learn about NASA's national network of programs, organizations, and services dedicated to technology transfer and commercialization.

If you are interested in information, applications, and services relating to satellite and aerial data for Earth resources, contact: Dr. Stan Morain, **Earth Analysis Center**, (505) 277-3622.

New image processing tools.

Treat your image data to MATLAB.

Now there is a complete set of advanced image processing tools for MATLAB, the world's number one technical computing environment. You can analyze, enhance, and segment images. Perform registration, morphology, deblurring, and multidimensional operations. Develop image processing algorithms, and convert your image applications to C/C++ with the MATLAB Compiler.



Multiple, touching objects segmented using the watershed transform.

And because it's MATLAB, it's flexible and programmable, and it's easy to explore.

See how much better image processing can be with the MATLAB solution.

Go directly to application examples, demos, tutorials, user stories, and pricing at www.mathworks.com/nti.

MATLAB®
& **SIMULINK®**

Signal Processing Toolbox

Statistics Toolbox

Neural Network Toolbox

Mapping Toolbox

Wavelet Toolbox

Filter Design Toolbox


MATLAB Compiler

MATLAB
training
offered in
15 locations.

MATLAB image and signal processing products are used in aerospace, electronics, medical, and mapping applications.

The MathWorks

Visit www.mathworks.com/nti
or call 508-647-7040




© 2001 The MathWorks, Inc.

PRODUCT OF THE MONTH

MathSoft Engineering & Education, Cambridge, MA, has released Mathcad® Client for sharing and collaborating on Mathcad-created content across and throughout organizations. It provides a tool for sharing math on the Internet, as well as via corporate extranets and intranets. Designed for organizations with multiple locations, Mathcad Client lets users interact with technical documents and applications, including Mathcad worksheets, electronic books, and MathML documents. The software restricts changes to the structure of original documents. It can be used as a standalone, interactive viewer for Mathcad documents in which engineers can share Mathcad-created designs with anyone who has Mathcad Client. The program supports Mathcad add-ins for Excel, Visio, and AutoCAD, as well as applications developed in Visual Basic and C++. Mathcad Client also can be used as a browser plug-in for Internet Explorer or Netscape to view Web-based live math content.

For Free Info Circle No. 740 or Enter No. 740 at www.nasatech.com/rs



What's New On-line

You spoke, we listened. NASA Tech Briefs readers have asked for an automated way to renew or change their subscriptions. Now, when you go to www.nasatech.com/ subscribe and access the online subscription form, simply enter the unique ID number that appears above your name on the mailing label (printed on the front cover of the magazine), and your current address, phone, fax, and e-mail data will appear onscreen, saving you time and effort. You still need to complete the demographic questions, but these only require a few clicks of your mouse. E-mail comments about this new service to Hugh Dowling at hugh@abptuf.org.

Which Way Is Up?

On Earth, gravity tells us which way is up, and which way is down. But what about in space, where there is no gravity? The body's vestibular system, which includes the inner ear, can't sense the familiar pull of gravity in space, and can't distinguish up from down. In addition, nerves in the body's joints and muscles that tell us where our arms


and legs are without looking at them also are fooled in zero gravity. The result of all this disorientation: space sickness. Do you know that feeling you get while reading in a moving car, or riding a roller coaster? That's similar to what space sickness feels like.

In 1997, NASA formed the National Space Biomedical Research Institute (NSBRI) in Houston, TX, to research countermeasures to health problems associated with long-duration space travel. Much of that research can directly benefit millions of patients here on Earth. Using 12 integrated research teams composed of scientists from leading research institutions and national labs, the NSBRI's work covers areas such as bone and muscle loss, cardiovascular changes, immunology, infection, behavioral factors, physical fitness and rehabilitation, nutrition, and radiation effects.


NSBRI research is designed to help physicians treat patients with inner ear disorders, osteoporosis, cardiac problems, sleep disorders, immune system disorders, stress-related viral outbreaks such as shingles, and a variety of stress, personality, and psychological disorders.

Visit the NSBRI Web site at www.nsbri.org, or contact Kathy Major, Manager of Program Coordination, Communication, and Outreach, at major@bcm.tmc.edu; 713-798-5893.





Go from 2D to 3D design without a detour through hell.



IMAGERY PROVIDED BY ALPHA MARATHON

Don't get burned. Get **Autodesk Inventor™** software. It's the industry's biggest leap in 3D design technology in over 15 years, with breakthrough adaptive technology, exceptional large assembly performance, and industry-leading DWG compatibility. For Alfredo Bentivoglio, President of Alpha Marathon, "The transition from 2D to Autodesk Inventor was a breeze." And its intuitive nature will save you more than just time: "We'll save up to one million dollars by drastically reducing prototyping," he says. If you're ready for 3D the easy way, you're ready for Autodesk Inventor. Freedom to design without limits. Visit www.autodesk.com/inventor to find out more.

autodesk®

© 2001 Autodesk, Inc. Autodesk and the Autodesk logo are registered trademarks, and Autodesk Inventor is a trademark, of Autodesk, Inc. in the U.S.A. and other countries.

For Free Info Circle No. 542 or Enter No. 542 at www.nasatech.com/rs

Reader Forum

Reader Forum is dedicated to the thoughts, concerns, questions, and comments of our readers. If you have a comment, a question regarding a technical problem, or an answer to a previously published question, post your letter to Reader Forum on-line at www.nasatech.com, or send to: Editor, *NASA Tech Briefs*, 317 Madison Ave., New York, NY 10017; Fax: 212-986-7864. Please include your name, company (if applicable), address, and e-mail address or phone number.

I have a patient care application that involves measuring the effect of air pressure on the wall of the trachea. The pressure is induced via a pulsating mechanical ventilator using a catheter that is inserted into the trachea. The catheter diameter is 4 mm and the trachea diameter is 6 mm. I would like to be able to measure the actual pressure of the air puffs against the trachea wall, and be able to show its distribution. Typical pressure in the catheter tip is less than 2 psi. Tactile pressure indicating film would be perfect for this application since it can be formed into a cylinder that replicates the trachea, but it is not very practical at low pressures. Any suggestions would be appreciated.

Frank Magnarelli
fdm39@aol.com

The July Reader Forum included a letter from John Marchesini requesting information on scaring birds away from airplane landing strips. I would suggest John contact Dr. Richard Dolbeer of the US Department of Agriculture, and the Chairman of Bird Strike Committee USA. The use of acoustics such as bird distress calls and propane cannons near airfields has a long and frustrating history. Noise often has been used to chase a roost. I myself have done work with the US Air force, the USDA, and the Federal Aviation Administration (FAA). The bottom line seems to be that the sound must hurt the birds or they will habituate. Our testing uses the sound to make the birds more aware of the approaching vehicle, and, thus, evokes an improved avoidance reaction.

James J. Genova
libbajim@mindspring.com

In response to John Marchesini's letter in the July issue on scaring birds with sound, my limited experience has shown that the sounds that move birds depend on the species and the history of the birds. A distress call of an injured bird will chase other birds for a short time, but if they don't detect further danger, they'll return. There have been rodent/bird/insect chasers on the market for at least 15 years that consist of nothing more than 555 timers and a horn tweeter. The only results I've detected that they produce are to cause radio and TV interference. The electronics needed are trivial, but the ornithology Mr. Marchesini requests is complex and can take years to learn — and may still be ineffective.

Dr. Gerald N. Johnson
geraldj@isunet.net



>MISSION CONTROL, WE HAVE A VISUAL

IDL : THE LANGUAGE OF DATA VISUALIZATION

Work with our experts to develop that 'killer app' that gives you the competitive edge or use IDL to build your own custom applications in less time than with any traditional programming language.

- Create interactive Web-enabled applications using JAVA and IDL.
- Take your productivity to a new level with IDL's built-in multi-threading capabilities.
- Use the power of IDL to manipulate 1D, 2D, 3D or even 4D visualizations interactively.
- Develop a user interface in IDL, or use IDL as an ActiveX control.
- Call C, C++, FORTRAN code, or call IDL from your existing application.


Available for Window, UNIX, Linux, and Macintosh.

IDL

Call us today at 303.786.9900 or visit our website at www.ResearchSystems.com/Aerospace to find out more.

RESEARCH SYSTEMS
A Kodak Company

What do you need to record ? Waveforms – Video – Audio... **Dash 18[®]** handles it all!




- Record waveform data, synchronized video snapshots and audio
- 18 Universal input channels for voltage, thermocouple and bridge
- 15.4" touch-screen display for data viewing and analysis
- Record data directly to 9 GB hard drive at 100 kHz per channel
- Real-time filtering and math functions
- 10/100 BaseT Ethernet interface and 250 MB Zip drive



Optional Printer

For real-time recording or playback from memory, an attachable 10" wide high speed printer is available.



Call, E-mail, Fax, or write to us today for all the details. Web Site: www.astro-med.com/de10



Astro-Med, Inc.

TEST & MEASUREMENT PRODUCT GROUP

Astro-Med is System Certified to ISO-9001

Astro-Med Industrial Park, West Warwick, Rhode Island 02893

Phone: (401) 828-4000 • Toll Free: 1-877-867-9783 • Fax: (401) 822-2430

In Canada Telephone 1-800-565-2216 • E-mail: mtgroup@astromed.com

Application Briefs

NASA Facility Refitted With Modular Storage System

Mobile storage cabinets and workstations
Lista International
Holliston, MA
508-429-1350
www.listaintl.com

NASA's Johnson Space Center (JSC) in Houston, TX, houses the facility where the International Space Station's crew return vehicle — the X-38 — is being developed and built. According to NASA manufacturing engineer David Young, "The development of a spacecraft is obviously extremely important. The tools used to build the vehicle are very important as well. That is why NASA chose Lista to provide a secure storage system for the tools."

The modular storage components selected by NASA include a network of modular drawer storage cabinets, which feature drawers that can be designed with a variety of heights and interior configurations to fit NASA's wide range of installations and applications. At the JSC facility, a wide range of small parts such as nuts, bolts, screws, and fasteners — as well as large tools such as wrenches — are stored in one cabinet.

JSC also utilizes two mobile cabinets, a double-width cabinet, and a mobile unit with a maple top for easy access to stored items. The final element of the JSC workspace solution is an industrial workbench completely customized to fit the exact needs of the X-38 technicians. It features an outlet strip to plug in power tools, and permanent riser shelving for added storage. "The workstation allows organization and efficiency," said Young. "The technicians have an organized area for light technical work, as well as paperwork and computer use." Other Lista storage systems already are in use at NASA's Kennedy Space Center in Florida.

For Free Info Circle No. 730 or
Enter No. 730 at www.nasatech.com/rs



Nickel-Hydrogen Batteries Power Mars Mission

CPV and IPV nickel-hydrogen batteries
Eagle-Picher Technologies
Power Subsystems Group
Joplin, MO
417-623-8000
www.epi-tech.com

NASA's 2001 Mars Odyssey spacecraft, launched this spring, is expected to arrive at Mars later this month to join the Mars Global Surveyor, which already is in orbit. A probe will search for and analyze various elements of the Martian environment such as water, ice, mineral deposits, and radiation. The spacecraft — built by Lockheed Martin Space Systems for NASA's Jet

Propulsion Laboratory in California — was powered by a nickel-hydrogen battery that combined two types of cells.

The 16-ampere-hour battery design combined 11 two-cell Common Pressure Vessel (CPV) cells and one Independent Pressure Vessel (IPV) cell to achieve the 23-cell equivalent battery. The battery's function is reserve power for spacecraft operation, used approximately one-third of the time, when solar arrays become eclipsed. According to Ron Repplinger, director of the Power Subsystems Group at Eagle-Picher, his company "has been a continuous source of battery power throughout four decades of space flight missions."


The nickel-hydrogen cell and battery technology also will be used as terrestrial backup power for applications in high-reliability environments such as semiconductors, medical, defense, and telecommunications.

For Free Info Circle No. 731 or Enter No. 731
at www.nasatech.com/rs

Six-axis Force/Torque Sensors

Strong Transducers With Low-Noise Outputs Measuring F_x , F_y , F_z , T_x , T_y , T_z .

**NEW PCI, cPCI
& PCMCIA Interfaces**



Shown are ATI six-axis transducers from 17mm dia. to 330 mm dia.

ATI manufactures a variety of extremely robust six-axis Force/Torque (F/T) sensors that provide low-noise, high-resolution signals with output speeds of up to 10kHz and factors of safety up to 27 times measurement range. Since 1983, ATI has provided thousands of customers with F/T's ranging from the smallest six-axis sensor in the world (17 mm diameter) to sensors measuring thousands of pounds. The F/T can provide data via voltage outputs, RS-232 serial or interface with either ISA, PCI, PCMCIA or cPCI buses. ATI is developing interfaces to Firewire, VXI, USB, DeviceNet and Ethernet. The F/T can also interface with analog data acquisition systems (seven channels required).

For more information, contact Milton Gore at mgore@ati-ia.com or extension 132.

"I highly recommend ATI's force/torque transducers to anyone who needs a reliable, pre-calibrated, easily programmable transducer. It is a truly versatile plug-and-play system."

Prof. Francisco Valero-Cuevas
Neuromuscular Biomechanics Laboratory
Sibley School of Mechanical and Aerospace Engineering
Cornell University

"Because of their off-the-shelf solutions for miniature force and torque sensing, we were able to go from concept to working prototype in months instead of years."

Patrick Jensen, Ph.D., Assistant Professor of Ophthalmology
Johns Hopkins University

"The force/torque systems from ATI are ideal in our study of human grip force coordination and production. They are as close to a turn-key system that we have found."

Professor Jay L. Alberts, Ph.D.
Dept. of Health and Performance Sciences
Georgia Institute of Technology

Our Products Also Include:

- Quick-Change** Robotic Tool Changer
- Protector** Robotic Crash Protection Device
- Speedeburr** Robotic Deburring Tool
- Compensator** Automated Assembly Alignment Device

**ATI INDUSTRIAL
AUTOMATION**
ISO 9001 Registered

Engineered Products for Manufacturing Productivity

Pinnacle Park, 1031 Goodworth Drive, Apex, North Carolina 27502 USA
Tel: +1.919.772.0115 • Fax: +1.919.772.8259
Email: info@ati-ia.com • www.ati-ia.com

Dr. Marla Perez-Davis, Chief of the Electrochemistry Branch, Glenn Research Center

Dr. Perez-Davis is a chemical engineer and head of the Electrochemistry Branch at NASA's Glenn Research Center in Cleveland, OH. Her branch develops electrochemical technologies that result in high energy density and long-life batteries and fuel cells for NASA missions. In July, Dr. Perez-Davis was presented with the Career Achievement in Government Award at the Women of Color Government and Defense Technology Awards Conference, which honored 23 women for their achievements in science, engineering, and technology.



nickel electrode. We are looking at different cell chemistries, advanced materials, and novel cell, stack, component, and system designs, and how to make them more compact with longer life. Right now we're researching lithium-based battery systems because that offers the potential for lighter weight, less complexity, and higher performance.

Current research includes the technical feasibility of utilizing carbon nanotubes and nanotechnologies in future energy storage systems and designs.

NTB: What are the commercial applications for long-life batteries and fuel cells?

Perez-Davis: One of the big commercial areas is portable, wireless electronics like cell phones and laptop computers that need longer battery life. You get on a plane and want to have your laptop run for a while without having to charge your battery. There is a need for technology breakthroughs and new batteries that can provide that kind of performance. There also must be flexibility in terms of the size and weight of the batteries for those devices. Nanotechnology becomes important in storage capabilities.

NTB: How might these technologies affect our everyday lives?

Perez-Davis: The 21st century is a very exciting time, with new technical challenges and opportunities. One of those opportunities is to couple our traditional trends with emerging technologies such as nanotechnology. When you look at fuel cells, you want to look at different types of fuels, their efficiencies, and how to use devices where the impact to the environment is reduced. That could also mean a reduction in the amount of fuel you need to power a device. That's a double impact.

A full transcript of this interview appears on-line at www.nasatech.com/whoswho. Dr. Perez-Davis can be reached at marla.perez-davis@grc.nasa.gov.

NASA Tech Briefs: What is the function of the Electrochemistry Branch?

Dr. Marla Perez-Davis: Over the past three decades, the main function of the Electrochemistry Branch has been the development of advanced battery and fuel cell systems for NASA missions and programs. We go back to the 1970s, when we started working with the original space systems, and we worked on battery systems for electric vehicles, alkaline fuel cell technology for the shuttle, and fuel cells for large-scale power plant applications. In the 1980s and 1990s, we became involved in the development of nickel-hydrogen batteries for low-Earth orbit and geosynchronous orbit for satellites and spacecraft.

NTB: How do the technologies you're working on affect battery and fuel cell efficiency?

Perez-Davis: In the 1980s, the battery team at NASA Glenn became involved in the development of nickel-hydrogen technology for aerospace applications. We've made improvements in specific energy and energy density of the nickel-hydrogen system with the development of a lightweight

16 Bit 10 MS/s Scope with 1 Billion Points Acquisition Memory



CompuScope 1610

- 16 Bit Resolution at 10 MS/s A/D and Scope Card for PCI Bus
- Up to 1 Gigasample On-board Acquisition Memory
- Differential Inputs
- Wide Analog Bandwidth
- Programmable Input Gain
- Software Development Kits for C/C++, MATLAB, LabVIEW under Win 95/98/NT/2000

Compatible with GageScope®




World's Most Powerful
Oscilloscope Software

GaGe

A Tektronix Technology Company

1-800-567-GAGE ext:3405
www.gage-applied.com/ad/nasa901.htm

Outside the U.S. contact: Gage Applied, Inc.
Tel: +1-514-633-7447 Fax: +1-514-633-0770
e-mail: prodinfo@gage-applied.com



the evolution in servo braking has begun

Nexen's Eclipse™ servo motor brake started a revolution in motion control. With high braking strength and a flexible, universal design, Eclipse proved it was the strongest, safest, and most efficient brake available. To meet customer requests, Eclipse has evolved. New models expand the product line to eight size groups, fitting more than 250 servo motors from 15 manufacturers. Designed to fit all axes—vertical and horizontal, equipped to override virtually any motor, Eclipse is the natural selection for all servo motor applications. **For complete information, stop at www.nexengroup.com/eclipse.**



nexen™

Nexen Group, Inc.
560 Oak Grove Parkway
Vadnais Heights, MN 55127
651 484 5900
Toll Free 800 843 7445



Commercialization Opportunities

End Caps Increase Thermo-Oxidative Stability of Polyimides

New formulations are candidates to supplant the norbornene end cap compound so that the product polymers can withstand higher temperatures and have extended lifetimes.
(See page 30.)

Fluorinated Diamondlike Carbon Coatings

Experiments with this coating material show that it has a low coefficient of friction, is almost as hard as diamond, and that it can withstand flexure and shock without cracking.
(See page 37.)

Ultra-Efficient K_a-Band MMIC Power Amplifier

The proposed amplifier is designed to operate at frequencies around 28 GHz. Computer simulation shows that this amplifier would operate at a power-added efficiency of more than 60 percent, which is more than 20 percent above the state-of-the-art amplifiers in this frequency range.
(See page 40.)

Implementing Permutation Matrices by Use of Quantum Dots

Integrated circuits based on quantum dots would rely on permutation matrices. These circuits are viewed as the next generation that will enable miniaturization beyond that of VLSI circuitry.
(See page 42.)

Flex Wedges

Flex wedges are proposed to improve the performance of brakes and clutches. The wedges are relatively lightweight, require less actuating force, and operate more smoothly than prior systems.
(See page 51.)

Heat-Shield Panels in a 2D Shingling Arrangement

Lightweight metal heat-shield panels designed for simplicity of insertion or removal are proposed for use on spacecraft. The design can be adapted to non-aerospace applications.
(See page 52.)

Improved Automated System for Transferring Liquid Helium

The proposed system for transferring liquid helium from a supply tank to an end-use cryostat would reduce the consumption of liquid helium. Applications include long-duration scientific experiments and large cooled electromagnets in medical imaging systems.
(See page 54.)

Improving Thin Foil X-Ray Mirrors

The proposed improvements for these conical mirrors intended for x-ray astrophysics are increased resolution and diameter. Angular resolution would be 15 arc seconds and mirror diameter would be as large as 1.6 m.
(See page 56.)

For the BEST Stereo Viewing...

Look No Further.

MONITOR **ZSCREEN®**

CrystalEYES®3

When you need to visualize large, complex data sets naturally and interactively, you need the best visualization tools. Used by industry leaders, StereoGraphics CrystalEyes3 and Monitor ZScreen are the professional's choice. Whether you are looking for active shutter eyewear or a passive polarizing system, StereoGraphics Corporation has the best solution for your stereo viewing needs.




STEREOGRAPHICS®

For More Information:
Call Toll Free: 866-455-1490
Visit: www.stereographics.com/ntb/
Email: Stereo3D@stereographics.com

GIS/Mapping • Molecular Modelling • CAD • Industrial VR • Medical Imaging • Simulation


NTB1001



"It's not always
what you know.
It's knowing
where to look."

**yet2.com. The world's leading
Internet-based technology marketplace.**

yet2.com is an interactive tech marketplace that enables you to think outside the box. Expand your technology horizons. We offer a fast, convenient, easy-to-navigate way to look at hundreds of licensable technologies from leading international organizations and individual inventors alike. Every week we feature a *Tech of the Week* so viewers can learn about the coolest new technologies available for licensing. Tell us what you're looking for and we'll e-mail you when relevant abstracts get listed. Or list your own technology for the world to see.



yet2.com is a rich, dynamic arena where diverse industries meet and ideas cross-pollinate. It's the one place where inventors and users come together. Where the possibilities are endless and you can actually see the future.

yet2.com

You can also view yet2.com's *Tech of the Week* by logging onto nasatech.com/techsearch

Technologies of the Month


Sponsored by **yet2.com**

For more information on these and other new, licensable inventions, visit
www.nasatech.com/techsearch

Temperature-Driven Pumping Technology for Supercritical Fluids

Janusz B. Pawliszyn, University of Waterloo

Supercritical fluids typically have been delivered using syringe, membrane, and dual-piston pumps. Unfortunately, these methods have had drawbacks including high cost and leakage under high pressure.



The University of Waterloo has developed a supercritical pumping technology that uses temperature to create pressure within

two high-pressure vessels constructed of stainless steel. Temperature is controlled by an electronic circuit that switches power to a heating element, off and on, in response to preset pressure values. When a certain pounds-per-square-inch (PSI) is achieved, the vessel is discharged, the power is switched off, and the vessel is allowed to cool to another preset PSI level for filling. This results in a continuous flow of supercritical fluid. The technology is ideal for pharmaceutical manufacturing, wastewater treatment, laboratory processes, and food and beverage manufacturing.

Get the complete report on this technology at:

www.nasatech.com/techsearch/tow/waterloo.html

Powerful New Program Unearths Value in Disparate Data

Ted Izen, Rockwell Scientific

Data mining technology has posed several challenges including the requirement of IT staff assistance, expensive data warehouse tools to handle legacy databases, and analysis that can often delay results.

Rockwell Scientific has developed a user-friendly computer program that uses sophisticated search and optimizing algorithms to extract useful information from confusing, often seemingly unrelated data. The technology combines digital signal processing, pattern classification, knowledge extraction, reasoning under uncertainty, optimization, decision analysis, and data visualization. Its functionality enables a variety of data resources to be mined and exploited, even images such as photographs and x-rays. The results are available in real time and presented in simple language for immediate use. This technology is ideal for pattern recognition and signal processing in scientific research, risk management, and market studies for business, and portfolio management and market trends for the financial and insurance industries.

Get the complete report on this technology at:


www.nasatech.com/techsearch/tow/rockwell.html

Gear Combines Principles for Motion Control in Mechatronics Drives

Deutsches Zentrum für Luft- und Raumfahrt

The ability to obtain a range of precision motion with few components in a compact volume is one of many challenges in robotics and other mechatronic applications. The German Aerospace Research Center (DLR) has developed electro-mechanical actuators designed around patented planetary roller screw drives (PRSD).

Originally designed to act as an artificial muscle in the DLR Robotic Hand, the PRSD combines the planetary gear and roller bearing to create a new type of linear translator, transforming rotary motion into powerful, low-speed linear movement. When PRSDs are blended with brushless DC motors, the result is a compact, simple alternative to hydraulic and pneumatic actuators for automotive systems, lifting heavy gear, and small-range motion tasks.



Get the complete report on this technology at:

www.nasatech.com/techsearch/tow/dlr.html

Inverter Railway Propulsion System Offers Improved Performance and Reliability

Hyundai Heavy Industries

Diesel electric propulsion systems have been utilized by the railway industry to operate locomotives, but one weak spot in this system has been the consistency and controllability of the power conversion process as the diesel engine is used to generate electricity via an alternating power generator.

Hyundai Heavy Industries has developed a new digital variable voltage, variable frequency (VVVF) inverter system to help control the speed of the train by means of a parallel traction



motor. The VVVF inverter system converts the 1500 V DC line voltage into a three-phase power supply to drive or brake the traction motor, which converts electricity into mechanical power that is transferred to the wheels via the coupling and gear-

box. This reduces the "jerk" often felt in train travel, providing a smoother, more comfortable ride.

Get the complete report on this technology at:

www.nasatech.com/techsearch/tow/hyundai.html

FDA Approval of Medical Devices Starts with Design

Designing and manufacturing a medical device incorporates many of the same methods and processes as designing and building a car, except for one big difference: the U.S. Food and Drug Administration (FDA). Something as simple as a basic wooden tongue depressor or as complex as a programmable pacemaker with microchip technology are both considered medical devices by the FDA, the government arm that regulates the design, manufacture, packaging, and safety of medical devices. Lab equipment, test kits, and radiation-emitting products such as ultrasound, x-ray, and laser machinery also fall under the FDA's regulated medical devices.

The medical device industry encompasses a wide variety of products and technologies, from hand tools and implantable screws, to computer-controlled surgical machines and artificial organs. According to Forrester Research, the U.S. is the world's largest medical device market, valued at \$43 billion. The industry is expected to grow at a rate of 9 percent per year through 2004. The development of more innovative medical devices in areas such as orthopedic implants, cardiovascular treatment, and surgical equipment continues to increase.

To account for the diverse design, manufacturing, and control procedures used to make such devices, the FDA has compiled Current Good Manufacturing Practice (CGMP) requirements that help manufacturers comply with FDA regulations. These CGMP regulations ultimately protect patients and users of medical devices from purchasing ineffective or dangerous products.

So how far into the design and production of a medical device should a manufacturer go before worrying about FDA compliance? According to the FDA, they must think about compliance at the very beginning, before the product is even designed. The FDA's Center for Devices and

Radiological Health (CDRH) — responsible for the regulation of medical devices and ionizing and non-ionizing radiation-emitting electronic products — has issued CGMP requirements for design controls that guide manufacturers from the very first drawing they make of a new device.


Design controls are a set of procedures incorporated into the design and development process that cover the life of the medical device, from design to production, distribution, maintenance, and obsolescence of the device. The design controls apply to all changes to the device or the manufacturing process, including those that occur long after a device has been introduced to the market. They include everything from the initial design input and review, to verification and validation of the design, to design changes and a history file of those changes. Once the device is designed, the FDA has further regulations covering clinical evaluation, manufacturing, packaging, labeling, and post-market surveillance of the device.

Sound mind-boggling? The FDA, and some commercially available software packages, can help medical device manufacturers get started.

Reducing the Risk

While the FDA is the best place to go for exact information on compliance with their regulations, there are a number of commercially available software packages that can help medical device manufacturers streamline their processes, reporting, and quality procedures to ensure compliance with CGMP standards.


NetRegulus is a provider of product quality intelligence software and services for FDA-regulated medical product manufacturers. Based in Oakbrook Terrace, IL, NetRegulus offers their PQIntelligence™ software, an enterprise-wide,



The US Food & Drug Administration (FDA) Web site at www.fda.gov provides medical device manufacturers with compliance information they can use from the very first drawing of a product, to whether their product is regulated by the FDA, through the design and manufacturing processes and final approval.

Web-enabled data management package that lets users track products and product-related information from initial bench testing all the way through to product phase-out. It automates, organizes, and manages clinical, regulatory, and product data. It also provides tools to track marketing trends, file on-time regulatory reports, handle postmarket surveillance, manage clinical and scientific studies, and manage quality audits, field actions, and recalls.

Pilgrim Software (Tampa, FL) offers the Quality & Manufacturing Integrated System (Q&MIS®) suite of software that helps manufacturers analyze their man-



CATIA: driving innovation, this advanced 3D design links design and manufacturing, improves collaboration. Along with IBM's industry expertise, it's part of a com

IBM

@business

CATIA AND INNOVATION

CATIA®, the world's leading CAD/CAM/CAE software, takes 3D design and innovation to a new level. It streamlines the entire development process from idea to design and through the entire product life cycle by providing a virtual environment for testing, prototyping and manufacturing. It drives the development of innovative, high-quality products, while drastically reducing time for development, cutting costs and providing a faster return on investment.

Better still, it opens up a new range of market opportunities by offering not only the ability to customize on a massive scale, but also personalization for every customer. In short, it gives you the power to create innovative products in a market where innovators lead. And ultimately win.

PLM AND COLLABORATION

IBM's Product Lifecycle Management (PLM) solutions provide an integrated approach to the development of products that fosters innovation. How? By linking your product team's knowledge and processes with the network of suppliers, engineers, customers and partners on which your success ultimately depends. CATIA is an integral part of IBM's PLM solutions.

SEE FOR YOURSELF

The trial code CD version of the latest, award-winning CATIA software is yours to try, free, for 30 days. Simply call 1 800 IBM 7777 (Priority Code 6N1FS029) or visit our Website: ibm.com/solutions/catia



COLLABORATION

we know

they know

INNOVATION


CATIA: driving innovation, this advanced 3D design and engineering software from Dassault Systemes links design and manufacturing, improves collaboration, reduces costs and gets products to market faster. Along with IBM's industry expertise, it's part of a complete PLM solution. See it at ibm.com/solutions/catia



IBM and the e-business logo are trademarks or registered trademarks of International Business Machines Corporation in the U.S. and other countries or both. CATIA is a registered trademark of Dassault Systemes S.A. ©2001 IBM Corporation. All rights reserved.

ufacturing process, recognize trends and measure quality, and meet FDA guidelines. Also an enterprise-wide application, the Web-based product allows users to integrate audits, calibration management, document control issues, supplier quality management, preventive maintenance operations, internal process controls, and training processes into one approach. These different functions also can work as standalone applications.

Other companies, such as EduNeering, provide online compliance education and risk management solutions for FDA compliance. In 1999, EduNeering entered into a Cooperative Research & Development Agreement (CRADA) with the FDA to jointly develop online training programs and courses, which will ensure that everyone in industry and government has access to the same tools and core knowledge, enhancing compliance efforts by regulated manufacturers.



Able Software's 3D DOCTOR enables 3D visualization and rendering of CT and MRI images to create CAD models that can be used for rapid prototyping of medical devices. This example shows the CAD model of a knee created from various CT images.

Earlier this year, Able Software received clearance from the FDA to market its 3D-DOCTOR software for medical imaging applications. 3D-DOCTOR is also a rendering and measurement software for computer tomography (CT), magnetic resonance imaging (MRI), microscopy, and other volumetric images. It creates 3D surface models from cross-section images in real time on a standard PC, letting doctors perform 3D visualizations of CT/MRI images. In effect, the software creates CAD models from medical images.

The software currently is in use by leading medical research organizations, and according to the company, the FDA clearance should help 3D-DOCTOR become more widely and rapidly adopted in other applications, including prototyping of medical devices.

Visit www.nasatech.com/features for more information on medical device manufacturing.

(Continued on page 28)

Get Connected to the Companies Featured in this Article:

Able Software	www.ablesw.com
EduNeering	www.eduneering.com
NetRegulus	www.netregulus.com
Pilgrim Software	www.pilgrimusa.com
U.S. Food & Drug Administration	www.fda.gov

A 10,000 psi ON/OFF valve in a 3.1" package!



Come visit us at
The ISA Expo
Booth #367

'V' Series Valves provide extremely long cycle life/high reliability

- Piston sensor design ensures high reliability & exceptional cycle life
- Compact package - only 3.1" high
- High flow capacity: $C_v = .75$ or 2.0
- Gas or liquid applications
- Normally open or normally closed
- Brass or 316 stainless steel machined bar stock
- Low actuation pressure: 30-60 psi
- High operating pressure: 6,000 psi maximum (brass), 10,000 psi maximum (stainless)

TESCOM
CORPORATION

INDUSTRIAL CONTROLS DIVISION

call 1-800-447-1250

www.tescom.com

Global technical support & distribution • Facilities in the US, Germany and Asia

NASA/Industry Partnership Improves Medical Device

NASA has consistently been in the forefront of innovative medical device development. The pacemaker, ingestible thermometer, microencapsulated drugs, cool vests, laser angioplasty, and magnetic resonance imaging (MRI) systems all trace their roots to NASA-developed technologies. The technology behind a surgical tool that uses artificial intelligence to increase the safety, accuracy, and efficiency of delicate surgical operations has been licensed by NASA to a commercial company for development of an early breast cancer diagnostic device.

Originally developed by Dr. Robert Mah of NASA's Ames Research Center in California, the "Smart Surgical Probe" was licensed to BioLuminate of Dublin, CA, which plans to develop, produce, and market a measurement device for early breast cancer detection. The device will consist of a disposable needle that will be used for each patient test. The needle will be used only after initial screening steps indicate the presence of a suspicious lesion.

The device provides six specific measurements of known cancer indicators, including oxygen partial pressure, electrical impedance, temperature, deoxygenated hemoglobin, vascularization, and tissue density. The measurements are taken simultaneously in real

time as a small 20 to 21 gauge disposable needle, connected to a computer, is inserted into the lesion. The needle is expected to exceed the accuracy achieved by core needle biopsies, and should approach the accuracy of surgical biopsies.

Since results are provided in real time, doctors and patients don't need to wait for pathology results, which could take up to two months from the first exam to the final diagnosis. If the results indicate the presence of cancer, treatments can begin immediately.

The average cost of breast cancer biopsies is approximately \$2,620 per patient. The BioLuminate procedure is estimated to cost \$525 per test, which includes a \$250 disposable needle. The test system itself is expected to cost less than \$50,000, and will include an electronic box about the size of a small typewriter that contains a computer, optical components, conversion electronics, and a display.

The combination of the NASA-developed probe technology, with BioLuminate's approach to reduce the size of the probe to a small needle, makes this partnership a unique one in the medical device industry.

For more information, visit BioLuminate at www.bioluminate.com.

Mass Flowmeters for Gases

Series 4100 (up to 20 L/min.) to measure air O₂, N₂ and N₂O

Series 4000 (up to 300 L/min.) to measure air, and O₂

... ideal for a wide range of applications

HIGH ACCURACY

FAST RESPONSE

LOW PRESSURE DROP

**Low Cost Measurement Solutions in
Laboratory and Installed OEM Versions for**


- Research and Development
- Laboratory Reference
- Manufacturing Testing
- Quality assurance

*... from TSI, a worldwide leader
in air and gas flow measurement technology*



**TSI Incorporated
Flowmeter Products**
St. Paul, Minnesota, USA

Tel.: +1 651 490 3849
Fax.: +1 651 490 4053
Email: flowmeters@tsi.com
Web: <http://flowmeters.tsi.com>



"Solid Edge gives us *everything* we need for machinery design."

– Paul Choate
Engineering Manager
Alcoa Packaging Machinery

Solid Edge is a complete tool kit for machinery design – powerful solid modeling, industrial-strength assembly design, engineering aids, and drafting – all in a remarkably affordable and easy-to-use package. Solid Edge is the most productive CAD package for machinery design, with the lowest cost of ownership, delivering the highest return on investment.

Alcoa Packaging Machinery is using Solid Edge to design innovative machinery for beverage packaging. "We chose Solid Edge because it was the easiest to use," says Paul Choate, engineering manager. "Solid Edge gives us all the tools we require, at a fraction of the cost of high-end systems."

Solid Edge is helping machinery designers realize the business benefits of 3D design – shorter design cycle times, improved product quality, fewer errors, and lower costs. To get down to the business of machinery design with Solid Edge, call 1 800-807-2200 or visit www.solid-edge.com.



powering
collaborative
commerce
formerly Unigraphics Solutions



SOLID EDGE

UGS, Unigraphics Solutions, and Solid Edge are trademarks, registered trademarks or service marks of UGS. All other trademarks, registered trademarks or service marks belong to their respective holders. The information within is subject to change without notice and does not represent a commitment on the part of UGS.

For Free Info Circle No. 527 or Enter No. 527 at www.nasatech.com/rs



End Caps Increase Thermo-Oxidative Stability of Polyimides

A thermo-oxidative-reaction path that leads to more stable products is exploited.

John H. Glenn Research Center, Cleveland, Ohio

Latently reactive end caps have been investigated as improved means to increase the thermo-oxidative stability of polyimides of the polymerization of monomeric reactants (PMR) type, which are often used as the matrix resins of high-temperature-resistant composite materials. The present end-cap compounds are candidates to supplant the norbornene end cap (NE) compound that, heretofore, has served to limit molecular weights during oligomerization and, at high temperatures, to form crosslinks that become parts of stable network molecular structures.

NE has been important to processability of high-temperature resins because (1) in limiting molecular weights, it enables resins to flow more readily for processing and (2) it does not give off volatile byproducts during final cure and, therefore, enables the production of void-free composite parts. However, with respect to ability of addition polymers to resist oxidation at high temperature, NE has been a "weak link." Consequently, for example, in order to enable norbornene-end-capped polyimide matrices to last for lifetimes up to

1,000 hours, it is necessary to limit their use temperatures to $\leq 315^\circ\text{C}$. The present improved end caps are also subject to oxidation at high temperature, but they oxidize in a different manner, such that the long-term stability of a polymer made with one of these end caps exceeds the long-term stability of the corresponding polymer made with NE. Hence, use temperatures and/or lifetimes can be increased.

Prior attempts to increase thermo-oxidative stability of PMR polyimides were oriented toward formulation of end caps that are inherently more stable than is the nadic end cap. The results were not satisfactory in that the end caps thus formulated adversely affected processability, the nature of the crosslinks, and, in some cases, the thermomechanical properties of the resulting polymers. In the present approach, one does not attempt to formulate end caps that are inherently more stable; instead, one seeks nadic derivatives that exploit one of the modes of the thermo-oxidative degradation of the nadic end cap in such a way as to retard the overall thermo-oxidative degradation of the affected polymers.

Research on the aging of PMR-15 polyimide has revealed that the degradation of the nadic end cap can occur via two primary reaction paths, designated A and B (see Figure 1). On path A, degradation proceeds through initial scission and oxidative opening of the norbornyl ring to form a 2-hydroxy substituted maleimide. On path B, degradation proceeds through oxidation of the bridging methylene of the norbornene moieties, followed by carbon monoxide extrusion. Aromatization of the resulting biradical leads to substituted phthalimides, and related secondary degradation products. The oxidation products of path A (including the 2-hydroxy substituted maleimide) are cleavage products that are most likely formed concomitantly with large loss of weight from the affected polymer. In contrast, the products of path B are more oxidatively stable and form with very little weight loss.

Therefore, in the present approach, one seeks to formulate end caps that preserve desirable processing properties of NE while favoring path B strongly, leading to lower weight loss




Figure 1. The Thermo-Oxidative Degradation of a norbornenyl end cap follows paths A and B. The products of path B are more stable than are those of path A.



**The Largest Design and
Manufacturing Exposition
on the West Coast!**

PACIFIC & MANUFACTURINGTM DESIGN show

February 5-7, 2002

**Anaheim Convention Center
Anaheim, CA**

Show Highlights:

- More than 400 leading OEM suppliers
- Network with more than 24,000 attendees
- Expanded and new product-specific pavilions:


CAD/CAM/PDM

Contract Manufacturing

Automation Technology

Electronics

Packaging

Motion Control sponsored by  **SMTA**
Solder Mounting Technology Association

- FREE admission to the co-located PLASTECHTM West, MD&M West 2002, and the NEW Electronics West shows—1600 additional exhibitors!

Register today for FREE Exhibit Hall Admission at

www.pacdesignshow.com

When registering on-line, please use Priority ID: AH

For more information:

Tel: 310/445-4200 • Fax: 310/996-9499 • www.pacdesignshow.com




Figure 2. End Caps of This Molecular Structure have been investigated for their potential to increase the thermo-oxidative stability of polyimides. X can be CRR', where R or R' can be H, OH, SH, F, Cl, an alkyl, an alkoxy, or an aryl; alternatively, X can be a ring molecular substructure.

and thus less shrinkage and cracking in the thermally oxidized layer of the affected polymer. Figure 2 depicts a generic molecular structure for a class of end caps that become thermo-oxidatively degraded primarily along path B. In this structure, X maintains its stability during imidization (at a temperature of 200 °C) and cross-linking (at 315 °C). Nevertheless, following these critical steps, X is spontaneously converted, upon aging, to a thermally stable capping group.

This work was done by Mary Ann B. Meador and Aryeh A. Frimer of **Glenn Research Center**. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Materials category.

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Glenn Research Center, Commercial Technology Office, Attn: Steve Fedor, Mail Stop 4-8, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16987.

End Caps for More Thermo-Oxidative Stability in Polyimides

Alternatives to previous formulations have been found.

John H. Glenn Research Center, Cleveland, Ohio

An additional class of end-cap compounds that increase the thermo-oxidative stability of polyimides of the polymerization of monomeric reactants (PMR) type has been invented. The prior class of end-cap compounds in this line of development is described in the preceding article.

PMR polyimides are often used as matrix resins of high-temperature-resistant composite materials. Like the end-cap compounds described in the cited previous article, the present end-cap compounds are candidates to supplant the norbornene end cap (NE) compound that, heretofore, has served to limit molecular weights during oligomerization and, at high temperatures, to form cross-links that

become parts of stable network molecular structures.

To recapitulate from the previous article: NE has been important to processability of high-temperature resins because (1) in limiting molecular weights, it enables resins to flow more readily for processing and (2) it does not give off volatile byproducts during final cure and, therefore, enables the production of void-free composite parts. However, with respect to ability of addition polymers to resist oxidation at high temperature, NE has been a "weak link." Consequently, for example, in order to enable norbornene-end-capped polyimide matrices to last for lifetimes up to 1,000 hours, it is necessary to limit their use temperatures to ≤ 315 °C.

Like NE and like the end caps described in the prior article, the present end caps are also subject to oxidation at high temperature, but they oxidize in a different manner, such that the long-term stability of a polymer made with one of these end caps exceeds the long-term stability of the corresponding polymer made with NE. Hence, use temperatures and/or lifetimes can be increased.

Prior to the present line of development, attempts to increase thermo-oxidative stability of PMR polyimides were oriented toward formulation of end caps that are inherently more stable than is the nadic end cap. The results were not satisfactory in that the end caps thus formulated adversely affected





Figure 1. The Thermo-Oxidative Degradation of a norbornenyl end cap follows paths A and B. The products of path B are more stable than are those of path A.



Showcasing the Power of Light



850 Conferences
Plenary and Keynote
Speakers
Panel Discussions
Engineering Courses
Technical Exhibition
and more



The International Society
for Optical Engineering



**Photonics
WEST**

The world's largest lasers, optoelectronics, and imaging meeting

Integrated Optoelectronics

Biomedical Optics

Electronic Imaging

High-Power Lasers

19 to 25 January 2002

San Jose Convention Center • San Jose, California USA

www.spie.org/info/pw

TEL: +1 360 676 3290 • FAX: +1 360 647 1445 • pw@spie.org

**Fast.
Reliable.
Safe.
Everything
automated
riveting
should be.**



**Introducing POPmatic
Point & Set™, the first
reliable auto-feed rivet
system.**

POPmatic Point & Set, our new auto-feed rivet system, delivers what no riveting tool has before. Consistent riveting at a rate faster than any current hand tool. Designed with a safe, self loading hopper that holds up to 2500 rivets, Point & Set accelerates the riveting process to previously impossible speeds, meeting the requirements of any production line. It's reliability in an otherwise unreliable world. For more information, call us at 203-925-4424 or visit us on the web at www.emhart.com

Emhart®
POPMATIC

A BLACK & DECKER COMPANY

CERTIFIED
ISO 9001 • QS 9000

processability, the nature of the cross-links, and, in some cases, the thermo-mechanical properties of the resulting polymers. In the present approach, one does not attempt to formulate end caps that are inherently more stable; in-




Figure 2. End Caps of This Molecular Structure are alternatives to previously reported end caps for increasing the thermo-oxidative stability of polyimides. R₁ or R₂ or both can be alkyl, alkoxy, aryl, fluoro, chloro, carbomethoxy, nitro, or another substituent.

stead, one seeks derivatives that exploit one of the modes of the thermo-oxidative degradation of the nadic end cap in such a way as to retard the overall thermo-oxidative degradation of the affected polymers.

Research on the aging of PMR-15 polyimide has revealed that the degradation of the nadic end cap can occur via two primary reaction paths, designated A and B (see Figure 1). On path A, degradation proceeds through initial scission and oxidative opening of the norbornyl ring to form a 2-hydroxy substituted maleimide. On path B, degradation proceeds through oxidation of the bridging methylene of the norbornene moieties, followed by carbon monoxide extrusion. Aromatization of the resulting biradical leads to substituted phthal-

imides, and related secondary degradation products. The oxidation products of path A (including the 2-hydroxy substituted maleimide) are cleavage products that are most likely formed concomitantly with large loss of weight from the affected polymer. In contrast, the products of path B are more oxidatively stable and form with very little weight loss and with less shrinkage and cracking in the oxidized layer.

The present end caps are formulated to preserve the desirable processing properties of NE and to undergo thermo-oxidative degradation primarily or exclusively along path B. Figure 2 depicts a generic molecular structure for the present class of end caps. In this structure, the end cap contains no bridging methylene. Rather, the end cap is a 1,2,3,6-tetrahydrophthalic anhydride, substituted in such a way as to lower the cross-linking temperature from >415 °C to between 280 and 350 °C. The end cap maintains its stability during imidization (at 200 °C) and cross-linking. After the foregoing critical steps, the end cap is spontaneously converted, upon aging, to thermally stable capping groups.

This work was done by Mary Ann B. Meador of Glenn Research Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Materials category.

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Glenn Research Center, Commercial Technology Office, Attn: Steve Fedor, Mail Stop 4-8, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-17012.

Low-Density, Ablative Resin-Impregnated Ceramic Insulation

Properties can be tailored for enhanced thermal protection.

Ames Research Center, Moffett Field, California

Low-density, ablative thermal-protection panels can be made by impregnating fibrous ceramic substrates with organic polymers. With proper design and fabrication, these panels can protect temporarily against temperatures up to 3,500 °C or heat fluxes up to 16 MW/m².

Like ablative thermal-protection panels of older types made of other combinations of materials, the panels of the present type absorb and dissipate incident heat through depolymerization

and charring of resins, transpiration (blowing of gaseous pyrolysis products from boundary layers), and radiation from charred surface layers. In comparison with panels of older types, the panels of this type are more porous; thus, gaseous pyrolysis products can percolate more freely. The panels of the present type also dissipate heat through additional mechanisms that can include vaporization of ceramic fibers and radiation from the heated surfaces of the ceramic substrates.



IF YOU CAN THINK IT, WE CAN DO IT.

Emhart is a world leader in the design and supply of innovative fastening and assembly technology. From concept through installation, whether you're manufacturing around the corner or around the globe, Emhart provides cost-effective solutions for assembly applications. Visit us at www.emhart.com

Emhart[®]


A  BLACK & DECKER COMPANY

At a heat flux in the approximate range of 1 to 2.5 MW/m², the surface layer that forms on a typical panel of the present type includes not only a char formed by decomposition of the organic material but also the coalesced ends of ceramic fibers. The resulting char layer that builds up on the surface is stronger than are the char layers that build up on ablative thermal-protection panels of older types, and the surface-recession rate for this panel is therefore lower.

Another contribution to thermal protection arises from a complex of additional mechanisms that also occur at a heat flux in the approximate range of 1 to 2.5 MW/m²: If, for example, the ceramic fibers are made of silica, then during pyrolysis, the organic material can react with the fibers to form a layer of silicon carbide protected by a thin, glassy layer of silicon dioxide. The glassy layer makes the panel less catalytic and thereby reduces the rate of convective heating. The surface is also highly emissive and therefore most of the energy absorbed at the surface is reradiated. The combination of reduced convective heating and reradiation helps to suppress loss of mass and recession of the surface.

At a heat flux in the approximate range of 4.3 to 16 MW/m², the panel dissipates incident heat almost entirely by reradiation and micro spallation or evaporation of the ceramic substrate. The combination of a resin that has a high char yield and a substrate that has a high melting temperature enables the panel to reradiate heat efficiently from the heated surface without undergoing melting or significant mechanical failure.

Fibrous substrates for these panels can be made of any of a variety of ce-



The Fibrous Ceramic Substrate Is Impregnated with the resin solution in this apparatus. The impregnated substrate is then processed further to obtain a porous fibrous ceramic panel, the fibers of which are coated with a polymer.

ramic materials; for example, silica (mentioned above), zirconia, boria, hafnia, or silicon carbide, to name a few. Organic materials suitable for infiltration into the substrates include thermoplastic and thermosetting resins. Substrates can be impregnated evenly throughout their thicknesses; alternatively, by suitable design of infiltration

processes, one can obtain gradients in the densities of the polymers.

The figure illustrates an apparatus and process for impregnating a ceramic substrate with a resin. The burette on top of the vacuum chamber is initially filled with a resin solution. Also initially, the beaker in the vacuum container is empty. The substrate is placed in the beaker, then the chamber is evacuated, then the solution is allowed to flow into the beaker until the substrate is entirely immersed. Then the chamber is disconnected from the vacuum pump and vented to the atmosphere, forcing the solution into the interstices of the substrate.

Next, the impregnated substrate is removed from the beaker and subjected to further processing that depends on the type of resin and the desired uniformity or gradient of density; for example, to achieve even impregnation with a thermoplastic resin, the substrate can be dried slowly in air. When processing is complete, the fibers are coated with a polymer. Typically, the resulting panel has a void volume fraction between 85 and 93 percent, a density between 0.17 and 0.3 g/cm³, and a resin content between 30 and 60 weight percent.

This work was done by Huy K. Tran, William D. Henline, Ming-ta S. Hsu, Daniel J. Rasky, and Salvatore R. Riccitiello of Ames Research Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Materials category.

This invention has been patented by NASA (U.S. Patent No. 5,672,389). Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Ames Research Center, (650) 604-5104. Refer to ARC-12011-2.

Solar Heating for Deployment of Foam Structures

Local sources of energy could be reserved for other purposes.

NASA's Jet Propulsion Laboratory, Pasadena, California

Solar heating has been proposed as a means of deployment of structures of the type described in "Cold Hibernated Elastic Memory (CHEM) Expandable Structures," (NPO-20394), *NASA Tech Briefs*, Vol. 23, No. 2 (February 1999), page 56. A few examples of structures that would be amenable to the CHEM approach include expandable shelters, tanks, rafts, and thermally insulating boxes for storing food and drinks.

To recapitulate from the cited prior

article: The CHEM concept is one of utilizing open-cell foams of shape-memory polymers (SMPs) to make lightweight, reliable, simple, and inexpensive structures that can be alternately (1) compressed and stowed compactly and later (2) expanded and rigidified for use. A CHEM structure of any shape is compacted to a small volume while in the rubbery state above the glass-transition temperature (T_g) of the SMP. After compaction, the struc-

ture is cooled below T_g where it is frozen in the glassy state of the SMP. The compacting force can then be released and the structure remains compact as long as the temperature is kept below T_g . Upon subsequent heating of the structure above T_g to the rubbery state of the SMP, the simultaneous elastic recovery of the foam and its shape-memory effect cause the structure to expand to its original size and shape. Once thus deployed, the structure can

be rigidified by cooling below T_g to the glassy state. Once deployed and rigidified, the structure could be heated and recompacted. In principle, there should be no limit on the achievable number of compaction/deployment/rigidification cycles.

The attractiveness of the CHEM structure is the wide range of T_g resulting in a variety of potential space and terrestrial applications. Experiments have confirmed the feasibility of this innovative, self-deployable, and rigidizable structure.

The disadvantage of CHEM structures is that heat is needed for deployment. The proposed use of solar heat would eliminate the need to deplete other energy sources. According to the proposal, a CHEM structure would be wrapped in a blanket made of a material with a high ratio between solar absorptivity and infrared emissivity. Upon exposure to solar radiation, the struc-

ture inside the blanket would become heated because the blanket would absorb more heat than it would reradiate. Eventually, the temperature of the wrapped structure would increase beyond T_g , causing the structure to deploy itself by expanding to its full size and shape. After full deployment, the blanket would be removed, causing the structure to become cooled below T_g and thus rigidified. Thermal analysis confirmed a feasibility of this concept in the Mars environment. This concept will also work for applications on Earth and perhaps perform even better than on Mars.

This work was done by Witold Sokolowski, Art Chmielewski, and Henry Awaya of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Materials category. NPO-20961

Fluorinated Diamondlike Carbon Coatings

This material is expected to exhibit low friction and resistance to atomic oxygen.

Lyndon B. Johnson Space Center, Houston, Texas

Some experiments directed toward the development of improved hard, lubricious coating materials have involved direct fluorination of proprietary diamondlike coats on various substrates. The idea is to retain the hardness of the diamondlike material while adding surface molecular structures that impart the chemical inertness (especially resistance to erosion by atomic oxygen) and lubricity of fluorinated polymers.

The proprietary diamondlike coating material is Amorphous Diamond™, which comprises nodules of carbon that have the molecular/crystalline structure of diamond, with sizes of 100 to 200 nm, densely and uniformly packed in a net of amorphous carbon polytypes. This material has a low coefficient of friction and is almost as hard as diamond is. However, it is not brittle: it can withstand flexure and shock without cracking. It can be applied to plastic, polymer, metal, and ceramic substrates.

In the experiments reported thus far, material samples coated with the diamondlike material were exposed to fluorine to create a surface layer of

highly inert carbon/fluorine molecular bonds. Fluorination did not degrade the lubricity and hardness of the diamondlike coats. Among the samples were sheets of Kapton™ polyimide 5 mils (about 0.1 mm) thick. The sheets remained flexible after fluorination of the diamondlike coats. The coating layers were not compromised, even when the sheets were creased.

At the time of submission of information for this article, the ability of the fluorinated coats to resist erosion by atomic oxygen remained untested. Also untested at that time was the combined effect of ultraviolet radiation and erosion by atomic oxygen (this is of concern because the rates of erosion of fluoropolymers by atomic oxygen have been observed to increase in the presence of vacuum ultraviolet radiation).

This work was done by Mark S. Hammond and A. Wesley Moorehead of SI Diamond Technology, Inc., for Johnson Space Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Materials category. MSC-22364


*Now available in the
NASA Tech Briefs
bookstore:*

Encyclopedia of the Solar System

Edited by

Paul R. Weissman and
Torrence V. Johnson of
NASA's Jet Propulsion
Laboratory

Foreword by
Sally K. Ride



"Four decades of the most exciting explorations in human history in one book! Up-to-the-minute details by the best writers to explore the solar system are wonderfully organized for both looking up quick facts and for in-depth study. This one pulls it all together. Any citizen of the solar system from age 8 to 80 should own this encyclopedia."

— Dr. Jay Apt, Director, Carnegie Museum of Natural History, four-time Space Shuttle Astronaut

Superbly illustrated with images from the Hubble Telescope and other observatories.

Hardcover • 992 Pages

Discount price: \$96.95

Order online:

www.nasatech.com/store



Special Coverage: Composites & Plastics



MACtac Technical Products, Stow, OH, offers the GS-Series™ **adhesive tape** that features instant aggressive tack for the permanent bonding of substrates in assembly and manufacturing industries. This pressure-sensitive acrylic can be used with metal, wood, polyethylene, polypropylene, glass, rigid composites, hook-and-loop fasteners, extruded polymers, and a variety of other substrates. It also is suitable as a replacement for some mechanical fasteners.

The tape has a standard thickness of 5 to 60 mils, which allows it to establish secure bonds to uneven or irregular surfaces. The adhesive also has gap-filling properties and serves as a moisture barrier. Adhesives are supplied on a 60# kraft release liner with ungummed edges to provide easier handling and liner removal. The tape can be designed and custom-formulated to meet specific applications.

**For Free Info Circle No. 711 or
Enter No. 711 at www.nasatech.com/rs**



Master Bond, Hackensack, NJ, has introduced EP21AN, a two-part, thermally conductive **adhesive system** that works as an electrical insulator with a dielectric strength of >400 volts/mil, and a volume resistivity greater than 10^{13} ohm-cm.

The adhesive has been formulated with a non-critical 1/1 mix ratio, weight, or volume.

It cures readily at ambient temperatures or more quickly at elevated temperatures. The adhesive features adhesion to a range of substrates including metals, ceramics, glass, and plastics. Bonds exhibit dimensional stability, and shrinkage upon cure is low. It is available in ½-pint, pint, quart, gallon, and five-gallon kits.

**For Free Info Circle No. 712 or
Enter No. 712 at www.nasatech.com/rs**



The 9-20557 **conformal coating** from Dymax Corp., Torrington, CT, provides adhesion to PCB surfaces that receive little to no cleaning. The cured coating forms a transparent layer that protects underlying circuitry and components from moisture, dust, and other contaminants. The viscosity of the one-component coating is suitable for consistent spraying application through dispensing systems. Designed to cling to "hard to wet" surfaces, the coating does not run off of solder points and component edges.

The coating has a secondary heat curing capability and fluoresces under "black" lights for coverage inspection. It cures in 20 to 30 seconds upon exposure to UV/visible light, or standard, longwave lights. Cure times are as short as five seconds with high-intensity lights and conveyor speeds of 10-20 feet per minute. The resin coating provides adhesion to glass-filled epoxy, metal, and ceramic surfaces.

**For Free Info Circle No. 713 or
Enter No. 713 at www.nasatech.com/rs**




DuPont Performance Lubricants, Wilmington, DE, offers Krytox® XHT **lubricants**, a blend of low-volatility oils, additives, and thickeners that increase adhesion to protect bearing surfaces subjected to high heat conditions. The lubricants are based on fluoropolymer technology,

and are non-flammable, chemically inert, and do not carbonize. They are available with temperature ranges of up to 399°C for continuous use, with temperature spikes at 427°C when used with proper metalurgy and relubrication intervals.

The lubricants are suited for exhaust diverters, deicing systems, thrust nozzles, and other aerospace components, as well as the automotive industry, paint plant conveyor bearings, corrugator and paper machine bearings, welding machines, high-temperature fans, and valve lubrication. Krytox is a white, non-migrating lubricant compatible with all elastomers and plastics.


**For Free Info Circle No. 714 or
Enter No. 714 at www.nasatech.com/rs**



ABLETHERM® 3100 Series **thermal interface materials** for flip-chip BGA packages are available from Ablestik Laboratories, Rancho Dominguez, CA. The materials feature thermal performance, low modulus, and high adhesion. They have low moisture absorption, contributing to adhesive reliability during 200 hours HAST exposure.

The material's low stress bond between the chip and thermal lid survives 1,000 temperature cycles under condition B (-75°C to 125°C) without delaminating. The adhesive properties of the materials enable use for FCBGA lid attach applications. The materials also feature dispensability and rheology, allowing them to be incorporated into standard dispensing processes.

**For Free Info Circle No. 715 or
Enter No. 715 at www.nasatech.com/rs**



TRA-BOND 8-2 **thermally conductive epoxy adhesive** from Tra-Con, Bedford, MA, bonds difficult-to-bond metals such as gold, silver, copper, brass, and solder. Designed as an instrument adhesive, the epoxy offers thermal conductivity, high strength, and temperature resistance to 150°C. The blue epoxy has a dielectric strength of 500 volts/mil, and a working life of four hours at 25°C.

The epoxy has a shelf life of one year. Lap shear from aluminum to aluminum is 2,300 psi; lap shear from gold to gold is 2,600 psi. It is available in custom bipax, or pre-mixed and frozen.

The epoxy has a shelf life of one year. Lap shear from aluminum to aluminum is 2,300 psi; lap shear from gold to gold is 2,600 psi. It is available in custom bipax, or pre-mixed and frozen.

**For Free Info Circle No. 710 or
Enter No. 710 at www.nasatech.com/rs**

PHOTONICS

Tech Briefs

PHOTONICS SOLUTIONS FOR THE DESIGN ENGINEER



Fiber Lasers Come to the Ultrafast Realm	11a
The Diversification of Ultrafast Lasers.....	4a
Commercial-Tolerance Superachromatic Near-IR Laser System	8a
Software for Multidisciplinary Concurrent Optical Design	8a
Multibeam Beacon Laser Assembly	9a
Improved Fiber-Pigtailed Non-Planar Ring Oscillator Laser	10a
Computing Atmosphere Profiles from Spectral Measurements	12a
Study of Stitching Errors in Slot-Shifted E-Beam Lithography	12a
Magnetically Actuated Miniature Paraboloidal Mirrors with Variable Radii of Curvature.....	13a
New Products	14a

Cover Photo Courtesy of Thermo Laser Science

Fiber Lasers Come to the Ultrafast Realm

Optical fiber enables robust ultrashort-pulse laser designs for use in industry.


Commercial applications using ultrashort laser pulses are beginning to arise, particularly in the fields of materials processing, medicine, metrology, and microscopy. These application areas have a need for a source that not only meet particular optical design requirements—pulse duration, peak power, energy, and wavelength—but also must be ready to use outside of the more traditional laboratory environments where ultrashort-pulse laser systems have been used until now. Advances in the development of solid-state lasers have shown promise for use in in-

dustry, but in particular fiber lasers appear to hold many advantages that will allow ultrafast technologies to take root.

“Ultrashort” pulses, bursts of laser energy on the order of 1 picosecond (10^{-12} sec) or less, are thousands of times shorter than pulses from conventional Q-switched lasers. Ultrashort laser pulses enable applications that have a requirement for such things as high temporal resolution (metrology), and high spatial resolution and high peak powers (materials processing including some medical applications, and also some forms of microscopy).

As an example, ultrashort pulses have been shown to cleanly ablate a wide variety of materials with minimum damage to the surrounding material because of excessive local heating or shock. The types of “materials” can also include tissues such as dentin or the cornea. In fact, an ultrashort-pulse laser has been approved for use as a laser microkeratome in the field of ophthalmology, replacing the use of a mechanical blade to open the corneal flap during the course of the procedure.

For this and many biomedical applications such as spinal and heart surgery,



Schematic of the Wattlite laser. Ultrashort pulses at 1550 nm from an Er:fiber laser are Raman-shifted and then frequency-doubled to 1040 nm, making them compatible with ytterbium-doped amplifiers.

Broadband telecommunications is on a roll in Georgia. Believe it. The Yamacraw broadband design program is helping Georgia create over 2,000 attractive jobs for new engineers with powerhouses here like Broadcom, CIRREX, CIENA, StarCore, Wi-Lan, Echostar, Barco, Cypress, MicroCoating Technologies, Nortel Networks, SecureWorks, IDT, National Semiconductor, Movaz, Luxcore, RF Solutions, Ardest Technologies, BellSouth, Quantira Technologies, H.O. Systems, and iVivity. If your life is Broadband, live it in Georgia midst a marvelous climate, a wealth of natural resources and recreation and a favorable cost of housing and living. To submit a resume into the jobs database or for more surprising information, visit www.yamacraw.org/jobs.



BROADBAND IS SOARING IN GEORGIA.



GEORGIA

pulse energies in the range of 1 to 100 microjoules and repetition rates of 100-250 kHz appear to be appropriate. For other types of materials processing not involving ablation, but merely damage of materials (for instance, to modify the refractive index of glass), more modest pulse energies of nanjoule level at higher repetition rates (1-80 MHz) can be used. These higher-repetition-rate lower-energy lasers are also suitable for many metrology and microscopy applications.

"Flexible" fiber laser technology

Fiber optic technology is well known to have advanced telecommunications in recent years. In the wake of this progress, components such as pump laser diodes and rare-earth-doped optical fibers have been engineered to a high degree, and are routinely used in products with lifetimes predicted to last into the tens of years. Utilizing this highly reliable technology base, IMRA America has developed a variety of ultra-short fiber lasers to meet different wavelength, pulse energy, and peak power needs. All of this is done in conjunction with careful engineering of the fiber laser system to make it easy to use, turnkey, robust, and reliable for industrial use.

This drive for robust turnkey technology to suit industrial environments is behind the design concepts used by IMRA in the development of the Femtolite, Wattlite, and FCPA lasers. The heart of these lasers is IMRA's Femtolite technology, providing 1560-nm femtosecond pulses at 50 MHz. This erbium-doped fiber-based oscillator and amplifier system is environmentally stable, operating at ± 15 degrees C. Modelocked using a semiconductor saturable absorber, the oscillator starts up within a second and does not suffer pulse dropout, which is possible with other solid-state modelocked laser technology. The footprint of this portion of the system is about 9 by 5 in.—achieved with a fiber cavity length of a few meters—because of the ability to coil fiber into a small space. The resulting output at 1560 nm is up to 1.2 nanjoules with a few kilowatts peak power and less than 200-fs pulses. Optional frequency-doubled output at 780 nm of up to 0.5 nJ and less than 200-femtosecond pulses is also available.

In order to obtain light at 1040 nm for IMRA's ytterbium fiber amplifier-based Wattlite (see the figure), the output of the 1560-nm Femtolite is Raman-shifted in fiber to obtain 2080-nm radiation and then directed through a second-harmonic generator, in this case a piece of

periodically-poled LiNbO₃ (PPLN). The resulting 1040-nm light is used to seed a very efficient Yb-amplifier fiber. The amplifier is a double-clad fiber, cladding pumped using high-brightness laser diodes that provide a few watts of power. Through proper optical design, this system produces a few hundred milliwatts of 1040-nm light with broad bandwidth, compressible to less than 100 femtoseconds. Again, optical frequency doubling can provide nanjoule femtosecond 520-nm pulses.

To achieve even higher pulse energies, IMRA's FCPA (fiber chirped-pulse amplification) laser uses the Wattlite as a seeder for a further Yb-amplifier stage, also adding two stages of acousto-optic modulators to "down-count" the repetition rate in order to extract more energy during amplification. Energies of 2-10 microjoules are typically available from FCPA systems at repetition rates of up to 250 kHz.

An alternative high-pulse-energy technology, PCPA (parametric chirped-pulse amplification), uses stretched pulses from the Femtolite seed laser described above, along with a Q-switched microchip laser pump for extremely efficient amplification of 1560-nm light in PPLN.

Engineered to last

Beyond the flexibility for laser design in terms of wavelength and pulse energy, fiber lasers hold several advantages in ease of use and long-term operation, which are both relevant for industrial use. As stated above, many of the components used in the system are telecommunications-grade, providing long lifetime over a range of operating conditions.

Turnkey wall-plug operation is achieved by use of semiconductor laser diode pump sources as the fiber's optical gain medium. The water cooling necessary for some solid-state lasers is avoided because cooling of several-watt pump laser diodes can be achieved by convection and conduction.

A major advantage of fiber laser design above other solid-state laser systems is the fact that the laser cavity comprises only short "free-space" optical paths that are based on single-mode fiber optics. This yields the excellent pointing stability and TEM₀₀ operation inherent to the system. Typical pointing stability achieved by a 1040-nm Wattlite laser is less than 20 microradians RMS, which is an order of magnitude better performance than solid-state technology usually achieves. This is extremely important when a laser beam is used in an instrument or another permanent or

OEM setup because it enables system designers to discount beam wander.


Nonlinear effects can be exploited and/or avoided selectively in fiber systems, which are very efficient nonlinear media, but also highly dispersive. Nonlinear effects are used efficiently for femtosecond pulse generation in the Femtolite oscillator (a soliton pulse generator), as well as in the wavelength-shifting Raman-shifting fiber stage in the Wattlite. By stretching the pulse duration in the FCPA and PCPA laser systems, using the well-known chirped-pulse amplification technique, high energy extraction without pulse shape and final duration distortion can be achieved. This stretching can be achieved using long fibers or fiber Bragg gratings. Generation of solitons in (bulk) solid-state lasers is not achievable without use of fibers, while pulse stretching is generally done with ruled gratings, which leads to extra complexity of design.

Another aspect of fiber laser design is that the cavity can be packaged in an entirely different (and more compact) geometry than solid-state lasers. A solid-state modelocked laser cavity of 3 meters free space takes only about 2 meters in fiber, due to the refractive index of the fiber material being about 1.5 times that of air, which can be made into a flat coil of about 4 in. in diameter. Using fiber pigtailed pump laser diodes also takes little space, with the free-space optical portions of the laser system and high-power laser diodes taking up the greater part of the packaging.

Fiber lasers can also use the flexibility of the fiber to advantage in cases where delivery of the output laser beam to a position remote from the laser head is necessary. In particular, in the Wattlite laser system, fiber delivery between the main laser head and a small (4 in. \times 6 in.) output box can be achieved. This allows a user to locate the free-space output from the output box at about 0.5 m away from the 8½-in. \times 11-in. laser head. Furthermore, the output box provides the compressed, and optionally doubled, output directly at the application point, without need for extra steering mirrors.

The small footprint, ease of use, and highly stable output beam from IMRA's femtosecond fiber laser technology make these lasers a natural choice for industrial and OEM use.

For further information, please contact the authors of this article, Dr. Michelle L. Stock and Dr. Gregg Sucha, product managers, and Dr. Heinrich Endert, vice president of marketing, at IMRA America, 1044 Woodridge Ave., Ann Arbor, MI 48105; (734) 930-2560; www.imra.com.



Wavelength Measurement of Violet Laser using Coherent WaveMaster



No "Shrinking Violet"

New Longer Lifetime Violet Lasers

GENOMICS

PRINTING

CYTOMETRY

OPTICAL
STORAGE

DISPLAYS

CONFOCAL
MICROSCOPY

- 4 mW and >25 mW versions
- Longer lifetime InGaN laser diodes
- Superior beam quality
- User adjustable focus
- TE cooled for excellent wavelength stability
- CE marked standard HeNe size package
- Single transverse mode
- OEM versions available
- Longer wavelengths available


When it comes to violet laser systems, Coherent is the world leader. We combine the very latest Indium Gallium Nitride semiconductor laser technology available with our high quality optics and drive electronics to give you, our customer, a truly superior violet laser system.

Coherent's 30 years experience as the world leader in laser systems gives you the very best laser available for your application. We back our laser diode modules and systems with a one year warranty and a level of service and technical support that is second to none.

For a copy of our latest data sheets describing the new range of Violet Laser Diodes or to discuss your OEM application, please call 1-800-343-4912.



4 mW Violet Laser System



African Violet



A Member of Coherent Photonics Group



2303 Lindbergh Street
Auburn, CA 95602
Toll Free: 1-800-343-4912
Tel: (530) 889-5365
Fax: (530) 889-5366

<http://catalog.Coherentinc.com/lv.html>

UK Free Phone: 0800 515801
Germany +49-6071-968-303
France +33-1-60 19 40 40
Japan +81 (0) 3 5635 8680

For Free Info Circle No. 493 or Enter No. 493 at www.nasatech.com/rs

The Diversification of Ultrafast Lasers

The "one-box" concept takes hold.

An ultrafast laser is a source that generates pulses in the picosecond (10^{-12}) or femtosecond (10^{-15}) regime, achieved through a technique known as mode-locking. In their early days, developers of ultrafast lasers focused mainly on improving performance, resulting in shorter pulses with ever higher peak powers. But in the past few years, manufacturers have concentrated on improving reliability, ruggedness, package size and ease of use. This product revolution has resulted in the "one-box" ultrafast oscillator and the "one-box" ultrafast amplifier. These offer a turnkey simplicity that has, in turn, spurred considerable growth and diversification in applications for ultrafast pulses, from biomedical imaging to materials processing.

Mode-Locked Lasers

Most continuous-wave (CW) lasers have multi-longitudinal mode output. If the phase relationship between these modes can be fixed, or locked, then the modes constructively interfere at some point in the cavity and destructively interfere elsewhere, resulting in a single circulating pulse. Each time this pulse reaches the output coupler, part of it escapes the laser cavity (see Figure 1). The output thus consists of a stream of pulses separated in time by the interval of the light's circulation around the laser cavity.

In practice, mode-locking can be either active or passive. In active mode-locking, the gain of the cavity is modulated at the cavity round-trip time, e.g., by use of an acousto-optic modulator. Passive mode-locking utilizes a passive intracavity element that favors the high peak power characteristic of mode-locked pulses.

In principle, any CW laser can be mode-locked. But because the duration of the pulse is inversely proportional to its spectral bandwidth, shorter pulses can only be achieved by using wide-bandwidth lasing materials. Furthermore, the laser material and cavity optics must be able to withstand the transient peak powers generated by mode-locking. And lastly, the laser material must be compatible with simple product implementation.

Ti:sapphire and the Solid-State Revolution

The titanium:sapphire (or Ti:sapphire) mode-locked oscillator uniquely meets all the foregoing requirements, and virtually all commercial femtosecond lasers are currently based on this solid-state material. Ti:sapphire has a broad spectral emission from <700 to >1000 nm, enabling mode-locked pulses as short as a few femtoseconds. Just as important, Ti:sapphire crystals are sta-

rugged, and compact, with no requirement for cooling water or a high-voltage supply.

The typical commercial Ti:sapphire oscillator produces up to 2 watts of average power, with a pulse width of <100 femtoseconds, a pulse energy of several tens of nanojoules, and a pulse repetition rate around 80 MHz. These pulse energy levels are sufficient for a number of applications. In some instances, however, it is more important to have much higher pulse energies (and peak powers) rather than a high pulse-repetition rate. These needs can be met by amplifying the laser pulse, using a regenerative amplifier.

A regenerative Ti:sapphire amplifier acts by picking off an individual pulse from the output of a mode-locked Ti:sapphire oscillator, using an electro-optic modulator. The selected pulse is injected into and trapped in a regenerative cavity, which contains an optically pumped Ti:sapphire crystal. The pulse circulates around the cavity, and each




Figure 1. In a mode-locked laser, the longitudinal cavity modes interfere with each other. Because of their slightly different wavelengths, there is only one point in the cavity where they constructively interfere, producing a short pulse of light, which travels around the cavity.

ble, broadly available, and offer a high damage threshold. Moreover, Ti:sapphire oscillators can be designed to operate using active or passive mode-locking materials.

Because they require optical pumping with green or blue light, early Ti:sapphire lasers were pumped with power-hungry argon ion lasers. However, frequency-doubled diode-pumped Nd:YVO₄ lasers at 532 nm with several watts of CW power were introduced in 1996. Since then, these all-solid-state lasers have been the pump sources of choice, because they are simple,

time it passes through the crystal it gains energy. After several passes, the amplified pulse is ejected and a new pulse is allowed to enter the amplifier cavity. A typical regenerative amplifier is the Spectra-Physics Spitfire®, which produces pulse energies up to 2.25 mJ and operates at repetition rates up to 5 kHz.

The regenerative amplifier requires a pulsed visible pump source with kilohertz repetition rates to excite the Ti:sapphire crystal in the cavity. Here the best choice is a diode-pumped frequency-doubled Q-switched Nd:YLF solid-state laser, which delivers output at 527 nm without the need for external cooling water or high-power three-phase utility.

Of course, a number of research applications require the ability to produce ultrafast pulses over a wide range of wavelengths. This need is met by driving a commercial optical parametric amplifier (OPA) with the 800-nm output of a "one-box" Ti:sapphire amplifier. A state-of-the-art OPA with harmonic generators produces ultrafast laser pulses that are tunable from the UV (<300 nm) to the IR (>10µm).




Figure 2. The latest "one-box" lasers are extremely compact and rugged. This photo shows a typical example, the Spectra-Physics Mai Tai®, with and without its cosmetic outer cover.




Diagram courtesy of Photo Research, Inc.,
"The Light Measurement People."

What color of laser light do you want?

That's right, pick your laser light color. With our nitrogen pumped dye laser system, you can tune from 360 nm to 950 nm to get the color of laser light you want.

No, no, no! No flowing nitrogen, no running water, no pumping dyes. With our system, you just plug in and turn on. Then select the wavelength for your research and start taking data. It is that simple.

For UV light, add our doubling module. If you could see UV, you could watch it tune from 220 to 320 nm.

Talk to us about the color of laser light you want and what you want to do with it. We would love to help!


Thermo Laser Science 8E Forge Parkway Franklin, MA 02038
www.laserscience.com 508-553-2353 fax: 508-553-2355

Thermo Laser Science

provider of low cost laser light from UV through IR

For Free Info Circle No. 484 or Visit www.nasatech.com/484

Accelerate Your Vision Development



Quickly develop machine vision and scientific imaging solutions with the latest IMAQ™ Vision Builder.

- Integration of your vision application with motion and data acquisition
- Easy-to-use, configurable development environment
- Ability to create LabVIEW™ VIs and Measurement Studio™ code recipes
- Complete set of machine vision and imaging functions
- Vision Solution Wizard

ni.com/info

To learn more about IMAQ Vision Builder, visit ni.com/info and enter na9n28.

**NATIONAL
INSTRUMENTS™**

(800) 811-2046

Fax: (512) 683-9300 • info@ni.com

© Copyright 2001 National Instruments Corporation. All rights reserved. Product and company names listed are trademarks or trade names of their respective companies.

Rugged "One-Box" Packaging

There are many applications and potential applications for ultrafast pulses, beyond the traditional research areas of laser photophysics and photochemistry. In order to support these applications, it is vital that the laser provide rugged simplicity and that it can be fully utilized by virtually anybody. It is also important to minimize the size and complexity of these laser systems.

In response to this market need, Spectra-Physics and others have developed integrated "one-box" ultrafast oscillators, where the entire laser system—pump and mode-locked Ti:sapphire laser—is enclosed in a single sealed head that combines rugged reliability with stable hands-free operation.

There are two key aspects to this technology: these new lasers utilize all-solid-state technology throughout, and all the optics are assembled and mounted on monolithic aluminum structures in order to fully exploit the inherent stability of the technology. Just as important, the laser is designed so that no manual optical adjustments are required.

Another critical part of the design is to place the diode laser bar of the pump laser remotely in the power supply, and to use fiber optics to couple its output into the system. The long-lived bars can thus be field-replaced, without optical alignment. Combining these design factors with modern optical mounting techniques has led to the successful development of the sealed mode-locked Ti:sapphire laser head, typically measuring only 60 by 35 cm (see Figure 2). All operational parameters can be computer-controlled through a software interface.

Initial models offered femtosecond pulses at a fixed wavelength, usually factory-set at 800 nm. Within the past few


years, two variations of this basic product have emerged. The design of an automated dispersion compensation scheme has enabled the development of the Spectra-Physics Mai Tai®, the first "one-box" ultrafast (<100 fs) oscillator with widely tunable output (750-850 nm, or 780-920 nm)—again with no manual adjustments. In addition, the development of saturable Bragg reflectors (SBR), under license from Lucent Technologies, and negative dispersion mirrors has enabled reliable self-starting "one-box" solutions capable of producing ultra-short (<30 fs) pulses.

Similar progress has been made in the simplification of amplified lasers. Here the scenario is a little more complicated, with the Ti:sapphire oscillator, the Ti:sapphire regenerative cavity, and the pump laser for the amplifier. In today's systems, however, it has again proven possible to fully exploit the high stability attainable with diode-pumped solid-state technologies. The result is a compact "one-box" closed laser head, albeit somewhat larger than a self-contained Ti:sapphire oscillator. One example is the Spectra-Physics Hurricane®, which produces sub-130-femtosecond pulses with pulse energies of up to 1 mJ and operates at repetition rates of up to 5 kHz. The laser head measures only 100 by 72 cm, and again all functions can be controlled through a software interface.

A Host of Applications


The advent of hands-free ultrafast lasers is causing a dramatic mindshift in the way end users and systems integrators regard ultrafast technology. The ultrafast source is no longer the main focus of the experiment, requiring constant attention by a dedicated techni-

Femtosecond Laser Micromachining Stainless Steel



Exitech Limited 400um
Spectra Physics "Hurricane" Laser

Femtosecond Laser Micromachining Fused Silica



Exitech Limited 100um
Spectra Physics "Hurricane" Laser

Figure 3. Amplified ultrafast lasers can cut and drill a wide range of materials with great precision. These photos show holes in both steel (left) and fused silica machined by trepanning with the output beam of a Spectra-Physics Hurricane laser. (Photo courtesy of Exitech Limited.)

cian. Indeed, these latest lasers are now seen as tools that can be applied to a host of interesting experiments and commercial applications, and even integrated into OEM equipment.


One of the leading applications for tunable ultrafast oscillators is multiphoton 3D imaging. Here the laser is tightly focused through a microscope into a sample. The peak power density at the beam waist is high enough to drive two- and three-photon absorption. Elsewhere in the sample, the power density is too low for these nonlinear effects. Unlike conventional confocal microscopy, this natural spatial discrimination obviates the need for a confocal pinhole for imaging the sample's fluorescence. A high-resolution three-dimensional image of the specimen is created by scanning the focused beam through the sample.

There are now many variants on this technique, including microscopy, multifocal excitation, and third-harmonic generation (THG) imaging of transparent membranes and interfaces. Coherent anti-Stokes Raman spectroscopy (CARS) is widely used to probe molecular vibration. Related techniques are also used to investigate semiconductor materials and integrated circuits, such as two-photon optical beam-induced current (OBIC) imaging, which can be used for IC failure analysis.

New materials processing methods using ultrafast lasers are showing promising results. The high peak power of a femtosecond Ti:sapphire amplifier induces material ablation through multiphoton ionization. Because of the short interaction time, heat diffusion from the laser's focus into the surrounding area is very limited, thereby minimizing collateral damage. Ultrafast materials processing allows the machining of subwavelength feature size, which is not feasible with the nanosecond lasers widely used in laser ablation. Furthermore, because the multiphoton interaction with the material does not require direct absorption, ultrafast amplifiers can be used to process a wide spectrum of materials (see Figure 3).

In conclusion, ultrafast lasers have transitioned from complex, sensitive systems used only under controlled laboratory conditions to compact, reliable turnkey products. They are suitable for a variety of industrial and OEM uses and will enable the emergence of new, exciting applications of ultrafast laser pulses.

For more information, contact Arnd Krueger of Spectra-Physics Lasers; (650) 966-5447; fax: (650) 969-3546; akrueger@splasers.com.



Focus

...on Solutions

Photon

provides fast,
accurate, and reliable
light measurements for
your analytical needs.

www.photon-inc.com
800.374.6866

PHOTON can help you solve your light measurement problems. Rapid characterization of laser diodes, fast collimation of fiber GRIN lenses, and accurate measurement of position and size of laser beams for scanning, printing, or telecom applications provide you with solutions to your photonics problems. Call PHOTON inc. today or visit our website to see how we can help you with your analyses.

PHOTON inc. Light Measurement Solutions

(408) 226-1000 or on the web at www.photon-inc.com.



PHOTON inc
Light Measurement Solutions

Commercial-Tolerance Superachromatic Near-IR Lens System

Diffraction-limited performance is obtained even when tolerances are relaxed somewhat.


NASA's Jet Propulsion Laboratory, Pasadena, California

The figure depicts the optical layout and meridional-plane ray-trace diagram of a four-element superachromatic near-infrared (IR) lens system. The system features a 30-mm-diameter entrance pupil, a focal-length-to-diameter ratio ($f/\#$ number) of 4, and a field of view with a half-cone-angle width of 0.25° .

This optical design incorporates three key features:

1. Spectral bandwidth greater than one octave in the near IR.
2. Exceptionally low design geometric and chromatic aberrations. [Design root-mean-square (rms) geometric spot diameter $<1\ \mu\text{m}$.]
3. Commercial-level optomechanical tolerances for diffraction-limited performance.

This system was designed to replace a prior lens system that could not satisfy the applicable performance requirements because its tolerances were too tight. This system offers diffraction-limited performance over the wavelength band from 0.8 to $1.7\ \mu\text{m}$, even when the component lenses are fabricated and assembled with commercial-level optomechanical tolerances.



This Four-Element Lens gives diffraction-limited performance at wavelengths from 0.8 to $1.7\ \mu\text{m}$.

cial-level optomechanical tolerances.

This work was done by Hiroshi Kadowaga of Caltech for NASA's Jet Propulsion Laboratory. For further information,

access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Physical Sciences category. NPO-21078

Software for Multidisciplinary Concurrent Optical Design

An optical designer can collaborate with other experts at different locations.

Marshall Space Flight Center, Alabama

The Integrated Optical Design Analyzer (IODA) is a computer program that facilitates multidisciplinary concurrent engineering of highly precise optical instruments. (IODA should not be confused with a multidisciplinary optical-system-analysis program, called "IMOS," that has been reported previously in NASA Tech Briefs.) IODA facilitates the exchange of data among analysts, designers, and other experts in different disciplines (e.g., optics, structural analysis, heat transfer, and electronics) needed for accurate design. IODA integrates the modeling efforts of a team of such experts and provides simplified means for performing design trade studies.

IODA enables an optical designer to utilize advanced technical models, developed by experts in engineering disci-

plines other than optics, to optimize the design of an optical instrument. The optical designer need not be familiar with the details of the models. IODA is compatible with the Internet and can therefore enable the optical designer to integrate design inputs from other experts on the design team performing analyses on different computers at different locations.

In a sense, IODA can bring the various models developed by other experts to the optical designer's home computer system for use in the design process. IODA provides the optical designer with a user-friendly graphical user interface that enables this designer to easily gain access to the various models developed by other experts and manipulate selected model characteristics that influence the performance of the

optical instrument to be designed. IODA then submits each model thus modified to its native computer system, receives the results of the computation on the modified model, and integrates the results with the detailed optical model for evaluation of the performance of the instrument.

This work was done by James D. Moore, Jr., and Charles P. DePlachett of SRS Technologies for Marshall Space Flight Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Information Sciences category, or contact SRS Technologies at (256) 971-7000.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Marshall Space Flight Center; (256) 544-0021. Refer to MFS-31452.

Multibeam Beacon Laser Assembly

Scintillation is reduced,
relative to a single-laser-beam
beacon.

*NASA's Jet Propulsion Laboratory,
Pasadena, California*

An optical assembly that combines the output of mutually incoherent lasers into a multibeam source for transmission into free space was designed, assembled, and tested. This design was motivated by the need for ground-based beacon sources required for broadcasting laser beams to spaceborne, satellite-to-ground free-space optical communications systems. These beacons will provide a pointing and tracking reference for the spaceborne optical communications system and be used to uplink commands and data to the spacecraft. The assembly was field tested by broadcasting the beams through a 0.6-m-aperture telescope over a mountaintop-to-mountaintop 45-km atmospheric path, with receiving sensors located at the other end. The key advantages of the design are the following:

- Reduction in atmospheric-turbulence-induced irradiance fluctuations, due to incoherent averaging of the overlapping beams in the far field, effectively eliminating or greatly reducing fades experienced by the spaceborne sensor.
- The distribution of the required optical power among multiple beams, which in some cases allows greater optical throughput without exceeding the damage threshold of optical surfaces and in other cases can help maintain eye-safe irradiance levels at the transmitting aperture.

The assembly (see figure) includes four multimode fiber-coupled (62.5- μ m core) laser diodes emitting at \sim 780 nm. The output of each laser is further split into two beams, using multimode fiber-optic splitters. The resulting outputs are each free-space coupled through 11-mm focal length collimators, resulting in an optical power of \sim 10 mW per beam. The collimated outputs are then aimed radially toward eight right-angled prisms (see figure) arranged symmetrically about the optical axis of an optical train consisting of a positive combining lens, followed by a negative doublet lens, and finally a field lens at the Coudé focus of the tele-

Lasiris™ Lasers

THE LASER SOURCE FOR MACHINE VISION, ALIGNMENT,
INDUSTRIAL INSPECTION AND R&D APPLICATIONS



SNF LASERS

- Uniform intensity profile
- Focusable
- ESD-protected
- Two-year warranty



MINI LASERS

- Compact and lightweight (10 mm diameter)
- Uniform intensity profile
- Focusable
- ESD-protected
- Two-year warranty



DLS AND DLSC LASERS

- Pointer beam
- Circular or elliptical beam
- Rugged, industrial-grade design
- Focusable
- Two-year warranty on elliptical beam, One-year on circular beam



MAGNUM LASERS

- High power line generator
- Uniform intensity profile
- Visible red up to 750 mW at 670 nm
- Infrared up to 4 W
- Pigtail also available



MFL MICRO-FOCUS LASERS

- Projects down to 5.5 μ m line thickness
- Ideal for precision inspection
- Uniform intensity profile
- Two-year warranty

Many
patterns
available



plus others

Customizing lasers for 10 years



StockerYale
Simply brilliant ideas™


Visit us at Assembly Tech, #15065 & Vision East, #622

275 Kesmark, D.D.O. (Montreal), Quebec H9B 3J1 Canada
Tel.: (514) 685-1005 Fax: (514) 685-3307

1-800-814-9552

www.stockeryale.com sales@lasiris.com

Copyright © 2001 StockerYale Inc. All rights reserved.



The schematic shows how **Eight Laser Beams** are copropagated through a single telescope aperture. The inset shows a photograph of the individual laser spots on the telescope primary mirror. The beams overlap in the far-field and noncoherent averaging causes the atmosphere-induced intensity fluctuations (scintillation) to be eliminated or greatly reduced.

scope. The telescope focal length used was 25 m. The entire optical assembly was chosen to provide a 123- μ rad full-width (100-percent energy) beam divergence that also corresponded to ~42 mm subaperture spots arranged symmetrically on the primary mirror of the transmitting telescope.

The inset accompanying figure shows beam spots on the primary mirror. The spot sizes varied between 33 and 48 mm, resulting in a range of beam divergences.

In field tests, the expected reduction in atmospheric-turbulence-induced irradiance fluctuations was ascertained by measuring the normalized variance of

the received power. Thus, an observed normalized variance range (also called scintillation index) of 0.8 to 1.3 observed for single beams was reduced to 0.13 to 0.55 upon combining all eight beams. The range of observed normalized variances was recorded over three separate campaigns conducted between June and September of 2000. The observed range of values is attributed to the variations in (1) the extent of beam overlap achieved and (2) variations in atmospheric turbulence over the period of measurements.

This work was done by Malcolm Wright, Abhijit Biswas, Norman Page, and Babak Sanii of Caltech for NASA's Jet Propul-

sion Laboratory. For further information, access the Technical Support Package (TSP) **free on-line at www.nasatech.com** under the Physical Sciences category.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to Intellectual Property group

JPL

Mail Stop 202-233

4800 Oak Grove Drive

Pasadena, CA 91109

(818) 354-2240

Refer to NPO-21119, volume and number of this NASA Tech Briefs issue, and the page number.

Improved Fiber-Pigtailed Non-Planar Ring Oscillator Laser

Parts are held in stainless-steel housings that are laser-welded together.

NASA's Jet Propulsion Laboratory, Pasadena, California

An improved non-planar ring oscillator (NPRO) of the fiber-pigtailed type has been developed. The improvements over prior lasers of this type lie in details of design and construction that are intended to enhance mechanical stability and thereby increase the stability of optical performance.

A description of the prior art is necessary to put the improvements in perspective: A basic NPRO laser includes a specially shaped laser crystal that serves as the laser cavity. The input and output optical paths in the crystal intersect at a common point on the surface of the crystal. The laser crystal is pumped by a laser diode, the output of which is coupled into the crystal via a cylindrical lens and a grating-index-of-refraction (GRIN) rod lens. Because of the monolithic nature of the laser cavity, the laser frequency is highly stable. Magnets

placed near the crystal ensure unidirectional lasing. A quarter-wave plate converts the elliptically polarized output laser beam into a linearly polarized beam, and an optical isolator blocks undesired feedback to the laser. In the case of an NPRO of the fiber-pigtailed type, some components for output coupling to an optical fiber are included in the laser package.

In a fiber-pigtailed NPRO laser package of prior design, all of the aforementioned optical components are mounted, variously, by use of solder, epoxy, or screws on two substrates. In turn, the two substrates are joined to each other by solder at three points. The combination of solder, epoxy, and screws is vulnerable to long-term mechanical instability that can degrade critical alignments of optical components, thereby reducing the net output power.

In the improved NPRO ring laser, the need for critical alignment of the laser-diode pump, lenses, and laser crystal is eliminated because the laser-diode light is coupled to the laser crystal via a bare optical fiber. The NPRO crystal, a heater plate, and a thermistor are placed inside a monolithic, 304L-stainless-steel monolithic block housing by use of a precise tool, then bonded together by use of solder; these are the only components bonded by solder. The other optical components are made with 304L-stainless-steel housings, most of which are laser-welded to the monolithic block housing, except one that is laser-welded to another housing that is, in turn, welded to the monolithic block housing, as described in the next paragraph. Laser welding of these parts is superior to soldering and epoxy bonding and is expected to con-



*Femtosecond
technology:*

**GOING
MOBILE**



**It's ultraEASY to carry these ultraCOMPACT
lasers to your ultraFAST applications!**


From the very beginning, IMRA America's vision has been focused on bringing ultrafast technology out of the laboratory and into the real world for industrial, instrumentation, and medical use. Based on revolutionary fiber laser technology, IMRA's ultrafast lasers are leading the way.

These highly stable, fully fiber-based lasers provide ultrashort pulses at emission wavelengths of 1560/780 nm (Er:fiber) or 1040/520 nm (Yb:fiber). All models are ultra-compact, truly turnkey, and are maintenance free. All these features – combined with very rugged design and no need for external cooling – enable very easy integration into your applications.

Engineered for commercial, OEM, and research applications, IMRA's ultrafast fiber lasers are setting the standard for reliability and long life.

At SPIE Photonics West 2001, IMRA's Wattlite 100 was awarded the "2000 Photonics Circle of Excellence" (Photonics Spectra) and IMRA's FCPA-2 laser was awarded the "2001 Commercial Technology Achievement Award" (Laser Focus World).

For Free Info Circle No. 473 or Enter No. 473 at www.nasatech.com/rs



Low Stress UV Curing

with the
Strength of Epoxy

High Performance Optical Adhesives

- ◆ Low Strain
- ◆ Low Stress
- ◆ High Strength
- ◆ Multiple Refractive Indexes
- ◆ Cure in Seconds
- ◆ No Secondary Cure

Order Your
Introductory Kit or
Optical Adhesives
On-Line Today!

[www.dymax.com/
products/optical/selector.htm](http://www.dymax.com/products/optical/selector.htm)



DYMAX®
Corporation
Adhesives and Adhesive Equipment
51 Greenwoods Road, Torrington, CT 06790

Phone: (860) 482-1010

tribute greater mechanical stability.

In the improved laser as in a typical prior NPRO ring laser, the laser beam is coupled to an output single-mode optical fiber via a GRIN rod lens, which, in this case, is held in a 304L-stainless-steel housing. A novel procedure for alignment of the GRIN rod lens is based on the observation that if the beam is centered on the input face of the lens, then the beam emerges perpendicularly to the output face of the lens. Once the GRIN rod lens has been aligned, its housing is laser-welded to the monolithic block hous-

ing. The output optical fiber is held in a ferrule in a housing that, in turn, is laser-welded to the housing of the GRIN rod lens housing. Because the axis of the fiber is held parallel with the output beam emerging from the GRIN rod lens, this arrangement helps to maximize output coupling.

This work was done by Duncan Liu of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Physical Sciences category. NPO-20885

Computing Atmospheric Profiles From Spectral Measurements

NASA's Jet Propulsion Laboratory, Pasadena, California

The SEASCRAPE computer program estimates the composition, temperature, and pressure of the atmosphere as a function of position by fitting remote-sounding spectroscopic data to a mathematical model of the transfer of radiation through the atmosphere. SEASCRAPE consists of two integrated parts: (1) A forward mathematical model that is used to generate synthetic spectra and (2) an inversion algorithm that is used to estimate parameters. The forward model evaluates the emission and absorption of radiation on a line-by-line basis; in its current form, it includes a one-dimensional (spherically symmetrical) atmospheric submodel with homogeneous layers of arbitrary thickness. A future version of the code will include a multidimensional submodel with inhomogeneous cells. The inversion algorithm uses a sequential parameter-estimation method known as the square-root in-

formation filter. The program incorporates some flexibility for handling large sets of data; the user can control the level of accuracy in the model equations for spectral lines to trade accuracy against speed. The program can run on a single processor but is written for a parallel-processing environment; if a parallel processor is available, it can simultaneously retrieve multiple distributions and/or estimate a single set of parameters from multiple spectra.

This program was written by Lawrence Sparks, James McComb, and John L. Faselow of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Physical Sciences category.

This software is available for commercial licensing. Please contact Don Hart of the California Institute of Technology at (818) 393-3425. Refer to NPO-19694.

Study of Stitching Errors in Shot-Shifted E-Beam Lithography

NASA's Jet Propulsion Laboratory, Pasadena, California

A report presents a study of the efficacy of shot shifting for reducing stitching errors in diffraction gratings made by electron-beam (E-beam) lithography. Stitching errors arise from fabricating a grating as a mosaic of smaller gratings by frequently translating the grating blank. (This is done be-

cause typically, the required size of a grating exceeds that of the field swept by the electron beam.) In shot shifting, each field is written at a fraction of the total electron dose and the stage is moved the same fraction of a field width before writing the next field, so that the averaging effect of shifted

multiple passes will suppress errors that arise from miscalibration between beam and translation-stage motions. In the study, a simplified linear model was used to describe the grating-writing process in the spatial-frequency domain. The origin and magnitude of stitching-error spatial-frequency sidebands was demonstrated. The effect of

the multipass writing was shown to be equivalent to that of a band-pass filter that selectively nulls nearby sidebands. It was shown that M -order multipass writing suppresses only the nearest $M-1$ sidebands, and that increasing M results in restrictions on the allowable grating periods.

This work was done by David Dougherty,


Paul Maker, and Richard Muller of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Stitching Error Reductions in Gratings by Shot-Shifted Electron Beam Lithography," access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Manufacturing/Fabrication category. NPO-21072

Magnetically Actuated Miniature Paraboloidal Mirrors With Variable Radii of Curvature

These are intended to supplant conventional components, reducing the bulkiness associated with focusing and zooming mechanisms.

NASA's Jet Propulsion Laboratory, Pasadena, California

Design and development of miniature paraboloidal mirrors that would be deflected magnetically to vary their radii of curvature (and thus their focal lengths) are under study. These mirrors, which belong to the class of microelectromechanical systems (MEMS), are used for compact, robust, focusing optics instruments and imaging systems, and are intended to supplant conventional adjustable optical components (including lenses, curved mirrors, and hinged flat mirrors) for reducing the bulkiness of the associated focusing and zooming mechanisms. The suggested device (see figure)



MEMS Magnetic Multifunctional Mirror system design illustrates the key components.

would include a thin paraboloidal diaphragm mounted at a short axial distance from a planar coil; the concave side of the diaphragm would serve as the mirror, and the convex side of the diaphragm would face the planar (concentric) coil and would be coated with a thin layer of magnetic material. Electron-beam binary-optics and low-pressure chemical vapor deposition (LPCVD) processes are used to form the paraboloidal concave surface, and the radio-frequency sputtering process is used to form the thin magnetic layer. At the same time, electroplating is used

for the fabrication of the planar coil on silicon wafer. The two wafers would then be bonded together to form the mirror-and-actuator unit.

This approach to miniaturization offers several potential advantages in that the magnetic actuation forms the integral part of the optical sensing mechanism (including beam focusing and steering), thus reducing the overall size of the mirror. Also, the actuation sensitivity would be higher due to the high

coefficient of elasticity of the magnetic layer; thus deflections attainable by the proposed approach would be higher than those attainable with electrostatic or piezoelectric actuations.

This work was done by Mary Boghosian and William Tang of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Mechanics category. NPO-20949

The ONLY Equation You Need

Include TE Cooler Functionality in Your TAS Thermal Model

- Simulate cooling and heating mode
- Control voltage or current
- Select a Melcor part number from the built-in library

HARVARD THERMAL, INC.
Tel: 978-772-3800
www.HarvardThermal.com

MELCOR CORP.
Tel: 609-393-4178
www.melcor.com

New Products

PRODUCT OF THE MONTH



Handheld Thermal Imaging Camera

Raytheon Commercial Infrared, Dallas, TX, says that its new PalmIR 250 handheld camera is the first digital thermal imaging camera with zoom capability. It produces detailed 320-x-240-pixel uncooled ferroelectric thermal images, and offers users a choice between the standard 75-mm f/1.0 lens package or other packages ranging from 25 to 150 mm. An electronic 2x zoom feature and many menu items, including video peaking, are also featured. The camera offers VCR-compatible video output through an RCA jack in the NTSC format, and PAL format for international use.

For Free Info Circle No. 765 or Enter No. 765 at www.nasatech.com/rs



DPSS Laser for Semiconductor Metrology

Specifically designed for integration into semiconductor metrology tools, the Azure™ continuous-wave diode-pumped deep ultraviolet laser from Coherent Laser Products, Santa Clara, CA, radiates at 266 nm. The company says that the Azure's near-diffraction-limited beam has the ultralow amplitude noise that is characteristic of single-frequency lasers. The Azure incorporates automatic control of all operating features, thus making it, according to Coherent, the first all-solid-state deep UV laser engineered to operate fully "hands off."

For Free Info Circle No. 767 or Enter No. 767 at www.nasatech.com/rs



Nitrogen Laser for Proteomic Research

Thermo Laser Science, Franklin, MA, announces the 337 Sx OEM nitrogen laser for matrix-assisted laser ionization-desorption time of flight (MALDI-TOF) mass spectrometric and other OEM applications. The laser is expected to play a role in proteomic research, the mapping of the proteome, the complement of human proteins. MALDI-TOF is used to identify proteins, playing a key role in research and drug discovery, as well as clinical diagnosis. The 337 Sx delivers pulsed radiation at 337 nm in the UV, with a repetition rate of up to 100 Hz.

For Free Info Circle No. 768 or Enter No. 768 at www.nasatech.com/rs



Deep Blue DPSS Laser

Melles Griot, Carlsbad, CA, is offering the 58 BTL series, a new single-frequency laser line that operates in

the deep blue spectral region. The output of these diode-pumped solid-state lasers is at 430 nm, with a single longitudinal mode. The company says that the lasers produce low-noise output with less than two percent peak-to-peak noise. Output powers are either 5 mW or 8 mW. The beam is nearly circular (1.25:1 aspect ratio), and linearly polarized, and has an M2 factor of less than 1.3.

For Free Info Circle No. 760 or Enter No. 760 at www.nasatech.com/rs




Laser Diode Life Test System

ThetaDelta Technologies, Lawrence, MA, introduces the LD 960-32 laser diode life test system. The device uses ThetaDelta's patented conductive thermal control technology instead of an air-based oven for precise control of diode temperature during the test. The system is capable of performing life tests on up to 960 diodes, with 30 diodes at 32 independent sites, and each individually driven by a microprocessor-controlled source. The LD 960-32 has a thermal capacity of up to 500 W per thermal site and a temperature range of 25-250 degrees C.


For Free Info Circle No. 769 or Enter No. 769 at www.nasatech.com/rs




PHOTOMETRY / RADIOMETRY



COLORIMETRY



POSITION SENSING



FIBER OPTICS

UDT. A Quarter Century Of Light Measurement Solutions.

For over 25 years, UDT has dominated the light measurement industry—specializing in test instrumentation for Photometry, Radiometry, Fiber Optics, Position Sensing and Colorimetry.

Perhaps UDT's success is based on its full line of versatile benchtop and handheld meters. Featuring interchangeable sensors and integrating spheres, and covering the UV to near-IR range.

Or UDT's state-of-the-art NIST traceable calibration facility, ensuring the highest levels of measurement accuracy.

Or UDT's technical expertise and outstanding service, providing you with the "can-do" customer support you demand.

Whatever the reason, UDT is ready to make your light measurement a total success.

For more information, call 1-800-891-2709. Or visit us at <http://www.udtinstruments.com>.

UDT INSTRUMENTS

727 S. Wolfe St., Baltimore, MD 21231 (800) 891-2709 Fax (410) 342-7028 Web: www.udtinstruments.com



STAY ON THE CUTTING EDGE

Renew or get your own copy of *NASA Tech Briefs*. You can qualify at our website:
www.nasatech.com/subscribe or Fax this form to **856-786-0861**

Please print

Reader ID Number 000 | | | | | | | |

Name _____

Title _____

Company _____

Address _____

City/St/Zip _____

Check one of the following:

☐ New Subscription

☐ Renewal

☐ Change of address

For Change of Address and/or Renewal you must provide the 11-digit Reader ID Number from your mailing label.

You can also mail this form to:

NASA Tech Briefs
P.O. Box 10523
Riverton, NJ 08076-9023

1 Do you wish to receive (continue to receive) *NASA Tech Briefs*? ☐ Yes ☐ No

Please check preferred format:

a. ☐ Print Version of *NASA Tech Briefs* only

b. ☐ Digital (PDF) Version of *NASA Tech Briefs* only

c. ☐ BOTH the Print AND Digital (PDF) Versions of *NASA Tech Briefs**

Signature _____ Date _____

Bus.Tel. No. _____ Bus.Fax No. _____

e-mail _____

* If you checked "c" above that you wish to receive BOTH the Print and Digital Versions of *NASA Tech Briefs*, there is a small service fee of \$2.00 per month (\$24 annually).

☐ My check (for \$24) is enclosed ☐ Bill me

☐ Charge to my: ☐ American Express ☐ Discover Card ☐ Master Card ☐ Visa

Card # _____ Exp. Date _____

Signature _____

2 Which of the following best describes your industry or service? (check one)

- E ☐ Electronics
- S ☐ Computers
- X ☐ Communications
- O ☐ Automotive
- T ☐ Transportation
- M ☐ Materials/Chemicals
- P ☐ Power/Energy
- B ☐ Bio/Medical
- J ☐ Consumer Product Manufacturing
- Q ☐ Industrial Machinery & Equip.
- A ☐ Aerospace
- G ☐ Government
- D ☐ Defense
- R ☐ Research Lab
- U ☐ University
- Z ☐ Other (specify): _____

3 Your engineering responsibility is: (check one)

- A ☐ Manage Engineering Department
- B ☐ Manage a Project Team
- C ☐ Manage a Project
- D ☐ Member of a Project Team
- E ☐ Other (specify) _____

4 Your job functions are: (please check all that apply)

- 10 ☐ Design & Development Engineering (Inc. applied R&D)
- 12 ☐ Testing & Quality Control
- 13 ☐ Manufacturing & Production
- 14 ☐ Engineering Management
- 16 ☐ General & Corporate Management
- 17 ☐ Basic R&D
- 15 ☐ Other (specify) _____

Write in the number of your principal job function _____

5 a. In which of the following categories do you recommend, specify, or authorize the purchase of products? (check all that apply)

- 01 ☐ Electronics
- 02 ☐ Photonics
- 03 ☐ Computers/Peripherals
- 04 ☐ Software
- 05 ☐ Mechanical Components
- 06 ☐ Materials
- 07 ☐ None of the above

5 b. Products you recommend, specify, or authorize for purchase: (check all that apply)

- 32 ☐ ICs & semiconductors
- 33 ☐ Connectors/interconnections/packaging/enclosures
- 02 ☐ Board-level products
- 18 ☐ Sensors/transducers/detectors
- 16 ☐ Data acquisition
- 19 ☐ Test & measurement instruments
- 34 ☐ Power supplies & batteries
- 35 ☐ PCs & laptops
- 06 ☐ Workstations
- 36 ☐ EDA/CAE software
- 37 ☐ CAD/CAM software
- 17 ☐ Imaging/video/cameras
- 38 ☐ Lasers & laser systems
- 39 ☐ Optics/optical components
- 40 ☐ Fiber optics
- 41 ☐ Optical design software
- 20 ☐ Motion control/positioning equipment
- 30 ☐ Fluid power and fluid handling devices
- 31 ☐ Power transmission/motors & drives
- 42 ☐ Rapid prototyping and tooling
- 13 ☐ Metals
- 28 ☐ Plastics & ceramics
- 27 ☐ Composites
- 43 ☐ Coatings
- 80 ☐ None of the above

6 How many engineers and scientists work at this address? (check one)

- A ☐ 1
- B ☐ 2-5
- C ☐ 6-19
- D ☐ 20-49
- E ☐ 50-99
- F ☐ 100-249
- G ☐ 250-499
- H ☐ 500-999
- J ☐ over 1000

7 To which of the following publications do you subscribe? (check all that apply)

- 01 ☐ Cadalyst
- 02 ☐ Cadence
- 03 ☐ Computer-Aided Engineering
- 05 ☐ Designfax
- 06 ☐ Design News
- 07 ☐ Desktop Engineering
- 08 ☐ EDN
- 09 ☐ Electronic Design
- 10 ☐ Machine Design
- 11 ☐ Mechanical Engineering
- 12 ☐ Product Design & Development
- 13 ☐ Sensors
- 14 ☐ Test & Measurement World
- 15 ☐ Laser Focus World
- 16 ☐ Photonics Spectra
- 17 ☐ None of the above

8 Would you like to receive a free e-mail newsletter from *NASA Tech Briefs*?

☐ Yes ☐ No

Your e-mail address _____

You may receive renewal reminders via e-mail.
Do you want to receive other business-to-business third party e-mail offers from *NASA Tech Briefs*?

☐ Yes ☐ No



Ultra-Efficient K_a -Band MMIC Power Amplifier

The design is a substantial advance in the state of the art.

Lyndon B. Johnson Space Center, Houston, Texas

A proposed monolithic microwave integrated circuit (MMIC) power amplifier has been designed to operate at frequencies around 28 GHz. According to a computer simulation of performance, this amplifier would operate at a power-added efficiency of more than 60 percent, which is more than 20 per-

cent above that of the prior state-of-the-art power amplifiers in this frequency range.

The design calls for a two-stage amplifier (see Figure 1), each stage containing a pair of pseudomorphic high-electron-mobility transistors (PHEMTs) in a push/pull configura-

tion. The PHEMTs would be biased for class-B or -C operation (conduction angle $\leq 180^\circ$ at the fundamental frequency). The push/pull configuration would be achieved by connecting the PHEMTs to each other and to the input and output terminals by embedding them in a coplanar waveguide network




Figure 1. High-Performance PHEMTs would be connected in an impedance-matching, wave-forming network to obtain high power efficiency.




Figure 2. The Ultra-Efficient MMIC Power Amplifier would contain two mirror-image, two-stage amplifiers connected in parallel to double the output power. The layout would be essentially planar, with no via holes (which would contribute parasitic inductances).



We packed
2
instruments
IN
so you can
CRANK
more product
OUT.



Keithley 2400 Series SourceMeters® have tightly integrated source and measure functions for big throughput advantages compared with multiple instrument systems. Designed for component production testing, these instruments combine a precision power supply and a highly repeatable 5½-digit DMM. In operation, the 2400 line can act as a V-Source, an I-Source, a V-Meter, an I-Meter, and an ohmmeter.

The high voltage Model 2410 and high current Model 2420 extend dynamic range capabilities while the optional contact check function quickly verifies good connection to the component under test. Accessories and switching systems let you easily build complete multipoint solutions.

For a detailed brochure with complete specs, or to talk to an Application Engineer, contact Keithley today at 1-888-534-8453 or www.keithley.com.

KEITHLEY


A GREATER MEASURE OF CONFIDENCE

2400 SERIES SPECIFICATIONS

DYNAMIC RANGE				MAX SYSTEM SPEEDS:	EXTERNAL INTERFACE:	1 YEAR BASIC ACCURACY: (5½-DIGIT RESOLUTION)	
2400/2400-C	2410/2410-C	2420/2420-C					
Voltage	±200V	±1100V	±60V	Pass/fail = 500µs	IEEE-488 (SCPI)	Volts	0.01%
Current	±1A/20V	±1A/20V	±3A/20V	To memory = 500µs	RS-232	Amps	0.02%
	±100mA/200V	±20mA/1100V	±1A/60V	To IEEE-488 = 1ms	Digital I/O	Ohms	0.04%
Power	22W	22W	66W	Range change = 13ms	Component handler		
				Contact check = 350µs			

The High-Performance Alternative™

Searching for realtime I/O?



Our PowerDAQ analog and digital I/O cards have drivers for:

• RTAI

• RTLinux

• QNX



Tel: (800) 829-4632 Web site: www.PowerDAQ.com

© 2001 United Electronic Industries, Inc. All product names listed are trademarks or trade names of their respective companies.

For Free Info Circle No. 412 or Enter No. 412 at www.nasatech.com/rs

of microstrip conductor lines and slots (see Figure 2). The network would include input and output balun transformers in the form of slot/line hybrid junctions.

Efficiency greater than the theoretical maximum of $\pi/4$ for classical class-B operation would be achieved by a wave-forming design concept directed toward minimizing the time integral of (drain voltage \times drain current) for a given output level at the fundamental frequency. This concept involves (1) exploiting the specific transfer characteristics of the high-performance PHEMTs, to obtain approximately square-wave drain-voltage waveforms, and (2) suppressing the harmonic contents of the square waves on the way to the output terminal to shape the final output waveform into a fundamental-frequency sinusoid. For this purpose, the waveguide network would include wave-forming subnetworks in which the harmonics would be terminated in reactive impedances.

This work was done by James M. Schellenberg of Schellenberg Associates for Johnson Space Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Components and Systems category. MSC-22503



SEALING SOLUTIONS

FOR ALL PROCESSING APPLICATIONS

AMERICAN VARISEAL • BUSAK + SHAMBAN • DOWTY ENGINEERED SEALS
FORSHEDA • PALMER-CHENARD • SILCOFAB • WILLS

- Turcon®, Turcite®, HiMod®, Zurcon®, Luytex®, Orkot® Marine and other high performance materials available
- Designs and materials for wide range of applications

Call: 1-800-767-3257

Fax: 1-303-469-4874

Polymer sealing solutions

2531 Bremer Drive, P.O. Box 176, Fort Wayne, IN 46801

Tel: (219) 748-5703 • Fax: (219) 749-4208

email: tcallison@tispp.com • web: www.polymersealing.com

A part of Smiths Group plc

Shamban
aerospace sealing systems

Busak+Shamban

Implementing Permutation Matrices by Use of Quantum Dots

Computing circuits could be simplified in that signal paths could be crossed.

*NASA's Jet Propulsion Laboratory,
Pasadena, California*

Integrated circuits of a proposed type based on quantum-dot cellular automata (QCA) would implement permutation matrices. These circuits would serve as prototype building blocks for demonstrating the feasibility of quantum-dot-based computing and for the further development of increasingly complex and increasingly capable quantum-dot-based computing circuits. Permutation matrices were chosen as part of the basis of this development because (1) they play a major role in fast transforms (e.g., the fast Fourier,

In package design there are two truths:
You either have **signal integrity problems**

...or you will.

Faster clock speeds and higher chip I/O densities demand complex IC packages.
Your package performance can significantly impact overall system performance.
Effective characterization of high speed packages requires the power and accuracy of full 3D parasitic extraction.

Rely on Ansoft's high performance
EDA solutions for your signal integrity
and EMI needs.

Contact us for a free evaluation at
412-261-3200 or info@ansoft.com.

**For Free Info Circle No. 520 or
Enter No. 520 at www.nasatech.com/rs**



*Unmatched accuracy and speed in
3D parasitic extraction.*

Face it




high performance EDA

www.ansoft.com

POSITIONING SLIDES AND X-Y TABLES

**Free Design
Guide of
modular
linear and
rotary
stages for
scanning,
indexing,
and
fixtures**



Call: 800 642-6446
www.velmex.com/b
in New York: 716 657-6151

For Free Info Circle No. 415 or
Enter No. 415 at www.nasatech.com/rs

ELECTRICAL CONDUCTIVE ADHESIVES

**Designed To Your
Specifications**

MASTER BOND EP76M EPOXY

- High conductivity
- Thermal shock resistant
- Durable, high strength bonds
- Water and chemical resistant
- Convenient packaging
- Long storage stability without refrigeration
- Repairability



Call or write:
Master Bond Inc.
154 Hobart Street
Hackensack, NJ 07601
201-343-8983
Master Bond Inc.
Adhesives, Sealants & Coatings
www.masterbond.com

For Free Info Circle No. 418 or
Enter No. 418 at www.nasatech.com/rs






Figure 1. Quantum-Dot Cellular Automata can be assembled into binary wires, which can cross with-out adverse effect.

$$Q_4 = \begin{pmatrix} 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \\ 1 & 0 & 0 & 0 \end{pmatrix}$$

**DOWNSHIFT PERMUTATION
MATRIX**



**SCHEMATIC DIAGRAM OF
PERMUTATION CIRCUIT**



**IMPLEMENTATION OF CIRCUIT IN
QUANTUM-DOT CELLULAR AUTOMATA**

Figure 2. A Simple QCA Circuit would implement the downshift permutation matrix Q_4 .

cosine, and Hartley transforms) that arise in the processing of signals and images and that are amenable to parallel computing by application-specific integrated circuits and (2) in principle, they could be implemented directly in the patterns of circuits of the proposed type.

As the development of very-large-scale integrated (VLSI) circuitry approaches the lower limits of practical feature sizes, QCA may offer an alternative that will enable further miniaturization. Of equal if not greater significance is the expectation that QCA may enable a great simplification of VLSI circuit patterns while affording capabilities that, heretofore, have not existed:

At present, wherever two wires in a VLSI circuit cross each other, the wires must not be in the same plane; that is, there must be a layer of electrical insulation between them (unless, of course, they are meant to be connected at the intersection). Much of the complexity and hence cost of VLSI design is associated with minimization of data routing and assignment of layers to minimize crossing of wires. The proposed circuits would enable one to take advantage of a unique feature of QCA; namely, the possibility of coplanar crossing of signal paths. This feature is what makes it possible, in principle, to implement various permutation matrices directly in coplanar patterns of quantum-dot circuit elements. Such a direct and compact implementation would be extremely costly if not impossible in conventional complementary metal oxide/semiconductor (CMOS) VLSI integrated circuitry.

A quantum-dot cellular automaton contains four quantum dots positioned at the corners of a square (see Figure 1). The cell contains two extra mobile electrons that can tunnel (in the quantum-mechanical sense) between neighboring dots. Tunneling out of the cell is assumed to be completely suppressed by the potential barriers between neighboring cells. The Coulomb repulsion between the two electrons tends to make them occupy antipodal dots in the cell. For an isolated cell, there are two energetically equivalent arrangements (denoted polarization states) of the extra electrons. The cell polarization is used to encode binary information.

The polarization of a nonisolated cell depends on interactions with neighboring cells. The interaction between cells is one of Coulomb repulsion only (no current flows between cells) and provides the basis for com-

puting with QCA. Theoretically, universal logic gates and binary wires could be constructed by assembling QCA of suitable design in suitable patterns. As to the possibility of coplanar crossing of signal paths without adverse effect, a complete theoretical explanation would exceed the space available for this article, but one can gain a partial, qualitative understanding from the illustration of crossed binary QCA wires in the bottom part of Figure 1.

One of the fundamental permutation matrices is the downshift permutation matrix, which is given by

$$Q_n(i, j) = \begin{cases} 1 & \text{if } j = i + 1 \pmod{n} \\ 0 & \text{otherwise} \end{cases}$$

where n is the number of elements to be permuted. Figure 2 illustrates a proposed QCA circuit that would implement the permutation matrix Q_4 .

This work was done by Amir Fijany, Nikzad Toomarian, and Matthew Spotnitz of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Components and Systems category. NPO-20801

HOW IN THE WORLD CAN YOU GET THE PERFECT SILICONE FOR YOUR SPECIFIC NEEDS, NO MATTER HOW LARGE OR SMALL . . .



Silicone just might be the most cost effective substance to fulfill your material needs. Better than whatever you're using or considering now. But first you have to . . . FIND THE RIGHT PARTNER TO

CREATE IT . . . Nusil Technology partners with you from the outset with on-site, in-person application engineering support. Working with you, Nusil creates silicone with the properties specific to your individual application. Of course you need to . . . **BE SURE THEY HAVE THE FACILITIES TO PRODUCE IT . . .** Nusil's facilities in North America and in Europe are spacious, ISO-9001 certified, state-of-the-art labs and processing plants. From small highly specialized orders, to large, off-the shelf 'standard' purchases, every batch is tested for quality and consistency. Nusil has . . . **THE EXPERTISE TO PRICE IT RIGHT . . .** As masters of silicone technology, Nusil has over 400 fully characterized silicone formulations. Customizing these 'standards' to provide or impart specific properties affords tremendous economies. **AND THE GLOBAL REPUTATION TO BACK IT UP . . .** Nusil's people are known for being hands-on, can-do professionals. From creating the aerospace industry's most complete line of silicones for space flight to being the healthcare industry's trusted resource, Nusil's reputation is second to none. At Nusil, we look forward to being your . . . Creative partners in a material world.

Nusil Technology
1050 Cindy Lane
Carpinteria, CA 93013
Telephone: (805) 684-8780
Fax: (805) 566-9905

Nusil Technology - Europe
Technical Services Center
2740 Route des crêtes
F-06560 Valbonne
Sophia Antipolis, FRANCE
Telephone +33 (0)4 92 96 93 31
Fax +33 (0)4 92 96 06 37



www.nusil.com/ntb

Software for Concurrent Development of Reusable Software

The YaM computer program provides a conceptual framework (including configuration management) and a set of software tools that support the concurrent development of reusable software by members of a team. YaM favors development of software in modules that can be assembled into packages and that, during development, serve collectively as the software analog of scaffolding that supports the development of other modules. YaM is written in Practical Extraction and Reporting Language (PERL) and is organized as a set of software utilities on top of the public-domain Concurrent Versioning System (CVS) software. Programmers can set up sandboxes for the development of modules and packages: all such development takes place on private CVS branches. High-level YaM commands support the setup, update, and release of modules and packages. Released and prebuilt versions of modules are available to all programmers on the team. Programmers can tailor the mixes of source and link modules for their sandboxes so that new sandboxes can be built up easily and quickly by pointing to previously released modules. All inter-module interfaces are publicly exported via links. A minimal, but uniform, convention is used for building modules.

This program was written by Abhinandan Jain and Jeffrey Biesiadecki of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Software category.

This software is available for commercial licensing. Please contact Don Hart of the California Institute of Technology at (818) 393-3425. Refer to NPO-21083.

Adaptive Problem Solving for Refining Control Strategy

A computer program implements an adaptive problem-solving (APS) algorithm for real-time development, refinement, and maintenance of the control strategy of an autonomous system that must operate in an environment about which little or no detailed information is available in advance. In the initial application for which the APS software was de-

veloped, the autonomous system would be an exploratory spacecraft that would feature a flexible control architecture and would be equipped with planning and scheduling software, which the APS software would complement. Given a generic set of control strategies, the APS software evaluates the strategies, performs "what-if" analyses, and utilizes statistical methods to rank each strategy or generate a more appropriate strategy in face of current information about the environment. In an iterative process of reinforcement learning, the highest-ranked strategies are passed back and forth between the APS algorithm and a search algorithm until a stopping criterion is satisfied. The user can specify the allowable error in the choice of the best control strategy. In this choice, other things being equal, strategies that can be evaluated accurately by use of fewer data points are favored over those for which more data points are needed.

This program was written by Steve Chien, Barbara Engelhardt, Darren Mutz, and Robert Sherwood of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Software category.

This software is available for commercial licensing. Please contact Don Hart of the California Institute of Technology at (818) 393-3425. Refer to NPO-21071.

Software for Automated Ortho-Rectification of SAR Images

The Automated SAR Ortho-rectification Software System enables users of synthetic-aperture-radar (SAR) data to form processed images that are free of the distortion caused by the SAR imaging geometry and topography. The software consists of four modules:

- FOCUSTM, a program for automated formation of SAR images;
- PHASETM, a complete package of software for interferometry;
- RadarStereoTM, a stereoscopic-image-processing program; and
- OrthoSARTM, a package of software for automated terrain and geometry correction and geocoding of SAR image data.

The disadvantage of SAR satellite data is that heretofore, images obtained by processing the data have been distorted

by the peculiar imaging geometry of SAR systems and by topography. However, SAR can provide information that is not obtainable by other imaging techniques. Because SAR is unaffected by clouds, digital elevation models (DEMs) can always be obtained by use of stereoscopic SAR. Furthermore, because SAR is a coherent imaging technique, accurate DEMs can be obtained by use of interferometry; these accurate topographic models can be used by OrthoSARTM to remove from imagery the distortion due to topography and imaging geometry.


Techniques for processing SAR image data, including techniques for processing data from stereoscopic and interferometric SAR, and techniques for ortho-rectification, existed before the development of the present software. However, there were no commercial-grade software systems for stereoscopy and ortho-rectification, and there was no integrated system that performed all of these functions.

The principal novelty of this software is the integration, into one easy-to-use package, of all of the software packages needed to process SAR data, including the processing to extract DEMs and the distortions due to imaging geometry and topography. The modules were designed and implemented in an object-oriented manner so that they can easily be upgraded as new techniques or new data sources become available. The software system was constructed to be operated through a JavaTM graphical user interface, which can also be easily changed and upgraded as needed.


FOCUSTM is fully automated, can be used to process data from all current SAR satellite missions, and can easily be modified to work with data from future missions. The software is able to take advantage of multi-processor architectures and is significantly faster than previously available software designed for the same purpose.

PHASETM can be used to create DEMs with vertical errors of less than a meter (depending on the quality of the data). In the displacement-map mode, PHASETM can be used to detect tectonic movement or subsidence of the ground to a sensitivity of less than a centimeter. While the software affords much flexibility in process control, including choice among different algorithms for several of the necessary tasks, it remains easy to use.

TIMELINE



Timeline's Event Editor provides click-and-drag points for easy curve definition as well as: 1 export functionality and a library manager; 2 Equation Editor for curve creation from designated inputs and 3 tabular entry for curve data.



The Event Viewer can plot multiple curves 4 together or 5 separately to show how multiple physical phenomena will simultaneously act on a model during analysis.

ALGOR's Timeline Event Manager graphical utility enables engineers to quickly and easily define and visualize time-based event curves for Mechanical Event Simulation, transient structural analysis and transient thermal analysis. It simplifies the setup of complex real-world events by simultaneously plotting curves for multiple analysis types to show exactly how variables will interact.

TIMELINE EVENT MANAGER FOR:

- Mechanical Event Simulation (MES)
- Transient Structural Analysis with Linear and Nonlinear Material Models
- Transient Thermal Analysis

- Graphical visualization of curve data helps engineers catch input errors during analysis setup.
- A built-in Equation Editor uses start times, end times and a library of supported functions to generate event curves.
- Built-in spreadsheet provides fast entry or modification of magnitude versus time data.
- Multiple load curves can be depicted on a single plot in the Event Viewer for multiphysics analyses.
- Points on any plot can be dynamically dragged to new locations.
- Timeline integrates with Microsoft applications including Excel.
- A library stores frequently referenced, user-defined curves.
- Timeline works within CAD for a value-added modeling solution.



Watch a free Internet Webcast at **eventmgr.ALGOR.com** to learn about the Timeline Event Manager for performing time-dependent and multiphysics analyses with ALGOR software.



ALGOR

When Engineering Has to be Right

US Phone: 1.412.967.2700
Europe (UK): 44.1784.442.246
Fax: 1.412.967.2781
California: 1.714.564.0844
eventmgr.algor.com
www.algor.com
E-mail: eventmgr@algor.com
150 Beta Drive,
Pittsburgh, PA 15238-2932 USA

A particular advantage of the software is that a crude DEM, perhaps one that was created with RadarStereo™, can be ingested to aid in the production of a more accurate, refined DEM.

RadarStereo™ is fully automated and uses novel techniques for the registration of images and generation of tie points. It also uses a novel algorithm for calculating stereoscopic solutions from radar parameters.

OrthoSAR™ is also fully automated, and, unlike other ortho-rectification software packages, it uses the radar equations to perform corrections. OrthoSAR™ can

optionally produce a mask of regions where imagery is compromised by layover or by shadow.

Significant interest in this integrated software system has been expressed by persons in universities and laboratories who wish to use the software to create DEMs to study motion and deformation of the ground. Some features of this software are also being marketed as part of a comprehensive radar ground station, with great success. OrthoSAR™ and RadarStereo™ are also available as parts of a popular geographic-information software system, ERDAS Imagine™.

This work was done by Grant R. Burkhart of Vexcel Corp. for Stennis Space Center. For further information, please contact Ron McCoy, (303) 444-0094, extension 229.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to


Vexcel Corporation

22477 55th Street

Suite 201

Boulder, CO 80301

Refer to SSC-00108, volume and number of this NASA Tech Briefs issue, and the page number.



This is rocket science...

So much rides on superior imaging.

True. EDT's data interface boards are exceptionally fast. But when years of planning and research are at stake – not to mention millions of dollars – speed is only half the equation. Scientific and technological breakthroughs demand dependable performance.

EDT masters the challenge with products featuring simple and practical designs. Built to tough military specifications, they handle the most advanced camera

specifications. And our latest models come complete with PCI/RCI fiber-optic interface for flawless image transfer and total flexibility in locating your computer.

It isn't rocket science when it comes to selecting the best interface cards. Contact EDT today and see how our products provide the extraordinary performance your work demands... with engineering customer-support that ensures seamless integration of your system.



Engineering Design Team, Inc.

1100 NW Compton Dr., Suite 306, Beaverton, Oregon 97006

Phone: 1-800-435-4320 • Fax: (503) 690-1243

email: info@edt.com • www.edt.com

Advanced Software for Two-Phase Thermohydraulic Systems

Recent improvements in the SINDA/FLUINT computer program have made the program into a highly capable, commercially viable software product for general mathematical modeling of thermohydraulic systems. Versions of SINDA/FLUINT have been described in a number of previous *NASA Tech Briefs* articles. To recapitulate: SINDA/FLUINT is the NASA standard software system for computational simulation of interacting thermal and fluid effects in arbitrary flow networks. As its name suggests, SINDA/FLUINT is an integral combination of two subprograms: Systems Improved Numerical Differencing Analyzer (SINDA) program is a software system for solving lumped-parameter representations of physical problems governed by diffusion-type equations. The Fluid Integrator (FLUINT) program is an advanced one-dimensional fluid-analysis program that solves equations of arbitrary fluid-flow networks. Working fluids that can be modeled in SINDA/FLUINT include single-phase vapors, single-phase liquids, and two-phase fluids.

The recent improvements in SINDA/FLUINT fall into two categories. In the first category is the addition of capabilities for advanced mathematical modeling of two-phase flows of types that are of particular relevance to thermal-control, propulsion, environmental-control, and fire-suppressant-delivery systems. Phenomena that could not previously be modeled but can now be modeled include the dissolution and evolution of noncondensable gases and the effects of thermal equilibrium between the liquid phase and the vapor/gas phase in a pipe. Specific features added to the program include one that defines the equilibrium dissolution of a solvent/solute pair, mass-transfer correlations based on flow regime, a feature for tracking of solutes and rates of evolution

and dissolution in both tank and junction network elements, interface network elements to provide for subdivision of control volumes, twinned tanks, twinned ties, and superpaths.

The second category of improvements comprises miscellaneous additions that provide enhanced capabilities for posing and solving problems. The additions include (1) prepackaged software components that provide options for handling ducts with axially varying flow areas, (2) software components that provide double-precision solution options, (3) software components that implement some optional solution techniques, and (4) a database subprogram that manages complex relationships among inputs and outputs and represents these relationships in a spreadsheet. The latter improvement relieves the user of some programming tasks, making parametric analyses easy and making the program easier to learn and to apply to complex problems.

This program was written by Brent Cullimore, David A. Johnson, and Steven G. Ring of Cullimore and Ring Technologies, Inc., for Johnson Space Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Software category.
MSC-23052/58

Test Automation Software for AI Planning Software

This test automation software reduces the burden of testing artificial-intelligence (AI) planning software written in the Heuristic Scheduling Testbed System (HSTS) [a software architecture for planning and scheduling]. It automates what would otherwise be the labor intensive and infeasibly time-consuming process of determining whether the plans produced by the planner in response to test case inputs are consistent with the specifications. Automating this process is particularly important for verifying planning systems due to the large numbers of test cases and the complexity of both the plans and the specifications. This program automatically translates constraints written in the HSTS constraint language into automatically executable queries in a database language. As a result, plans generated by HSTS planning software can be automatically verified for satisfaction of all the constraints. Moreover, the constraints can be validated by manually expressing their intents directly in the database query language, then plans generated by the HSTS planning software can be automatically verified through the responses to those queries. Redundant information contained within plans is automatically cross-checked, thus increasing confidence in the correct operation of the planning software and of the plan-checkers themselves. This program generates a pass/fail report of the responses of the planning software, as well as detailed and summary reports as to how each constraint was or was not satisfied. It also generates simple metrics concerning the constraints and requirements exercised in testing.

This program was written by Benjamin Smith and Martin Feather of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Software category

This software is available for commercial licensing. Please contact Don Hart of the California Institute of Technology at (818) 393-3425. Refer to NPO-21118.

Software for Simulation of 3D, Three-Phase Combusting Flow

A computational fluid dynamics (CFD) code has been developed to enable simulation of spray combustion near the fuel injectors in a liquid-fueled rocket engine. This code reflects the three-dimensional (3D), multiphase nature of the flow field in




Serious FEA

Structural failure is simply unacceptable when you're pulling 8G's at 600 mph. Or Depending on a spinal implant. Or an automotive fuel tank. Or the mast of an America's Cup contender. This is why developers of the most critical structures depend on **NE/Nastran** for FEA analysis.

Along with uncompromising accuracy, **NE/Nastran** is one of the most complete, easiest-to-learn-and-use FEA packages available. And it's yours for 1/3 to 1/10 the price of comparable software.

Free Demo. We're so sure that you'll see the value in **NE/Nastran** that we want you to use a demo version for free.

It runs on Windows 95/98/NT4.0/2000 with Unix and Linux versions available soon. Visit our web site to learn more about this serious FEA, and download your free evaluation copy.



Upgraded F-5E fighter avionics bay, radar support structure, and wing analyzed using **NE/Nastran**.



Noran Engineering, Inc.
www.NENastran.com
Toll Free: 877-NENastran

© 2001, Noran Engineering, Inc. NE, NE/ and NEI logo are registered trademarks of Noran Engineering, Inc. NASTRAN is a registered trademark of the National Aeronautics and Space Administration. Windows is a registered trademark of Microsoft Corporation.

**For Free Info Circle No. 422 or
Enter No. 422 at www.nasatech.com/rs**

a rocket engine and is capable of modeling even a flow field as complex as one that results from the use of impingement injectors. Unlike prior spray-combustion codes that emphasize physical constraints at the expense of geometric ones, this code implements a compromise between physical and geometric constraints in order to enable analysis and comparison of the performances of alternative engine designs that involve different injector geometries. In particular, this code was constructed to enable prediction of the interactive effects of injector-element impingement angles and impingement points, momenta of individual orifice flows, and the resulting combusting flow.

This computer program includes finite-difference Navier-Stokes CFD subprograms for mathematical modeling of spray combustion from several different perspectives. Two of the subprograms implement models of heterogeneous spray combustion: One of these models, denoted a volume-of-fluid (VOF) model, represents a liquid core of coaxial and impinging jets and the atomization and vaporization thereof. The other, denoted a blob model, represents injected streams as a cloud of droplets that are initially of the size of the injector orifice and that subse-

quently exhibit particle interaction, vaporization, and combustion. These models are computationally intensive, as they must be to account accurately for the complex combustion and other physics that one seeks to predict.

One of the subprograms implements a model of homogeneous spray combustion, representing the flow as a continuum of multiphase, multicomponent fluids that move without thermal or velocity lags among the phases. This model enables relatively fast computation. To enable the representation of subcritical and supercritical liquid and vapor flows, this subprogram uses a real-fluid model that comprises thermal and caloric equations of state. The great advantage of this real-fluid model is that it is valid over a wide range of pressures and temperatures, making it unnecessary to provide (as in prior approaches) a submodel to represent the effects of surface tension in the subcritical regime; this is important because liquid-fuel rocket engines usually operate at supercritical pressures (for which surface tensions are zero), making it counterproductive to continue to adapt low-pressure spray-combustion models.

Because some rocket engines utilize RP-1 (essentially, kerosine) and liquid

oxygen as propellants, the homogeneous-spray subprogram includes a simplified hydrocarbon-combustion model for use in simulations of 3D, multiphase flow. This model does not identify drops or their distribution, but it does enable accurate prediction of film coolant flow and of recirculating flow along the injector face and into an acoustic cavity. Soot is represented as a third phase that behaves as a dense gas. The resolution of the flow field of the reacting, vaporizing propellants predicted by this spray model exceeds that of any other published model developed for the same purpose.

The heterogeneous VOF and blob spray-combustion subprograms include provisions for Euler-Lagrange particle tracking to account for thermal and velocity lag of droplets. These subprograms also use the real-fluid equations of state to calculate thermodynamic properties of fluids.

This program was written by R. C. Farmer and G. C. Cheng of SECA, Inc., and Y. S. Chen of Engineering Sciences, Inc., for Marshall Space Flight Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Software category. MFS-31599

NASA Chooses Top Software of the Year

Computer programs that reduce aircraft engine analysis time and improve the study of fluid dynamics in rocket engines are NASA's 2001 Software of the Year winners. Since 1994, NASA's Inventions and Contributions Board and the NASA Chief Information Officer have selected the top software programs submitted from a field of government agencies, corporations, and universities.

Visit <http://icb.nasa.gov/Soy2001> for more information on the winners.

Faster, Better, Easier

Developed at NASA's Glenn Research Center in Cleveland, OH, the Numerical Propulsion System Simulation (NPSS) software is part of an effort by NASA to develop an integrated collection of software programs for the analysis and design of aircraft engines and space transportation components. NPSS dramatically reduces the time, effort, and expense involved in designing and testing jet engines by generating sophisticated computer simulations of an aerospace object or system. Engineers can

then "test" design options without doing costly and time-consuming real-world tests.

Using the software, engineers can analyze different parts of an engine simultaneously, perform different types of analyses simultaneously, and perform those analyses faster, better, and at a lower cost.


NPSS currently is in use by aircraft and aircraft engine developers, and has even been used to model the turbofan engine for a supersonic passenger jet. In the future, it should cut new

engine development time in half, from ten years to five years.

A Dynamic Program

A team led by Alok Majumdar of Marshall Space Flight Center in Huntsville, AL, developed the Generalized Fluid System Simulation Program (GFSSP) for analyzing steady state or transient flows in complex networks, specifically the internal secondary flows in rocket engine turbopumps. Before GFSSP, there was no generalized code capable of such analysis. The program handles both incompressible (liquid) and compressible (gas) flow systems, or a combination of both.

The software has been used to support the space shuttle main engine turbopump secondary flow circuit analysis, and the International Space Station's Environmental Control and Life Support System design. It has the potential to make a significant impact in any industry that must analyze fluid flow processes, including petroleum, power, automobile, heating and air conditioning, and chemical.



Some codes developed through NPSS analyze individual engine components. Shown here is a simulation of the Energy Efficient Engine's combustor using ALLSPD-3D, a NASA Glenn-developed combustor code.

Compact PCI DaqBoards



IOtech introduces a family of six new Compact PCI data acquisition boards, featuring a 16-bit/200 KHz A/D, quad 16-bit/100 KHz D/A's, 40 digital I/O, and six counter/timers. Unlike other boards, the new **DaqBoard/2000c** boards feature synchronicity amongst all input and output functions, allowing simultaneous acquisition of analog, digital, and frequency data concurrent with output of analog waveforms and digital patterns. A full-suite of isolated signal conditioning and expansion options is also available.

www.iotech.com/daqboard2000/4


Active X/COM Daq Software



DaqCOM™ is a suite of ActiveX/COM tools for IOtech's family of plug-in and portable data acquisition devices. DaqCOM provides a powerful set of tools for developing custom data acquisition applications under Windows® for C++ and Visual Basic. **DaqCOM/Net** enables distributed data acquisition amongst any number of network-enabled PCs with IOtech data acquisition hardware attached.

www.iotech.com/daqcom/4

PCI Data Acquisition



IOtech introduces a family of six new low-cost PCI data acquisition boards, featuring a 16 bit/200 KHz A/D, quad 16 bit/100 KHz D/A's, 40 digital I/O, and 6 counter/timers. Unlike other boards, the new **DaqBoard/2000™** boards feature synchronicity amongst all input and output functions, allowing simultaneous acquisition of analog and digital data, with output of analog waveforms and digital patterns. A full-suite of signal conditioning and expansion options is also available. www.iotech.com/daqboard2000/4

Distributed Ethernet Data Logging

IOtech's new Ethernet-based **ScanWare™** family of hardware & software offers a cost-effective, user-configurable solution for distributed data logging applications. (To learn about real-time applications using Ethernet, visit www.iotech.com/ethernet/4).

ScanWare includes our new **PointScan™** modules, offering **built-in Ethernet** connectivity, low-cost per channel, & 16-bit accuracy. Over 30 PointScan modules are available, ranging from multi-function volts/thermocouple/bridge modules, to high-isolation discrete I/O modules.

PointScan™



Over 30 modules available


NetScan™



For applications with high channel concentrations, our **MultiScan™** & **NetScan™** data loggers offer low-cost, isolated, high-accuracy solutions, with channel counts scalable from 16 to nearly 1000 channels.

We've partnered with **Citect®** software to provide a user-configurable, highly-scalable software solution, with support for our **Scan** products, as well as support for over 200 hardware solutions from other vendors. Citect is currently being used in 1000's of large- & small-scale data acquisition applications throughout the world. Our global network of systems integrators is available to help with your custom application.

Citect™



To discuss your application with our sales department, call 1.888.583.3174.

www.iotech.com/scanware/4



IOtech Inc
25971 Cannon Rd
Cleveland OH 44146
Tel 1.440.439.4091
Fax 1.440.439.4093
www.iotech.com
sales@iotech.com



PortableWaveform Measurements

Attach the WaveBook/516™ to your notebook PC for portable, 16-bit waveform measurements up to 1 Msamples/s. Start with eight built-in channels, and easily expand up to 72, including vehicle network measurements (J1850, ISO 9141, CAN, etc.), ICP®-style accelerometers, strain gages, position encoders, thermocouples and more.



WaveBook/516™

- External clock input
- Multichannel analog triggering
- Digital-pattern triggering
- Pulse-amplitude & pulse-width triggering
- Pre- & post-trigger modes
- In-vehicle bus measurement option

Included *Out-of-the-Box™ WaveView™* software converts your PC and the WaveBook/516 into a compact, multichannel waveform analyzer, streaming data to your PC's hard drive in real time. Also included are Windows® 95/98/2000/NT drivers, LabVIEW® and DASyLab® support, and file support for MATLAB™, Excel™, and many more.



IOtech has been the undisputed leader in portable, notebook PC-based data acquisition for nearly a decade. For a demo or 30-day evaluation, contact our sales department at 1.888.583.3174.

www.iotech.com/wavebook/4


IOtech Inc
25971 Cannon Rd
Cleveland OH 44146
Tel 1.440.439.4091
Fax 1.440.439.4093
www.iotech.com
sales@iotech.com



©Copyright 2001, IOtech, Inc. Out-of-the-Box, WaveBook/516, WavePort, & WaveView are trademarks of IOtech, Inc. ICP is a registered trademark of PCB Piezotronics. All others are trademarks or registered trademarks of their respective holders. For a complete listing of IOtech worldwide sales offices, see www.iotech.com/sales/4


ADVERTISEMENT

USB Data Acquisition



The new ZonicBook™ from IOtech is a portable, multi-channel vibration analyzer, available in 4-, 8-, or 16-channel models. The ZonicBook features built-in ICP® biasing for accelerometers, 16-bit A/D converters for each channel, and PC-Card interface for notebook PCs. eZ-Analyst™ software is included with the ZonicBook, providing gap-free acquisition and real-time display and analysis of acquired waveforms, in both time-domain and frequency-domain. www.iotech.com/zonic/4

Stand Alone Data Acquisition



The LogBook360™ from IOtech provides stand-alone data acquisition capability, using removable PC-Card memory for program and acquired data storage. Unique to the LogBook is the ability to acquire dynamic data, such as sound and vibration, along with voltage, temperature and frequency measurements. Modem support for remote cellular phone access, GPS support for position logging, and vehicle bus (see below) are also supported.

www.iotech.com/logbook/4

Vehicle Bus Data Acquisition



The new DBK70™ acquires vehicle parameters from up to 4 different vehicle networks simultaneously, including J1850, J1939, ISO 9141, and CAN. The DBK70 attaches to IOtech's portable DaqBook, WaveBook, and plug-in DaqBoard data acquisition devices, and is also capable of working with any analog measurement device. Unique to the DBK70 is the ability to graphically view acquired vehicle network parameters simultaneously with acquired analog and digital data. www.iotech.com/dbk70/4

Flex Wedges

Brakes and clutches could perform more reliably and predictably.

Goddard Space Flight Center, Greenbelt, Maryland

Flex wedges have been proposed for use in brakes and clutches like those in which, heretofore, basic wedges have been used. Flex wedges (see Figure 1) offer advantages of superior braking and clutching performance and less weight, relative to basic wedges.

The upper part of the figure depicts part of a typical brake or clutch that contains a basic wedge that mates with the side walls of a groove in a fixture. To obtain braking or clutching action, one pushes the wedge into the groove to obtain friction between the wedge and the fixture. A large frictional force is obtained by utilizing the mechanical advantage afforded by the wedge/groove geometry to multiply the perpendicular-to-the-surface contact force between the wedge and the fixture.

The mechanical advantage, and thus the effectiveness of braking or clutching in

the case of a basic wedge, is greater for wedge faces and groove walls that are more nearly parallel. Unfortunately when these contact surfaces are fabricated more nearly parallel, there is a greater tendency for a wedge to become jammed in a fixture once it has been pushed in; as a result, the force needed to remove the wedge from contact with the fixture is larger and less predictable, and there is an increasing tendency for unjamming action to jerk the brake or clutch mechanism.

The lower part of the figure depicts part of a typical brake or clutch similar to that of the upper part of the figure, except for the use of a flex wedge instead of a basic wedge. This mechanism functions similarly to the basic-wedge mechanism, except that it offers enhanced holding performance, reliability, and predictability. Less actuation force is needed for

both insertion and removal of the wedge; even unjamming requires little force and hence gives rise to little or no jerk.

The flex wedge (see Figure 2) is regarded as having been fabricated by machining away most of the material from a basic wedge. The flex wedge includes wedge shoes connected, via shoe flexures, to a wedge compliance flexure. The wedge shoes mate with the side walls of the groove in the fixture, in the same manner as that of the basic wedge. The wedge compliance flexure is made flexible with respect to motion in the x direction to accommodating small motions needed to align the wedge shoes with the side walls of the groove in the fixture. However, the wedge compliance fixture is stiff along the axis of insertion and removal (the y axis) and along the axis of the relative motion (the z axis) that the




Figure 1. These Parts of a Brake or Clutch generate large contact forces between the wedge and groove surfaces in order to generate large friction forces to resist relative motion in the z direction. The flex wedge offers advantages over the basic wedge, as described in the text.



Combine the SBC6711 with multiple OMNIBUS modules to custom tailor your embedded solution!

	Analog Input	Analog Output
A4D4	4 Ch. 16-bit 0-200 kHz	4 Ch. 16-bit 0-200 kHz
A4D1	4 Ch. 14-bit 0-10 MHz	1 Ch. 14-bit 0-10 MHz
A16D2	16 Ch. 16-bit 0-195 kHz	
AD16	2 Ch. 12-bit 0-40 MHz	
AD40	4 Ch. 16-bit 0-2.5 MHz	
MOT		4 Ch. 16-bit 0-200 kHz
RF	2 Ch. 12-bit 0-65 MHz	2 Ch. 12-bit 0-65 MHz
SD	4 Ch. 24-bit 2-96 kHz	4 Ch. 24-bit 30-96 kHz
Servo16	16 Ch. 16-bit 0-100 kHz	16 Ch. 16-bit 0-100 kHz

OMNIBUS Modules



www.innovative-dsp.com
805.520.3300 phone • 805.579.1730 fax

Looking for Mr. Right?

Single Board Computer, strong, independent, flexible, green, 160mm x 100mm, USB, 150 MHz DSP, 2 OMNIBUS sites seeks long term relationship with intelligent end-user. Call anytime 805-520-3300.

Features

- ▶ 150 MHz TMS320C6711 floating-point DSP
- ▶ Operates independently from a host PC
- ▶ Plug-n-Play USB interface
- ▶ Dual OMNIBUS I/O Module sites
- ▶ Comprehensive C/C++ cross development tools & servo algorithm templates
- ▶ Windows 9x/NT/2000 drivers

Applications

- ▶ Noise Cancellation
- ▶ Embedded Control
- ▶ Wide-Channel Audio
- ▶ Precision Motion Control

SBC6711



Call for special OEM pricing and custom configuration!

brake or clutch was meant to resist when engaged.

The shoe flexures are perpendicular to the wedge shoes, affording an additional mechanical advantage (beyond that of the basic wedge geometry) for both engagement and disengagement of the brake or clutch: Once the flex wedge was inserted as far as it could go, further pushing of the flex wedge into the fixture gives rise to a slight bend of the shoe flexures with consequent pushing of the wedge shoes into tighter contact with the side walls of the groove. Hence, the perpendicular-to-the-surface contact force (and thus the de-

sired frictional braking or clutching force) for a given insertion force is greater than that for a basic wedge.

Even if the wedge shoes were pushed very tightly against the side walls, as described in the preceding paragraph, disengagement does not depend on the application of a large unjamming force. This is because pulling on the wedge compliance flexure in an effort to disengage the brake or clutch would first cause the shoe flexures to bend oppositely to the way they bent during insertion and this bend pulls the shoes out of contact with the side walls of the groove. This dis-



Figure 2. A photograph of the Flex Wedge shows the key components.

THE ONLY WAY TO SEAL IT SHUT IS TO PNEUMA-SEAL IT


Pneuma-Seal® inflatable gaskets are pressurized with air to fill the uneven gaps between surfaces. When deflated, they quickly retract preventing interference when opening and closing a door or cover. Pneuma-Seal is an effective barrier against pressure differentials, and seals out water, dust, gas, chemicals, noise and other contaminants. Typical applications include:

- Processing Equipment: chemical, food, textile, pharmaceuticals, dryers, ovens and where rapid sealing and unsealing are required.
- Semiconductor Fabrication
- Pollution Control
- Laboratory Facilities
- Transportation
- Construction

Pneuma-Seal is particularly suitable in:

- Large enclosures where it is uneconomical to machine the entire sealing surface.
- Uneven fabrications where traditional compression gaskets or latches are ineffective.
- Horizontal or vertical sliding doors or covers that tend to drag on and abrade conventional seals.
- Hinged doors where flush thresholds are required.

For complete details on profiles, configurations, and applications, visit our website at: **www.presray.com**



PNEUMA-SEAL®
manufactured by
PRESRAY

Presray Corporation
159 Charles Colman Blvd. • Pawling, NY 12564 USA
(845) 855-1220 • Fax: (845) 855-1139
West Coast: (949) 475-9842 • e-mail: info@presray.com

engagement action is characterized by a mechanical advantage that depends only on geometry (and not on the coefficient of friction). Hence, the force needed for extraction or disengagement would be small and predictable.

The shoe flexures are made thin and flexible to allow bending in the parallel-to-the-shoe directions, yet stiff as needed in the perpendicular-to-the-shoe directions. They are also made long in the z direction, as needed for strength and rigidity in holding against the relative motion that the brake or clutch is meant to resist when engaged.

This work was done by John M. Vranish of Goddard Space Flight Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Mechanics category.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Goddard Space Flight Center; (301) 286-7351. Refer to GSC-14006.

Heat-Shield Panels in a 2D Shingling Arrangement

Adjacent panels are slid aside to make room for insertion or removal.

*Marshall Space Flight Center,
Alabama*

Figure 1 depicts mockups of lightweight metal heat-shield panels that have been proposed for use on spacecraft of the reusable-launch-vehicle type. These panels are designed for simplicity of insertion and removal. The design could also be adapted to both insulating and noninsulating panels in nonspacecraft applications.




Figure 1. **Panels Overlap** and thus interlock in a two-dimensional shingle-like pattern. However, the interlock can be removed locally, to enable insertion or removal of a given panel, by simply sliding the overlapping parts of two adjacent panels out of the way.

Each panel includes a thin front (outer) face sheet bonded to a thicker insulating block. The insulating block occupies an area slightly smaller than that of the face sheet and is located off center on the rear (inside) surface of the face sheet in such a way as to leave flange areas on two sides of the face sheet.

The panels are installed on stand-off brackets on a framework, as shown in Figure 2. When installation is complete, the two flanges of each panel overlap the nonflanged edge areas of two adjacent panels. In other words, the panels are overlapped in a two-dimensional (2D) generalization of the common shingling pattern.




Figure 2. **Panels Are Supported** on a framework in such a way that they can be slid aside to insert or remove one panel without having to insert or remove others at the same time.

The overlap creates an interlock that, in the case of a simple shingling arrangement, would make it necessary to remove many other panels in order to replace a given panel. However, unlike a simple shingling arrangement, this design provides for the removal of any given single panel without having to remove other panels; the panels, framework, and stand-off brackets are configured so that the panels can slide over each other in the front-surface plane. All one need do to remove the interlock from a given panel (e.g., the middle panel in Figure 1) is to push the overlapping adjacent panels to slide their flanges off the given panel.

This work was done by Dalton Nguyen of Marshall Space Flight Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Mechanics category. MFS-31266

Single-Board Computers with Ethernet!



BL2010 shown
3.43" x 4.15" x .82"
(87 x 105 x 21 mm)

\$199 qty. 1

\$159 without Ethernet

- Simplify your next embedded design project with Z-World single-board computers. Value-priced with the features you need, these boards are programmed with industry-proven Dynamic C[®] (TCP/IP source provided royalty free). Our hardware and software integration saves you development time and cost.

Our product line features:

- 10Base-T Ethernet
- Up to 168 digital I/O
- A/D and D/A
- Up to 4 serial ports
- Up to 512K SRAM/Flash
- Battery-backed time/date clock
- Operator interfaces/core modules
- Program/debug via the Internet

Order Z-World products online @

www.zworld.com

or call toll-free

888.362.3387




2900 Spafford Street • Davis, CA 95616

T: 530.757.3737 • F: 530.753.5141 • E: zworld@zworld.com

For Free Info Circle No. 426 or
Enter No. 426 at www.nasatech.com/rs

Heating a medical device? We have the perfect prescription!

Heaterstat[™] sensorless controller



Stick-on simplicity...
Sophisticated thermal control

Flexible Thermofoil[™] heaters are the sure cure for chronic heating ailments: Easy to apply as a flexible bandage, yet capable of uniform, efficient heat • Proven performance in diagnostic devices, catheters, fluid warming, respirators

Etched-foil element with chemical-resistant polyimide insulation • Drop-in-place subassemblies with integral sensors, connectors, metalwork, flex-circuitry • Optional factory mounting • Full range of temperature controllers

MINCO

Minco Products, Inc.

7300 Commerce Lane / Minneapolis, MN 55432-3177 U.S.A.
Tel: (763) 571-3121 / Fax: (763) 571-0927 / www.minco.com

For Free Info Circle No. 427 or
Enter No. 427 at www.nasatech.com/rs



Improved Automated System for Transferring Liquid Helium


Consumption of liquid helium would be reduced by optimizing use of vapor for precooling.

Goddard Space Flight Center, Greenbelt, Maryland

An improved automated system for transferring liquid helium from a supply tank to an end-use cryostat has been proposed. Like automated systems developed previously for the same purpose, this system would reduce the time that must be spent by technicians in replenishing cryostats in equipment required to operate for times longer than cryostat holding times. However, relative to prior automated liquid-helium-transfer systems, this system would operate in a more nearly optimum manner so as to reduce the consumption of liquid helium. Examples of equipment with which this system could be used include apparatuses for long-duration scientific experiments and large cooled electromagnets in medical imaging systems.

The system would control the flow of liquid helium through a transfer line and would control ancillary flows of helium gas generated by vaporization of the liquid helium. It would precool the transfer line, as needed, to minimize boiling of liquid helium in the line and would prevent the flow of warm gas into the cryostat.

The system would include a liquid-level sensor in the cryostat, an electronic control circuit, three valves (V1, V2, and V3, as shown in the figure), and a temperature sensor in the transfer line upstream of V1. The transfer line would comprise a stainless steel inner tube for carrying liquid helium, surrounded by a vacuum jacket to minimize loss of heat, surrounded by an outer tube for the passage of helium gas to cool the parts within. V2 would control the flow of liquid helium through the inner tube. V1, located at the top of the inner tube, would control the flow of helium gas from the inner tube to the outer tube. After flowing through the outer tube, the helium gas could be vented, or, if necessary for safety, it could be collected. V3 would be used to stabilize the system by bleeding off helium gas generated by vaporization in the storage tank.



Three Valves Would Control the Flows of liquid and gaseous helium in this system.


Upon sensing that the cryostat liquid level was below the minimum acceptable level, the system would trigger a regulator to pressurize the storage tank to pump liquid helium into the transfer line. Simultaneously, V1 would be opened. The initial warmth of the transfer line would cause some of the liquid helium to boil; the resulting vapor would flow through V1 into the outer tube. Once the temperature measured just upstream of V1 had fallen to predetermined level near the boiling temperature of helium, V1 would be closed and then V2 would be opened so that liquid helium could flow through the inner tube to the cryostat. When the cryostat liquid level reached the maximum acceptable level, the transfer would be considered to be complete and hence both V1 and V2 would be closed.

This work was done by G. Mark Cushman and Richard M. Gummer of Goddard Space Flight Center.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Goddard Space Flight Center; (301) 286-7351. Refer to GSC-14106.

SEALMASTER® INFLATABLE SEALS

"They're
Deucedly
Clever"



Fitting Solutions For Troublesome Design Problems!



Eliminate closure difficulties where gaps or irregular and uneven surfaces exist with a custom-built, fabric-reinforced, elastomeric inflatable seal. Use anywhere a positive seal is required between opposing surfaces. We've developed over 5,500 different products in a wide range of sizes and configurations. We'll help solve your problem.

Ask about our RSVP Design Assistance Program.



SEAL MASTER CORPORATION
Inflatable seals and other custom rubber products

368 MARTINEL DRIVE, KENT, OH 44240-4368 USA
800.477.8436 • 330.673.8410 • FAX 330.673-8242
E-mail: info@sealmaster.com • www.sealmaster.com

Algorithm for Computing Dynamics of Molecules

Equations of motion are solved more efficiently.

NASA's Jet Propulsion Laboratory, Pasadena, California

The Newton-Euler Inverse Mass Operator (NEIMO) algorithm and software that implements the algorithm have been developed to reduce the amount of time needed to perform computational simulations of the dynamics of macromolecules. The NEIMO algorithm and the associated software are intended, in particular, for simulations of molecular motions at a space-time mesoscale, defined here as a length scale ranging from nanometers to micrometers and a time scale ranging from microseconds to milliseconds. Older molecular-dynamics algorithms and computer programs are not suitable for mesoscale simulations because they were formulated for the time scales, of the order of a microsecond or less, characteristic of such high-frequency degrees of freedom as stretching of molecular bonds.

If, in a macromolecular-dynamics computation, one constrains the high-frequency degrees of freedom and uses internal coordinates, one not only reduces the number of degrees of freedom but also enables the use of a larger time step in numerical integration. Doing so also eliminates friction in the simulated system, enabling fast and efficient searches among conformations. On the other hand, the use of internal coordinates leads to coupled equations of motion. The solution of the equations involves inversion of a dense mass matrix. Older algorithms that solve coupled equations of motion exhibit computational complexity proportional to $O(N^3)$, where $O(X)$ signifies a number of the order of X and N is the number of degrees of freedom in a simulated system. For example, for a rhinovirus containing nearly 500,000 atoms, it would be necessary to invert a 167,000-by-167,000 matrix at every time step — clearly impractical.

The NEIMO algorithm was derived within the theoretical framework of the spatial-operator formulation of multi-body dynamics. This formulation, which has been discussed in a number of previous issues of *NASA Tech Briefs*, was conceived for modeling the dynamics of complex, articulated collections of bodies (principally, multiple-link robot arms); since its conception, this formulation has also been found to be useful for simulating the dynamics

of a variety of complex systems, including molecules. The software that implements the NEIMO algorithm is a modified version of the DARTS computer program, which was also based on the spatial-operator formulation and was reported in "Program for Simulating Dynamics of Multibody Systems" (NPO-20168), *NASA Tech Briefs*, Vol. 22, No. 2 (February 1998), page 70.

The great advantage of NEIMO is that in comparison with the older algorithms, it involves much less computation. The computational complexity of the NEIMO algorithm is proportional to $O(N)$ — much less than $O(N^3)$ for multiple degrees of freedom. The NEIMO algorithm solves the constrained equations of motion efficiently by keeping all high-frequency

SMART SWITCHES

THE INTELLIGENT WAY TO LAUNCH ANY APPLICATION



TEXT

STILL IMAGES

MOVING
DISPLAYS



NKK's liquid crystal smart switches could be the brightest idea you ever had. They can be programmed to display numbers, characters, still images and moving graphics. They can also be programmed with switch-to-switch animation sequences that guide users through an error-free succession of even the most complex actuations. Regardless of your industry, don't launch another application without looking into NKK Smart Switches.

NKK[®]

SWITCHES

Phone (480) 991-0942 • Fax (480) 998-1435
7850 E. Gelding Drive, Scottsdale, Arizona 85260
www.lcdswitch.com

INTERACTIVE CIRCUITS AND SYSTEMS LIMITED

Record Sensor Signals at 50MB/s with our Portable daqPC



An 'Open Architecture' PC that
Acquires, Archives and Networks
Analog Sensor Signals in Real-Time

info@ics-ltd.com
www.ics-ltd.com

From Sonar to Cellular

INTERACTIVE
CIRCUITS AND
SYSTEMS LTD.

For Free Info Circle No. 431 or
Enter No. 431 at www.nasatech.com/rs

DYNETIC SYSTEMS

New Concepts in Motion

Quality Servo Motors, Gear Motors & Actuators

Aerospace, Military, Medical
& Industrial Applications

Built to suit your
application



Custom Connectorization & Cabling

Harsh environments, Temperature Extremes,
and DO-160D EMI Specs are no problem

Dynetic Systems
19128 Industrial Blvd
Elk River, MN 55330
(763)441-4300 fax (763)441-5217
sales@dynetic.com

modes fixed and reduces the number of degrees of freedom from $3M$ (where M is the number of atoms) to M . The remaining degrees of freedom are the dihedral ones.

This work was done by Abhinandan Jain, Guillermo Rodriguez, and Nagarajan Vaidehi of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Physical Sciences category.

This software is available for commercial licensing. Please contact Don Hart of the California Institute of Technology at (818) 393-3425. Refer to NPO-20796.

Improving Thin Foil X-Ray Mirrors

Resolution and diameter would be increased.

Goddard Space Flight Center, Greenbelt, Maryland

A proposal has been made to develop improved thin foil, replicated conical mirrors for use in x-ray astrophysics. In the NASA astrophysical programs in which such mirrors are used, they are required to be lightweight, and to offer moderate angular resolution and high throughput to afford required sensitivity in the photon-energy band from 0.1 to 20 keV. In the proposed improvement program, emphasis would be placed on increasing resolution and diameter:

- Angular resolution would be increased from the current level (half-power diameter of 1 arc minute, achieved for the Astro-E mission) to a higher level (half-power diameter of 15 arc seconds, required for the Constellation-X mission).
- Mirrors with diameters as large as 1.6 m would be developed.

Increased angular resolution of replicated conical foil mirrors depends mostly on the geometric accuracy and microscopic roughness of the surface being replicated, and on the accuracy with which the foil reflectors are held in position in mirror structures. According to the proposal, precise conical mandrels with root-mean-square surface roughness less than 5 \AA would be either fabricated in house or bought to demonstrate the ability to make precise reflectors. Polished quartz or Zerodur (or equivalent low-thermal-expansion glass) mandrels as well as less expensive diamond-turned nickel mandrels would be tested. The following three approaches would be investigated as means for increasing the accuracy of holding fixtures: (1) highly precise electrical-discharge machining, (2) diamond turning, and (3) application, to silicon fixtures, of microlithographic and etching techniques used in fabricating microelectronic circuitry.

Simultaneously with the efforts to increase angular resolution, there would be efforts to develop a prototype mirror with a diameter of 1 m. This effort would entail procuring and replicating reflectors from 1-m-diameter mandrels, and fabricating housings of the appropriate dimensions. The housing for the 1-m mirror would likely be designed similarly to housings used for the current narrower conical foil x-ray mirrors, except for modifications needed to attain the required angular resolution.

This work was done by Robert Petre, William Zhang, and Peter Serlemitsos of Goddard Space Flight Center and Yang Soong of USRA. For more information, contact the Commercial Technology Office at Goddard Space Flight Center at (301) 286-5810. GSC-14043



Σ An Improved Genetic Algorithm for Optimal Spacecraft Scheduling

A genetic algorithm and heuristic routine are combined to improve scheduling performance.

NASA's Jet Propulsion Laboratory, Pasadena, California

A method of computing globally optimal schedules and plans in the face of possibly temporally varying constraints involves the use of an improved genetic algorithm. The method and computer program are directed toward the eventual use to schedule tasks to be performed on spacecraft.

The main problem in scheduling is to select the order and the starting and ending times of tasks so that they do not violate constraints; among other things, this means that the instantaneous aggregate demands of the tasks must not exceed the available resources (e.g., finite power-generating capacities) and that the tasks must be completed within the allowable time. One can treat a scheduling problem as a global-optimization problem if one embeds resource limits and other constraints into a cost or fitness function. One can then use a genetic algorithm to search the space of potential solutions.

The present genetic algorithm incorporates several improvements over a

prior algorithm that result in better performance, including higher speed and improved schedules. One improvement is a heuristic routine (see figure) that takes the order of tasks as input and generates the starting times of the tasks as output.

Another improvement is a capability for systematic incorporation of time and task ordering constraints. Specific tasks

```

input = order of tasks
output = starting times of the tasks

for time = first to last
  for task = first to last
    if task satisfies ordering constraints
      if task satisfies resource constraints
        starting time of the task = time;
      end
    end
  end
end
end

```

This **Heuristic Routine** generates feasible solutions for the improved genetic algorithm. This routine has been found to be particularly effective for scheduling tasks subject to resource and time constraints.

can now be forced to be performed before, after, or during other tasks, and/or specified absolute times. Time-out and nonoverlap constraints can also be applied. These new time and task ordering constraints are added to the resource constraints that were included in the prior algorithm.

Still another improvement is a capability for adaptive resequencing. In this mode, the genetic algorithm functions in an environment where resource constraints, time constraints, and task priorities can change at any time. Examples have shown that the algorithm works well, even when such changes are made during computation.

This work was done by David Bayard, Hamid Kohen, George Papavassilopoulos, and Il-jun Jeong of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Information Sciences category. NPO-20884

Σ Timeout Algorithm for Communications With Long Delays

Communications over long or intermittent links would be more efficient.

NASA's Jet Propulsion Laboratory, Pasadena, California

A query timeout detection algorithm has been proposed to support a protocol for reliable communications over links that are characterized by long delays because of (1) propagation of signals over interplanetary distances and/or (2) intermittency. The protocol could be an interplanetary analogue of Transmission Control Protocol/Internet Protocol (TCP/IP) of the terrestrial Internet. The protocol would enable the interconnection of the terrestrial Internet with the internets planned for Mars and other destinations in the Solar system. Potential beneficiaries include operators of space-exploration missions in the

short term and commercial internet users in the long term.

"Timeout" as used here refers to a deadline for determining whether it is necessary to retransmit a packet of data because either the packet or an acknowledgement of the packet was not delivered. Timeout intervals can be estimated from signal-propagation times. However, in the presence of extremely long and variable propagation delays and/or intermittency of communication links, the proposed algorithm would estimate timeout intervals more accurately and thus make it possible to utilize available transmission time more efficiently.

In the proposed algorithm, a timeout interval would be represented as a sum of eight subintervals. Values of some of the subintervals would be estimated initially and used to determine a reasonable future time when their final values must be calculated. At that time, the sum of subintervals would be recalculated to determine a final deadline.

This work was done by Scott C. Burleigh of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Information Sciences category. NPO-20519

STRUCTURAL ADHESIVE RESISTS UP TO 500°F

MASTER BOND POLYMER SYSTEM EP34CA

- Excellent bond strength to similar and dissimilar substrates
- 100% reactive, does not contain solvents or other volatiles
- Low viscosity assures convenient application
- Simplified thermal cure schedules
- Highest physical strength properties
- Outstanding dimensional stability and durability
- Superior resistance to water, fuels, lubricants and other aggressive chemicals
- Remarkable electrical insulation properties
- Job-tailored packaging


www.masterbond.com

For information,
call or write:
Master Bond Inc.,
154 Hobart St.
Hackensack, NJ 07601
201-343-8983

Master Bond Inc.
Adhesives, Sealants & Coatings

For Free Info Circle No. 436 or
Enter No. 436 at www.nasatech.com/rs

Rotating Electrical Connectors



- Superior to conventional slip rings, Mercotac's liquid metal-wetted contacts provide reliability. No electrical noise, less than 1 milliohm resistance.
- Durable, compact, low cost, no maintenance. Ideal for computers, instrumentation, thermocouples, strain gauges, packaging, heating and control equipment.



Mercotac Inc.

6195 Corte del Cedro #100
Carlsbad, California 92009
760 431 7723 • Fax 760 431 0905
Internet: www.mercotac.com
e-mail: info@mercotac.com

For Free Info Circle No. 437 or
Enter No. 437 at www.nasatech.com/rs



Books & Reports

Solar Sails Would Be Made From Carbon Nets

A report proposes that solar sails for spacecraft be made from nets of carbon fibers. The reason for choosing carbon nets over thin polymeric films is that nets offer greater capability for carrying tensile loads. The sails could be made from carbon-fiber nets of various thicknesses: nets used for high emissivity could be made from nanotube carbon fibers; nets for holding aluminum reflectors could be made from micron-thickness fibers; nets to carry tensile loads in sails could be made from fibers with thicknesses between 10 and 100 μm ; and nets to carry large bulk loads and loads in high-stress areas could be made from fibers with thicknesses from 100 to 1,000 μm .

This work was done by Charles Garner of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Carbon Net Solar Sail," access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Materials category.

NPO-20852

Solar Sails Would Be Segmented To Minimize Stresses

A report proposes that solar sails for spacecraft be constructed in segments in such a way as to minimize stresses. The segments could be made of metallized fabric or film and could be connected by short, strong tethers. Alternatively, the segments could be like islands, held loosely in pockets bounded by fibers. For stowage during transport to outer space, the sails could be folded along the gaps between segments, so as to minimize folding stresses in the sail material. Because tensile and other stresses in the sail material would be minimal, the sail material could be made in a thickness of the order of a micron and could thus be very lightweight. In cases in which there are requirements for sails to sustain tensile stresses, carbon-fiber nets like those described in the preceding article could be used.

This work was done by Charles Garner of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Segmented Solar Sail Design," access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Materials category.

NPO-20853

Modular Propulsion Clusters

A report proposes the development of modular propulsion clusters (MPCs) — small, self-contained propulsion systems that would be standardized, mass-produced, and readily installed on a variety of miniature future spacecraft. The MPCs would be inexpensive, "turn-key" alternatives to expensive conventional propulsion systems that are designed and built integrally with other spacecraft systems and structures. Each MPC would contain its own propellant tank, isolation valve, gas plenum, and valve/nozzle thruster assemblies. Each MPC would be delivered fully loaded; installation on a spacecraft would involve only mounting and electrical connections. The propellant would be a liquid that, by electrical actuation of valves, would be metered into the plenum as needed to vapor-

ize and generate thrust. An important advantage of using a vaporizing propellant liquid (as opposed to a propellant gas) is that stopping a liquid leak is orders of magnitude easier than is preventing a gas leak.

This work was done by Barry Nakazono of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Modular Propulsion Cluster," access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Machinery/Automation category. NPO-20783

Positioning System for a Human Habitat in a Large Centrifuge

A report describes the system for controlling the radial position and tilt of a spacecraftlike habitat for humans in NASA's Space Flight Environmental Simulator (SFES) — a 16-m-diameter centrifuge used previously to evaluate effects of hyper-gravitational acceleration on animals. The habitat-positioning system was installed as an upgrade of the SFES to enable similar testing on humans to obtain guidance for designing centrifugal artificial-gravitation systems for future spacecraft.

This work was done by W. F. Caldwell, Jr., of Ames Research Center, J. Tucker of Gates/Arrow Distributing, and P. Keas of Sverdrup Technology, Inc. To obtain a copy of the report, "Human Habitat Positioning System for NASA's Space Flight Environmental Simulator," access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Machinery/Automation category. ARC-14331

Launch-on-Demand Servicing Microsatellites


A report describes an emerging class of miniature, highly capable, relatively inexpensive satellites that could be launched rapidly by nontraditional methods. Of particular interest is a subclass of proposed launch-on-demand microsatellites for inspecting and servicing other satellites (targets) already in orbit. A satellite of this subclass would have a mass of ≤ 30 kg and could be launched, by use of a modified missile system, from a fighter airplane in flight.

This work was done by George Jaivin of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Novel Missions for Next Generation Microsatellites: The Results of a Joint AFRL/JPL Study," access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Machinery/Automation category. NPO-20813

First-Generation Integrated Free-Flying Micro-Spacecraft

The concept of free-flying micro-spacecraft was to develop a miniature spacecraft system fully integrated with a scientific sensor. A fleet of such tiny spacecraft would be deployed in space for multi-probe measurements of a three-dimensional phenomenon and to separate the spatial/temporal variations of that phenomenon. They would measure a parameter of interest, process the data onboard, and communicate the data in real time.

This work was done by Hamid Javadi, Raymond Goldstein, and James Randolph of Caltech for NASA's Jet Propulsion Laboratory. To obtain copies of the reports, "A Fully Integrated Micro-Magnetometer/Microspacecraft for Multipoint Measurements: The Free-Flyer Magnetometer" and "First-Generation Jet Propulsion Laboratory 'Hockey-Puck' Free-Flying Magnetometers for Distributed In-Situ Multiprobe Measurement of Current Density Filamentation in the North-



Quality


**RIGHT ANGLE
GEARBOX IS 80% TO
90% EFFICIENT**

The **G250 RAE Gearbox** has greater torque with smaller DC motors. Powerful and highly efficient. 250 in-lbs torque rating. Outperforms all others in savings and power.

RAE Corporation

4615 W. Prime Parkway • McHenry, IL 60050-7937 USA
Tel 815-385-3500 • Fax 815-363-1641 • www.raemotors.com

SMMA
Small Motors & Motion Actuators



Quality

**POWERFUL and
COMPACT**


RAE's **M1600 DC Motor** offers high continuous torque, speeds to 5000 RPM, high energy ceramic magnets, and double shielded ball bearings. Wide selection of applications.

RAE Corporation

4615 W. Prime Parkway • McHenry, IL 60050-7937 USA
Tel 815-385-3500 • Fax 815-363-1641 • www.raemotors.com

SMMA
Small Motors & Motion Actuators

**For Free Info Circle No. 438 or
Enter No. 438 at www.nasatech.com/rs**



Your best solutions come from flexible thinking.

For closed-cell foam solutions, our design team is ready to help you formulate a solution that fits your needs. Whether an Automotive, Medical, or Industrial Design application, our product line of Volara®, Volextra®, and Minicel® all provide dependable, high-quality, cost-effective ways to enhance your ideas. To find out more, or to receive a free "Thought Starter", call: (800) 225-0668 today.



Ideas Formed in Foam

NAS

100 Shepard Street, Lawrence, MA 01843 • Web Site: www.voltek.com

**For Free Info Circle No. 440 or
Enter No. 440 at www.nasatech.com/rs**



Flexible Bladders

NASA Qualified

- BLADDER TANKS & AIR CELLS
- DIAPHRAGMS & ACTUATORS
- BELLOWS & FUEL CELLS
- STRESS TEST BLADDERS
- CUSTOM INFLATABLES
- PNEUMATIC / HYDRAULIC PRESSES

ATL 800-526-5330

AERO TEC LABORATORIES INC.
 RAMSEY, NJ 07446-1251 USA
 TEL: 201-825-1400 • FAX: 201-825-1962
 e-Mail aerotec@cybernex.net
 http://www.atlinc.com

For Free Info Circle No. 443 or
 Enter No. 443 at www.nasatech.com/rs

Official NASA Logo Sweatshirts



NASA vector logo on quality white cotton sweatshirt.

Available in adult – M, L, XL. \$19.95 + shipping. A great holiday gift idea!

Order online:

www.nasatech.com/store

New!



Mechanical Engineer's Handbook

An essential companion for the mechanical engineer. With over 1,000 pages, 550 illustrations,

and 26 tables, the Mechanical Engineer's Handbook is comprehensive yet affordable and portable. It covers all major areas of mechanical engineering & design with succinct definitions, formulas, and examples.

Hardcover • 1,100 pages
Introductory price: \$67.95

Order online:

www.nasatech.com/store

Auroral Zone: Entrophy Mission, access the Technical Support Package (TSP) **free on-line** at www.nasatech.com under the Physical Sciences category.
 NPO-20728

Miniature Electrothermal Thruster

A report proposes a miniature electrothermal spacecraft engine. The engine would include a chamber with an inside length of ≈ 1.5 cm and inside diameter of ≈ 0.25 cm, with a dielectric (ideally diamond) sidewall lining, a metal-coated expansion nozzle at one end, and a metal electrode at the other end. A propellant liquid (ammonia) would be vaporized into the cavity. To heat the NH_3 vapor and dissociate it to a nitrogen/hydrogen plasma, the cavity would be excited with an electromagnetic field at a cavity resonance frequency of about 25 GHz (also the frequency of a dielectric resonance of NH_3). The expansion of the plasma through the nozzle would generate thrust. The electric field would be of such a strength and configuration as to prevent contact between the plasma and the inner surface of the chamber. The plasma skin depth would be great enough that the plasma could absorb a large proportion of the electromagnetic energy. By use of refractory electrode and dielectric materials, pulsed operation, and, preferably, evaporative cooling of the chamber wall by the propellant liquid, it should be possible to achieve high plasma temperature and pressure and, thus, high thrust.

This work was done by Frank T. Hartley of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Miniature Microthermal Thruster," access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Machinery/Automation category.
 NPO-20969

Using Photosynthetic Bacteria To Make Oxygen on Mars

A report presents a proposal to harness photosynthetic bacteria to generate essential materials needed during human and robotic exploration on the surface of Mars. Utilizing an extremely small amount of H_2O and an ample amount of CO_2 (and N_2 and/or other elements and compounds) already present in the Martian environment, along

with sunlight as the source of energy, the bacteria would produce O_2 and carbon-containing compounds (and nitrogen-containing compounds). The O_2 could be used to support human respiration and to burn fuels; the other compounds could be used, variously, to produce food and fuel or to grow green plants other than bacteria to produce food and fuel. The proposal would exploit the inherent capability of bacteria to reproduce and to adapt to changing environmental conditions. Bacteria to implement the proposal would be bred selectively and/or be genetically engineered for the intended applications, starting from candidate strains of natural terrestrial purple and green bacteria and cyanobacteria that can withstand harsh environments.

This work was done by Hamid Kohen of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "A Biologically Evolved and Genetically Engineered Bacteria for Facilitating Oxygen Delivery Throughout the Mars Advanced Outpost," access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Bio-Medical category.
 NPO-20927

DNS of a Transitional Supercritical $\text{C}_7\text{H}_{16}/\text{N}_2$ Mixing Layer


This report discusses direct numerical simulations (DNS) of a mixing layer, between a nitrogen stream and a heptane stream initially flowing at different velocities, under supercritical conditions and undergoing a transition to turbulence. Thermodynamically, supercritical conditions prevail when either the temperature or the pressure exceeds its critical value; the critical regime is in particular characterized by the existence of a single phase. The governing conservation equations were formulated according to fluctuation-dissipation (FD) theory, in which the low-pressure typical transport properties (viscosity, diffusivity, and thermal conductivity) are complemented, at high pressure, by a thermal-diffusion factor.

This work was done by Josette Bellan and Nora Okong'o of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Direct Numerical Simulation of a Transitional Supercritical Mixing Layer: Heptane and Nitrogen," access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Physical Sciences category.
 NPO-21144

New on the WEB

Lighting Products

A new Web site from Gilway Technical Lamp, Woburn, MA, features lens-end lamps, miniature and neon lamps, halogen lamps, cold-cathode fluorescent — and pre-focused lamps and reflector assemblies, and a range of LEDs in thousands of thru-hole and SMT configurations. Specifications are offered in downloadable PDF files. E-mail links are built in for obtaining quotations and catalogs. www.gilway.com




Motors and Drives

Pacific Scientific, Rockford, IL, has established a chat room on its Web site where engineers can answer customer questions regarding Pacific Scientific motors and drives, and their applications. By logging in, users may speak to a Pacific Scientific engineer, although

the room is available to anyone with an interest in chatting about industry issues. www.pacsci.com

CAD Translation

CADCAM-E.COM, Farmington Hills, MI, has introduced a Web translation service from ACIS- to PARASOLID-based CAD/CAM/CAE systems. The service allows users to read and manipulate data files generated by enterprise CAD systems. Users can download software and perform translations at their desktop. The service converts curve, surface, and solid data between the ACIS and Parasolid solid modeling kernels. www.cadcam-e.com



Pump Assemblies



A Web-based VPV product locator has been introduced by Bosch Automation Technology, Racine, WA. The feature allows users to create a valid VPV pump model code while reviewing features and options during the selection process. Once a model code is selected, the system will determine if a production part number has been previously issued. If the Bosch 10-digit number is already known, the user can enter any portion of the

number to explore the established model code. www.boschat.com


Synchronize to GPS



- Accurate GPS Satellite Clocks
- Synchronize Computers Precisely
- IRIG Time Code Input/Output
- Generate Pulse Rates

www.true-time.com

800.328.1230



For Free Info Circle No. 446 or
Enter No. 446 at www.nasatech.com/rs



We're BIG on the little things.

No matter how complex your custom stamped components, you can count on us to provide you with exceptional quality and service from start to finish. We firmly believe that superior technology sets us apart... yet, we also know paying attention to the small details is just as important. From design to delivery, we're committed to you—and that makes cents for us both.

Meier
TOOL & ENGINEERING INC.

875 Lund Blvd., Anoka, MN 55303
763-427-6275 • Fax: 763-427-9242
www.meiertool.com



ASME International

In Business Problems? In-Company Solutions

*Identify your training needs and save time,
while cutting costs with ASME In-Company
Programs!*

- ASME has the engineering courses and industry experts that enable your company to stay ahead in today's competitive marketplace.
- We will work closely with you to ensure that objectives are met and examples are incorporated specific to your company's needs.

*Call or e-mail to find out more information about
ASME In-Company Programs today!*

ASME International

Tel: 212-591-7752

Web: www.asme.org/pro_dev

Email: rubine@asme.org

**For Free Info Circle No. 449 or
Enter No. 449 at www.nasatech.com/rs**

SENIOR SCIENTIST FOR SPACE EXPERIMENTS

AFRL's Space Vehicles Directorate invites applications for the position of **Senior Scientist, Space Experiments**. We are seeking an internationally recognized expert in **science or engineering** to ensure that the scientific goals for Space Vehicles Directorate space experiments and demonstration of breakthrough technologies are accomplished and results provide significant new capabilities to the Air Force space mission.

Applicants should have an outstanding record of achievement in space experiments through a strong publication record, research citations, invited lectures and patents, and international recognition for contributions in space science technology. A Doctorate or equivalent and a Fellowship in a national professional society are also desired.

This senior AFRL position is open only to exceptionally qualified candidates and located at the Air Force Research Laboratory, Space Vehicles Directorate, Kirtland Air Force Base, Albuquerque, New Mexico. Salary and other employment factors are negotiable.

Further application information can be obtained from Dale Hite at (505) 846-2602, Ms Linda Kapitan, HQ AFMC/DPK, (937) 257-1094, or under "Space Experiments" at <http://www.afmc.wpafb.af.mil/HQ-AFMC/DP/dph>. The Air Force is in an equal opportunity employer.

New on the MARKET

Ultrasonic Level Transmitter

The LVU-1100 Series ultrasonic, non-contact, remote liquid level transmitter from OMEGA Engineering, Stamford, CT, uses small sensor technology to fit into hard-to-reach spaces such as existing capacitance system installations. The transmitter consists of a transducer and micro-processor-based electronics housed in a NEMA 7 explosion-proof enclosure. It has a 3/4" NPT mount for ranges from 1 to 12 feet. The sensor is suitable for liquid level measurement and product runoff. **For Free Info Circle No. 700 or Enter No. 700 at www.nasatech.com/rs**




Single-Board Computer



WinSystems, Arlington, TX, has introduced the LPM-TX industrial-grade single-board computer based on Intel's "Tillamook" Pentium® processor. The board provides an upward migration path for STD Bus systems while maintaining hardware, I/O, and software compatibility over a full industrial temperature range. It operates at a system clock speed of 166 MHz, and includes 16 KB of code, 16 KB of data cache, and a floating point processor for math-intensive applications. It comes with 32 MB or 64 MB of surface-mounted synchronous DRAM. **For Free Info Circle No. 701 or Enter No. 701 at www.nasatech.com/rs**

Simulation Software




MSC.Marc 2001 nonlinear simulation software from MSC.Software Corp., Santa Ana, CA, is part of the MSC.visualNastran Enterprise family, and features scalable parallel technology for advanced contact analysis, automated 3D meshing tools to reduce testing, and simulation capabilities for transportation, biomedical, and other industries. Other features include intuitive modeling capabilities including a graphical user interface, direct access to CAD geometry, and meshing capabilities. Applications include manufacturing simulations such as contact, forging, rolling, welding, sheet stamping, and interference fitting of materials ranging from metals to elastomers. **For Free Info Circle No. 705 or Enter No. 705 at www.nasatech.com/rs**

Switching Card

The Model 7090 optical switching card from Keithley Instruments, Cleveland, OH, enables optical, DC, and RF switching. It provides switching of an optical signal among several instruments, a single instrument among multiple devices, or a combination of both. The card is designed for optoelectronic device manufacturers to automate test applications. The card is available in 1 x 4 and 1 x 8 switching configurations. **For Free Info Circle No. 702 or Enter No. 702 at www.nasatech.com/rs**





PRECISION ALUMINUM EXTRUSIONS

New! An informative brochure from MIN-ALEX, leader in close tolerance shapes to 3 1/2", illustrates typical applications and describes capabilities including short runs. MINALEX, quality leader, delivers on time, every time. MINALEX, PO Box 247, Whitehouse Station, NJ 08889; Tel: 908-534-4044; Fax: 908-534-6788.

Minalex

For Free Info Circle No. 601 or
Enter No. 601 at www.nasatech.com/rs




DATA ACQUISITION AND INSTRUMENTATION eCATALOG

This free 37-page short-form catalog from IOTech features product overview charts and selection guides for IOTech's wide range of data acquisition systems and signal conditioning options. New products include the ScanWare™ family of products for Ethernet-based data acquisition and a new multi-function, 8-channel counter/encoder module for the portable data acquisition systems. IOTech, Inc.; Tel: 440-439-4091; Fax: 440-439-4093; email: sales@iotech.com; website: www.iotech.com

IOTech, Inc.

For Free Info Circle No. 604 or
Enter No. 604 at www.nasatech.com/rs




NEW 2001 RETAINING RING CATALOG

Smalley has over 4,100 rings in stock, sizes from 1/2" to 16". Special designs are available with No-Tooling-Charges™ with sizes from 9/32" to 84"; available in carbon and stainless steel. Smalley engineers are always available for FREE design assistance. Smalley rings have No Ears to Interfere™. Smalley Steel Ring Company, 385 Gilman Avenue, Wheeling, IL 60090; Tel: 847-537-7600; Fax: 847-537-7698; e-mail: info@smalley.com; www.smalley.com

Smalley Steel Ring Company

For Free Info Circle No. 607 or
Enter No. 607 at www.nasatech.com/rs



DISTANCE LEARNING SAVES TIME AND MONEY

Learn Finite Element Analysis using ALGOR software right at your desk with hundreds of Internet-based software demonstration Webcasts and in-depth product training Web Courses at learn6.eTechLearning.com. Web Courses qualify for Professional Development Hours toward P.E. license renewal. ALGOR, Inc.; Tel: 412-967-2700; e-mail: learn6@eTechLearning.com; learn6.eTechLearning.com

ALGOR, Inc.

For Free Info Circle No. 610 or
Enter No. 610 at www.nasatech.com/rs



FREE DATA ACQUISITION STARTER KIT

Maybe you've always wanted to try PC-based data acquisition. Or maybe you acquire data now but aren't pleased with the results or performance. Here's your chance to try our solution absolutely FREE. Sign up to receive our WinDaq Starter Kit that includes data acquisition hardware, and a CD-ROM containing WinDaq software, a multimedia tutorial, and electronic catalog. Visit DATAQ Instruments on the web at www.dataq.com/nlit to register.

DATAQ Instruments



AUTOMATED TEST AND MEASUREMENT SOLUTIONS BROCHURE

Automated Test and Measurement Solutions, a free brochure from National Instruments, describes how scientists and engineers can increase productivity and lower costs by using the latest PC technologies with National Instruments software and hardware to create high-performance, computer-based measurement and automation systems. Call today for a free brochure. National Instruments; Tel: 800-894-0885 (U.S. and Canada), 512-794-0100; Fax: 512-683-9300; e-mail: info@ni.com; www.ni.com/info/test

National Instruments

For Free Info Circle No. 603 or
Enter No. 603 at www.nasatech.com/rs




REVVO CASTERS & WHEELS

New brochure presents Revvo's comprehensive line of light, medium and heavy-duty casters and wheels for industrial products, display stands, medical equipment, furniture, business machines, material handling and special applications. Competitively priced, Revvo casters and wheels are manufactured to the highest quality standards for performance and durability. The Revvo Caster Company, Inc., 2440 North America Dr., West Seneca, NY 14224; Tel: 716-675-9609 or 888-883-3596; Fax: 716-677-2363; e-mail: revvoinc@msn.com; www.revvocaster.com

The Revvo Caster Company, Inc.

For Free Info Circle No. 605 or
Enter No. 605 at www.nasatech.com/rs



SCSI ENCLOSURES

StorCase™ Technology is pleased to announce the release of a new line of external expansion chassis, the InfoStation™ backplane-design SCSI enclosure. Its direct connect backplane supports up to 9 high-density, high-speed, 3.5" SCSI single-ended, Ultra2, or Ultra160 SCA devices for RAID or JBOD applications. With upgrade slots for adding RAID and SAFE controller modules, the InfoStation is ready for the future when you are. StorCase Technology, a Kingston Technology Co.; www.storcase.com

StorCase Technology, Inc.

For Free Info Circle No. 606 or
Enter No. 606 at www.nasatech.com/rs



LIGHT DETECTOR ASSEMBLIES

Electron Tubes' catalog features a complete line of Light Detector Assemblies designed for very low and high light level detection and measurement. Assemblies are available for analog, photon counting and pulsed light applications. Ideal for Spectrophotometry, Bioluminescence and Chemiluminescence, Harsh Environments, Scintillation Counting and High Energy Physics Experiments. For information or assistance please visit us at www.electrontubes.com, call 800-521-8382, or E-mail us at sales@electrontubes.com.

Electron Tubes Inc.

For Free Info Circle No. 608 or
Enter No. 608 at www.nasatech.com/rs




THERMACAM® SC 500 LOW-COST THERMAL IMAGING SYSTEM

Evaluate thermal performance with the powerful, yet affordable SC 500 FPA infrared imaging and temperature measurement system. ThermoCAM IR cameras offer outstanding thermal imaging, non-contact precision temperature measurement, extensive analysis, trending and reporting capabilities for R&D, thermal testing, product validation, design verification, and general scientific applications. FLIR Systems, 16 Esquire Rd., North Billerica, MA 01862; Tel: 1-800-GO-INFRA; www.flir.com

FLIR Systems

For Free Info Circle No. 609 or
Enter No. 609 at www.nasatech.com/rs




DYNAMIC FEA IS EASIER WITH TIMELINE

ALGOR's Timeline Event Manager enables quick, easy definition and visualization of time-based event curves for Mechanical Event Simulation, transient structural analysis and transient thermal analysis. Visit timeline4.algor.com and watch our free Webcast on how Timeline simplifies the setup of events by plotting multiple curves. ALGOR, Inc.; Tel: 412-967-2700; e-mail: timeline4@algor.com

ALGOR, Inc.

For Free Info Circle No. 611 or
Enter No. 611 at www.nasatech.com/rs



ALGOR SIMULATES MEMS

Free Webcasts show MEMS simulation with ALGOR's FEA technology that couples electrostatic analysis and static & dynamic stress analyses, all operated through an easy-to-use interface within CAD that includes model scaling & building tools. Website: mems6.algor.com; email: mems6@algor.com; Tel: 412-967-2700.

ALGOR, Inc.

For Free Info Circle No. 612 or
Enter No. 612 at www.nasatech.com/rs



OMEGA ELECTRIC HEATERS HANDBOOK

OMEGALUX Complete Electric Heaters Handbook and Encyclopedia™ offers equipment for thousands of industrial and lab, electric heating, and temperature control applications. Over 1,000 color pages present heating cables, strip, cartridge, tubular, immersion, lab, specialty, and band heaters. Temperature-related products include controllers, meters, recorders, sensors, hand-helds, and infrared products. Includes prices and ordering information. Over 80 pages of valuable technical information. OMEGA Engineering, One Omega Dr., Stamford, CT 06907; Tel: 203-359-1660; Fax: 203-359-7700; www.omega.com

OMEGA Engineering

For Free Info Circle No. 613 or
Enter No. 613 at www.nasatech.com/rs



FREE CATALOG OF TOOLING COMPONENTS

The Reid Tool Supply catalog offers more than 40,000 items, including handwheels, handles, knobs, spring and ball plungers, vibration-isolation items, leveling pads, clamps, set-up accessories, locating devices, linear motion slides, latches, hinges, thread inserts, bearings, and more. Most items are available in inch and metric. All items are in stock for same-day shipment with no minimum-order requirement. Reid Tool Supply Co., 2265 Black Creek Rd., Muskegon, MI 49444; Tel: 800-253-0421; Fax: 800-438-1145; www.reidtool.com.

Reid Tool Supply Co.
For Free Info Circle No. 614 or
Enter No. 614 at www.nasatech.com/rs




HIGH POWER LASER DIODES

High Power Devices manufactures single emitter, multi-mode diode lasers.

Visible devices range from 635-730 nm with powers from 0.25-1 watt. At IR wavelengths of 780-980 nm, power can range from 0.5-5 Watts to 100 Watts short pulse. All industry standard packages with optional TEC, MPD and Thermistor are available. Custom prototyping and pigtail are optional. High Power Devices; Tel: 732-249-2228; e-mail: info@hpdinc.com; www.hpdinc.com

High Power Devices

For Free Info Circle No. 615 or
Enter No. 615 at www.nasatech.com/rs



MAGNETIC PARTICLE BRAKES & CLUTCHES

Feature smooth, silent slip torque for tensioning (unwind/rewinding), torque limiting & load simulation. Torque is proportional to DC input current, and independent

of slip RPM. Stock items, from 1 oz.-inch to 220 lb.-in. Placid Industries; Tel: 518-523-2422; Fax: 518-523-2746; www.placidindustries.com

Placid Industries

For Free Info Circle No. 616 or
Enter No. 616 at www.nasatech.com/rs



CATALOG OF METALS & MATERIALS

The Goodfellow CD-ROM Catalog of Metals & Materials contains information and pricing for more than 40,000 different items, plus a wealth of technical data. Search for products by chemical name or formula, item number, or trade name, then be linked directly to forms, properties, and pricing. Comparative data tables are also included. Goodfellow, 800 Lancaster Ave., Berwyn, PA 19312-1780; Tel: 800-821-2870; Fax: 800-283-2020; e-mail: info@goodfellow.com; www.goodfellow.com

Goodfellow

For Free Info Circle No. 617 or
Enter No. 617 at www.nasatech.com/rs



FIRST NEMA 4X PLASTIC KEYBOARD

Texas Industrial Peripherals' new Desktop Ultimate is the first NEMA 4/4X industrial keyboard housed in a robust ABS-Polycarbonate plastic case. This innovative product has 119 keys, including 24 function keys, window keys, and an integrated three-button HulaPoint™ pointing device. For more information contact: Texas Industrial Peripherals; Tel: 800-866-6506; Fax: 512-837-0207; www.ikey.com

Texas Industrial Peripherals

For Free Info Circle No. 618 or
Enter No. 618 at www.nasatech.com/rs



DSP LOCK-IN AMPLIFIERS

The SR810 (single phase) and SR830 (dual phase) DSP lock-in amplifiers have a frequency range of 1 mHz to 102.4 kHz, and provide 100 dB of dynamic reserve without pre-filtering. Output time constants range from 10 μs to 30 ks, with 6, 12, 18, or 24 dB/oct rolloff. A low distortion (-80 dBc) synthesized reference source and GPIB and RS-232 computer interfaces are standard. SR810 Single Phase Lock-In: \$3,650; SR830 Dual Phase Lock-In: \$3,950. Stanford Research Systems; Tel: 408-744-9040; Fax: 408-744-9049; e-mail: info@thinkSRS.com; www.thinkSRS.com

Stanford Research Systems

For Free Info Circle No. 619 or
Enter No. 619 at www.nasatech.com/rs




POLYGON SHAFT-TO-HUB CONNECTIONS

Polygon shaft-to-hub connections can transmit twice the torque of involute splines in the same shaft diameter, due to the elimination of stress concentration risers. Three-lobe polygons are self-centering, and provide perfect concentricity, as they are precision ground on centers, with the shaft bearing diameters, using one set-up. They can be ground after heat treating, for absolute minimal clearance and backlash. Zero backlash connections are manufactured using taper polygons. Four-lobe polygons slide under torque loads. Stoffel Polygon Systems, Inc.; Tel: 914-961-2000; Fax: 914-961-7231.

Stoffel Polygon Systems, Inc.

For Free Info Circle No. 620 or
Enter No. 620 at www.nasatech.com/rs



INVESTMENT CASTINGS

Since 1948, EPCO has produced ferrous and non-ferrous investment castings for the aerospace/defense, medical, valve & pump, and countless other demanding applications. Our brochure describes our company and highlights the reasons behind the success of EPCO's high integrity, close tolerance casting technology. Find out how to get the most out of investment castings by contacting us by e-mail: epco@aol.com.

EPCO

For Free Info Circle No. 622 or
Enter No. 622 at www.nasatech.com/rs



PRECISION SLIDES AND STAGES

Precision UniSlide stages, XY, and rotary tables. Useful for positioning a gauge, sensor, cutter, or transducer. Width range from 1-1/2" to 9"; lengths up to 90". Over 950 models. Modular design makes XYZ combinations easy. Use our stock-designed components to make semi-custom fixtures and reduce costs. For more information, see www.velmex.com or call 800-642-6446 or 716-657-6151.

Velmex

For Free Info Circle No. 623 or
Enter No. 623 at www.nasatech.com/rs




MINI-POSITIONING TABLES

New catalog of precision miniature positioning tables designed for applications where precise positioning of smaller payloads within a small work envelope is critical. The new 401XR linear positioners are only 1.6 inches wide and offer standard features such as protective strip seals, linear encoder (0.1 micron resolution), precision ground ballscrew, and high-strength recirculating bearing system. Toll free: (877) 772-0205; www.phdaedal.com/tblf:ddl007@parker.com.

Parker Hannifin Corporation, Daedal Division

For Free Info Circle No. 621 or
Enter No. 621 at www.nasatech.com/rs



FLUXGATE MAGNETOMETERS

Color brochure highlights Walker's fluxgate magnetometers. 11 models to choose from, designed to measure magnetic fields from 0.01 milligauss (1nT) to 2 gauss; accuracy of 0.5% and linearity of 0.02% with analog/RS232 output of DC — 400Hz. Applications include solenoid/helmholtz system calibration, package inspection (FAA/IATA regulations), field mapping and shielding effectiveness. Walker Scientific Inc., Rockdale St., Worcester, MA 01606; Tel: 800-962-4638 or 508-852-3674; Fax: 508-856-9931; www.walkerscientific.com

Walker Scientific Inc.

For Free Info Circle No. 624 or
Enter No. 624 at www.nasatech.com/rs

FREE INFORMATION REQUEST FORM

For quickest service:

Fax this form to (413) 637-4343

Use the online reader service center at www.nasatech.com/rs

Or mail your completed form to
NASA Tech Briefs,
 PO Box 5077, Pittsfield, MA 01203-9109.

Name: _____

Company: _____

Address: _____

City/St/Zip: _____

Phone: _____

Fax: _____

e-mail: _____

Please tell us below how *NASA Tech Briefs* has helped you solve a problem or been applied to your business/product line.

Do you currently receive *NASA Tech Briefs*? ☐ Yes ☐ No

If no, would you like to receive *NASA Tech Briefs*? ☐ Yes ☐ No

ARE YOU AN INSIDER?

Subscribe today to receive the INSIDER, a FREE e-mail newsletter from *NASA Tech Briefs*. The INSIDER features exclusive previews of upcoming articles...late-breaking NASA and industry news...hot products and design ideas...links to online resources...and much more.

☐ I want to be an INSIDER. Send my newsletter to the following e-mail address:

Name _____

Company _____

I also want to receive special-focus e-newsletters on the following technology topics: (check all that apply)

- | | |
|----------------------------------|--|
| <input type="checkbox"/> CAD/CAE | <input type="checkbox"/> Fiber Optics/Communications |
| <input type="checkbox"/> Lasers | <input type="checkbox"/> Test & Measurement |
| <input type="checkbox"/> Optics | <input type="checkbox"/> Imaging/Cameras |
| <input type="checkbox"/> Sensors | |

For fastest service, sign up online
 at www.nasatech.com/insider

Circle the numbers below to receive more information about products and services featured in this issue.

401	402	403	404	405	406	407	408	409	410
411	412	413	414	415	416	417	418	419	420
421	422	423	424	425	426	427	428	429	430
431	432	433	434	435	436	437	438	439	440
441	442	443	444	445	446	447	448	449	450
451	452	453	454	455	456	457	458	459	460
461	462	463	464	465	466	467	468	469	470
471	472	473	474	475	476	477	478	479	480
481	482	483	484	485	486	487	488	489	490
491	492	493	494	495	496	497	498	499	500
501	502	503	504	505	506	507	508	509	510
511	512	513	514	515	516	517	518	519	520
521	522	523	524	525	526	527	528	529	530
531	532	533	534	535	536	537	538	539	540
541	542	543	544	545	546	547	548	549	550
551	552	553	554	555	556	557	558	559	560
561	562	563	564	565	566	567	568	569	570
571	572	573	574	575	576	577	578	579	580
581	582	583	584	585	586	587	588	589	590
591	592	593	594	595	596	597	598	599	600
601	602	603	604	605	606	607	608	609	610
611	612	613	614	615	616	617	618	619	620
621	622	623	624	625	626	627	628	629	630
631	632	633	634	635	636	637	638	639	640
641	642	643	644	645	646	647	648	649	650
651	652	653	654	655	656	657	658	659	660
661	662	663	664	665	666	667	668	669	670
671	672	673	674	675	676	677	678	679	680
681	682	683	684	685	686	687	688	689	690
691	692	693	694	695	696	697	698	699	700
701	702	703	704	705	706	707	708	709	710
711	712	713	714	715	716	717	718	719	720
721	722	723	724	725	726	727	728	729	730
731	732	733	734	735	736	737	738	739	740
741	742	743	744	745	746	747	748	749	750
751	752	753	754	755	756	757	758	759	760
761	762	763	764	765	766	767	768	769	770
771	772	773	774	775	776	777	778	779	780
781	782	783	784	785	786	787	788	789	790
791	792	793	794	795	796	797	798	799	800
801	802	803	804	805	806	807	808	809	810
811	812	813	814	815	816	817	818	819	820
821	822	823	824	825	826	827	828	829	830
831	832	833	834	835	836	837	838	839	840

Advertisers Index

For free product literature from these advertisers, enter their reader service numbers at www.nasatech.com/rs

Advertisers listed in bold-face type have banner ads on the NASA Tech Briefs Web site — www.nasatech.com

Company	Reader Service Number	Page
Aero Tech Laboratories Inc.	443	60
Air Force Research Laboratory		62
Algor, Inc.	594, 593, 610-612	7, 47, 63
Ansoft	520	43
ASME International	449	62
Astro-Med, Inc.	525	17
ATI Industrial Automation	540	19
Autodesk, Inc.	542	15
W.M. Berg, Inc.	659	9b
Coherent, Auburn Division	493	3a
DATAQ Instruments		63
Digi-Key Corporation	517	3
Dymax	459	12a
Dynetic Systems	409	56
Electron Tubes Inc.	608	63
Emhart, a		
Black & Decker Company	410, 567	34, 35
Endevco	401	8
Engineered Precision Casting Company (EPCO)	622	64
Engineering Design Team, Inc.	428	48
FLIR Systems	609	63
Gage Applied, Inc.	404	20
Goodfellow	617	64
Harvard Thermal, Inc., Melcor Corp.	460	13a
HD Systems	658	7b
Helical Products Company, Inc.	660	11b
High Power Devices	615	64
IBM		26
IMRA	473	11a
Innovative Integration	424	51
Interactive Circuits and Systems Ltd.	431	56
IOtech, Inc.	604	50A-B, 63
Keithley Instruments, Inc.	572	41
Master Bond Inc.	418, 436	44, 58
MathSoft Engineering & Education, Inc.	512	COV IV
The MathWorks, Inc.	564	13
Maxon Precision Motors	654-657	5b
Meier Tool & Engineering Inc.	447	61
Mercotac Inc.	437	58
Micro Mo Electronics	651, 652	10b
Minalex	601	63
Minco Products, Inc.	427	53
MSC Software	551	COV III

Company	Reader Service Number	Page
National Instruments Corporation	562, 603, 453, 653	COV II, 63, 6a, 3b
Nexen Group, Inc.	569	21
NKK Switches		55
Noran Engineering, Inc.	422	49
NuSil Silicone Technology	414	45
Omega Engineering, Inc.	613	1, 64
Pacific Design & Manufacturing Show		31
Parker Hannifin Corp., Daedal Division	621	64
Photon, Inc.	451	7a
Photonics West		33
Pittman-A PennEngineering Company	661	2b
Placid Industries	616	64
Polymer Sealing Solutions	423	42
Presray Corporation	425	52
RAE Corporation	438	59
Reid Tool Supply Co.	614	64
Research Systems, A Kodak Company	403	16
The Revvo Caster Company, Inc.	605	63
RGB Spectrum	402	10
Seal Master Corporation	434	54
Smalley Steel Ring Co.	607	63
Solid Edge, UGS	527	29
Stanford Research Systems	619	64
StereoGraphics Corporation	405	22
StockerYale Canada Inc.	454	9a
Stoffel Polygon Systems	620	64
StorCase Technology, Inc., a Kingston Technology Company	523, 606	9, 63
Synrad, Inc.	516	2
Tescom Corporation	406	27
Texas Industrial Peripherals	618	64
Thermal Laser Science	484	5a
TrueTime	446	61
TSI Incorporated, Flowmeter Products	442	28
UDT Instruments	455	14a
United Electronic Industries	412	42
Velmex, Inc.	415, 623	44, 64
Voltek	440	59
VX Corporation	546	4-5
Walker Scientific Inc.	624	64
Yamacraw	486	1a
yet2.com		23, 24
Z-World	426	53

NASA Tech Briefs, ISSN 0145-319X, USPS 750-070, copyright ©2001 in U.S. is published monthly by Associated Business Publications Co., Ltd., 317 Madison Ave., New York, NY 10017-5391. The copyright information does not include the (U.S. rights to) individual tech briefs that are supplied by NASA. Editorial, sales, production, and circulation offices at 317 Madison Ave., New York, NY 10017-5391. Subscription for non-qualified subscribers in the U.S., Panama Canal Zone, and Puerto Rico, \$75.00 for 1 year; \$135 for 2 years. Single copies \$5.00. Foreign subscriptions one-year U.S. Funds \$195.00.


Remit by check, draft, postal, express orders or VISA, MasterCard, and American Express. Other remittances at sender's risk. Address all communications for subscriptions or circulation to NASA Tech Briefs, 317 Madison Ave., New York, NY 10017-5391. Periodicals postage paid at New York, NY and additional mailing offices.

POSTMASTER: Send address changes to NASA Tech Briefs, PO Box 10523, Riverton, NJ 08076-9023.

Honey bee (Apis mellifera)



THE CONCEPT OF CLUSTERING IS AS OLD AS NATURE.
OF COURSE, OUR VERSION DOESN'T
INVOLVE GETTING STUNG.



INTRODUCING CLUSTERING TECHNOLOGY FOR THE REAL WORLD

At MSC.Software, providing clustering solutions for our clients comes second nature to us. In fact, we provide complete turnkey systems for the most demanding computational environments by optimizing the hardware, O/S, middleware and applications. What's more, our advanced MSC.Linux operating system and clustering technology offer extremely cost-effective customized solutions, so you won't feel a sting in your bottom line. Support is always just a phone call away at one of our over 50 offices worldwide. Call us today. And find out what the "buzz" on our company is all about.

For more information call 1.800.642.7437, ext.2500. Or visit www.msclinux.com/bee.

MSC SOFTWARE

Technical projects are a challenge.

Mathcad® 2001 is the most powerful tool for applying mathematics. It is the backbone for your technical desktop applications. With Mathcad 2001, you get faster performance, bi-directional MathML support for viewing and interacting with math in your browser, collaboration tools, powerful simulation and modeling capabilities, full compatibility with the Microsoft® Office suite, MATLAB®, AutoCAD®, and much more.

Now, with the addition of new Mathcad Client, you get a cost-effective way to share interactive technical documents throughout your organization. Isn't it time you standardized on the one corporate solution that ensures all your technical projects run faster and smoother, from start to finish?

Mathcad
2001
Better. Faster. More Powerful.

Also available from your favorite reseller:



Software
Spectrum



Softmart
The smart resource for business



Mathcad 2001 Professional includes IBM techexplorer™ Hypermedia Browser - Professional Edition, SmartSketch® LE, Volo™View Express and VisSim LE. With **Mathcad 2001 Premium** you get everything above plus Axum®, SmartSketch 3 and the Solving & Optimization Extension Pack. Mathcad 2001 runs on Windows 95, 98, 2000 and Windows NT 4.0 or higher. Volume and academic licensing is available.

To order call 1-800-628-4223 or go to www.mathcad.com

MathSoft

© 2001 MathSoft Engineering & Education, Inc. Mathcad is a registered trademark of MathSoft Engineering & Education, Inc. Axum is a registered trademark of Insightful Corporation. AutoCAD is a registered trademark and Volo is a trademark of Autodesk, Inc. SmartSketch is a registered trademark of Intergraph Corporation. Microsoft and Windows are registered trademarks and Windows NT is a trademark of Microsoft Corporation. MATLAB is a registered trademark of The Mathworks, Inc. IBM and IBM techexplorer Hypermedia Browser are trademarks of IBM in the United States and other countries and are used under license. All rights reserved.

For Free Info Circle No. 512 or Enter No. 512 at www.nasatech.com/rs